

NI.



(NASA-TM-79970) AUTOMATIC WELDING OF  
STAINLESS STEEL TUBING (NASA) 150 P  
HC A07/MF A01

N79-18322

CSCL 11F

Unclas

G3/37 16119

# Automatic Welding Of Stainless Steel Tubing

William E. Clautice

National Aeronautics and  
Space Administration

John F. Kennedy Space Center

**NASA**

## CONTENTS

	Page
INTRODUCTION . . . . .	1
TEST METHODOLOGY . . . . .	3
TEST RESULTS . . . . .	11
SUMMARY OF RESULTS . . . . .	20
CONCLUSION . . . . .	22
IMPLEMENTATION . . . . .	23
APPENDIX . . . . .	26

## INTRODUCTION

In the past, stainless steel tubing used in ground support equipment to contain hypergolic, pneumatic, and hydraulic fluids was fabricated by manual welding or induction brazing processes. Traditionally, it has been required that joints fabricated by these processes be 100 percent radiographically inspected, a costly type of inspection. Today, advances in the state of the art have made automatic welding a desirable, cost effective method of replacing the other methods of fabricating this type of tubing. The automatic process provides a precise control of the welding process parameters, minimizing human error and thereby improving the quality of welds over those made by other processes. When the automatic process is used, with its inherent improvement in quality, a question naturally arises concerning the need for the 100 percent radiographic inspection requirement imposed on other methods.

To determine if the use of automatic welding would allow the reduction of the radiographic inspection requirement, and thereby reduce fabrication costs, a series of welding tests were performed. In these tests an Astro Arc automatic tube welder was used on AISI tubing, Type 304, in the 1/2, 3/4, and 1 1/2 inch diameter sizes. The tubing was representative of that used in the hypergolics, pneumatics, and hydraulics systems in the launch complex. The Astro Arc automatic tube welder had been checked out and calibrated previously during a production job where hypergolic valve box assemblies had been fabricated of similar tubing for Space Shuttle ground support equipment. Optimum welding parameters (machine settings) were obtained from the automatic welding procedures previously qualified during production welding. These parameters and qualified procedures were used by certified welding operators as a baseline for proper machine settings and procedures used during testing.

The optimum parameters were investigated to determine how much variation from optimum in machine settings could be tolerated and still result in a good quality weld. Threshold or borderline conditions were established. The effects of variations in the automatic process controls (machine settings) on the weld quality were investigated by making welds over a range of essential variables and by x-raying the resulting welds to study the effect of changing the process variables on the weld quality. The purpose of this study was to establish a range of essential variables (machine settings) for a given tube size to ensure that welds made within this variable range would be of good quality, thus allowing the requirement for 100 percent radiographic inspection to be reduced.

The process variables studied were the welding amperes, the revolutions per minute (RPM) as a function of the circumferential weld travel speed, and the shielding gas flow. Acceptable tolerance ranges for these variables were determined through correlation with good x-ray quality vs bad x-ray quality of the welds.

Strip chart recordings were made of the amperage and RPM to determine if strip charts were definitive enough to identify a good weld vs a bad weld. Tests showed that the strip chart recordings were not definitive enough to accomplish this objective, and the technique was abandoned.

ORIGINAL PAGE IS  
OF POOR QUALITY

The investigation showed, however, that the close control of process variables in conjunction with a thorough visual inspection of welds, (as described hereinafter) can be relied upon as an acceptable quality assurance procedure, thus permitting the radiographic inspection to be reduced by a large percentage when using the automatic process. Radiographic inspection can be eliminated during production welding, with a radiographic inspection requirement remaining only for weld certification testing. Currently, the welding specifications at the Kennedy Space Center are being modified to reduce the radiographic requirements and to substitute the automatic process control and weld visual inspection requirements in their place.



## TEST METHODOLOGY

### EQUIPMENT

The effects of process control variations on weld quality were investigated. The following equipment was used:

1. Astro Arc Power Source and Controls  
Serial No. 328, with a strip chart recorder
2. Astro Arc Welding Head  
A-1250-D, Serial No. 1389
3. Astro Arc Welding Head  
A-2500-D, Serial No. 1262
4. Four Channel Strip Chart Recorder  
Texas Instrument  
Serial No. FL04W60-171666

This equipment had been used during the welding of valve box tubing and had been checked out and calibrated.

### MATERIALS

The following materials were used in testing:

1. Tubing, AISI, Type 304, Sizes: 1/4 inch x .035  
3/4 inch x .109, 1 1/2 inch x .049
2. Fittings, AISI, Type 316, 304, consisting of  
Parker-Hannifin Unions, 33 each size

### TECHNIQUES

The following describes the techniques used in testing:

1. Automatic Welding Process. The automatic welding process utilizes a power source connected by flexible cables to a welding head, which is clamped on the tube in a manner similar to a pair of tongs. The electrode of the welding head turns 360° around the tubing to make a butt weld. The welding process is gas tungsten, pulsed arc welding. No filler wire is fed into the weld puddle. The addition of filler metal to the weld puddle is accomplished by the use of a weld fitting that has an additional shoulder of metal machined integral with the fitting. The shoulder melts during the welding and provides sufficient additional metal to the weld. The fitting is provided with a raised ring that fits into a groove in the welding head and serves to guide the tungsten welding electrode around the tube and to maintain proper alignment during welding. A photograph of the machine, set up to weld tubing, is shown in Figure 1. A photograph of tubing specimens welded by the automatic process is shown in Figure 2. Closeup views are shown in Figures 3, 4, and 5.




Figure 1. Machine Set Up to Weld Tubing

ORIGINAL PAGE IS  
OF POOR QUALITY




Figure 2. Tubing Specimens in 1/4, 3/4, and 1 1/2 Inch Sizes, Welded by the Automatic Process






Figure 3. Close-up View of the Weld in 1/4 Inch Size Tubing

ORIGINAL PAGE IS  
OF POOR QUALITY




Figure 4. Close up View of the Weld in 3/4 Inch Size Tubing





Figure 5. Close-Up View of the Weld in 1 1/2 Inch Size Tubing

2. **Parameters Tested.** As a first step, the optimum parameters (machine settings) were established by adopting the automatic welding procedures previously stated as being qualified for this equipment. These procedures were used by certified welding operators as a baseline during testing. The automatic procedures qualified as optimum and the welding operators certified for the three tube sizes (1/4, 3/4, 1 1/2 inch) are shown in the Appendix. During testing, the parameters varied were amperage, RPM, and shielding gas flow. One parameter at a time was varied, and the other parameters were maintained constant at their optimum values. Each parameter was varied in a manner that established threshold or borderline conditions. Threshold conditions were determined by weld quality based upon the point at which defects began to appear in x-rays during radiographic inspection of the welds.
3. **Radiographic Inspection.** All welds during the investigation were inspected 100 percent by radiography to obtain the data used to establish process control ranges and threshold conditions. In addition, a visual inspection was made of each weld. The visual inspection included the use of a borescope for the inside diameter (ID) inspection of 1/4 inch size tubing. Defects observed at threshold conditions are recorded under Inspection Results in Tables 3.1 through 3.18. The defects recorded include lack of penetration (LOP), concavity, and drop-through.
4. **Strip Chart Recordings.** Strip chart recordings were made of welds to determine if this method could be used to identify good quality welds vs bad quality welds. A typical strip chart recording is shown in Figure 6.
5. **Test Runs.** The test was divided into three phases, with each phase corresponding to a specific tube size. The effects of increasing and decreasing the three parameters, amperage, RPM, and shielding gas flow, were investigated. The ranges of acceptable parameters were determined by varying the individual parameters in increments of 5 percent, until the threshold values were found by correlation with the results of the radiographic and visual inspections. One parameter at a time was varied, with the remaining two being maintained constant at optimum settings. When a reject first occurred, due to defects appearing in the x-ray, a repeat run was performed at the parameter deviation just preceding the setting where the reject occurred. This was done to verify each threshold value. One type of defect prominently noted was concavity. The data sheets for individual test runs are included as an Appendix. Visual inspection results are separate from x-ray results.

ORIGINAL PAGE IS  
OF POOR QUALITY




Figure 6. Typical Strip Chart Recording



## TEST RESULTS

Individual test results are reported in the following tables:

### Phase I

Table 3.1 - Increasing Amperage Tests

Tube size 1/4" x .035

Using the optimum amperage as a baseline:

<u>RUN NO.</u>	<u>AMPERAGE DEVIATION</u>	<u>INSPECTION RESULTS</u>
1	Plus 5 percent	Satisfactory
2*	Plus 10 percent	Satisfactory
3	Plus 15 percent	Reject, LOP
4	Plus 10 percent	Satisfactory

\*Threshold Value, 10 percent.

TABLE 3.2 - Decreasing Amperage Tests

Tube size 1/4" x .035

Using the optimum amperage as a baseline:

<u>RUN NO.</u>	<u>AMPERAGE DEVIATION</u>	<u>INSPECTION RESULTS</u>
1	Minus 5 percent	Satisfactory
2	Minus 10 percent	Satisfactory
3*	Minus 15 percent	Satisfactory
4	Minus 20 percent	Reject, LOP
5	Minus 15 percent	Satisfactory

\*Threshold Value, 15 percent.

**Table 3.3 - Increasing RPM Tests**

Tube size 1/4" x .035

Using the optimum RPM as a baseline:

<u>RUN NO.</u>	<u>AMPERAGE DEVIATION</u>	<u>INSPECTION RESULTS</u>
1	Plus 5 percent	Satisfactory
2	Plus 10 percent	Satisfactory
3	Plus 15 percent	Satisfactory
4	Plus 20 percent	Satisfactory
5*	Plus 25 percent	Satisfactory
6	Plus 30 percent	Reject, LOP
7	Plus 25 percent	Satisfactory

\*Threshold Value, 10 percent.

**Table 3.4 - Decreasing RPM Tests**

Tube size 1/4" x .035

Using the optimum RPM as a baseline:

<u>RUN NO.</u>	<u>RPM DEIVATION</u>	<u>INSPECTION RESULTS</u>
1	Minus 5 percent	Satisfactory
2*	Minus 10 percent	Satisfactory
3	Minus 15 percent	Reject, LOP
4	Minus 10 percent	Satisfactory

\*Threshole Value, 10 percent.

**Table 3.5 - Increasing Shielding Gas Tests**

Tube size 1/4" x .035

Using the optimum shielding gas flow as a baseline:

<u>RUN NO.</u>	<u>GAS DEVIATION</u>	<u>INSPECTION RESULTS</u>
1	Plus 5 percent	Satisfactory
2	Plus 10 percent	Satisfactory
3	Plus 15 percent	Satisfactory
4	Plus 20 percent	Satisfactory
5	Plus 25 percent	Satisfactory
6*	Plus 30 percent	Satisfactory
7	Plus 35 percent	Reject, LOP
8	Plus 30 percent	Satisfactory

\*Threshold Value, 30 percent.

**Table 3.6 - Decreasing Shielding Gas Tests**

Tube size 1/4" x .035

Using the optimum shielding gas flow as a baseline:

<u>RUN NO.</u>	<u>GAS DEVIATION</u>	<u>INSPECTION RESULTS</u>
1	Minus 5 percent	Satisfactory
2	Minus 10 percent	Satisfactory
3	Minus 25 percent	Satisfactory
4*	Minus 30 percent	Satisfactory
5	Minus 40 percent	Reject, LOP

\*Threshold Value, 30 percent.

## Phase II

**Table 3.7 - Increasing Amperage Tests**

Tube size 3/4" x .109

Using the optimum amperage as a baseline:

<u>RUN NO.</u>	<u>AMPERAGE DEVIATION</u>	<u>INSPECTION RESULTS</u>
1	Plus 5 percent	Satisfactory
2*	Plus 10 percent	Satisfactory
3	Plus 5 percent	Satisfactory

\*Threshold Value, 10 percent.

All three test runs produced satisfactory x-rays. However, visual inspection revealed a borderline condition in each run, consisting of some concavity associated with greater than normal drop-through at the inside diameter (ID) of the tube. This heavier walled tube was found to be very sensitive to changes in amperage.

**Table 3.8 - Decreasing Amperage Tests**

Tube size 3/4" x .109

Using the optimum amperage as a baseline:

<u>RUN NO.</u>	<u>AMPERAGE DEVIATION</u>	<u>INSPECTION RESULTS</u>
1	Minus 5 percent	Satisfactory
2*	Minus 10 percent	Satisfactory
3	Minus 15 percent	Reject, LOP
4	Minus 10 percent	Satisfactory

\*Threshold Value, 10 percent.

**Table 3.9 - Increasing RPM Tests**

Tube size 3/4 " x .109

Using the optimum RPM as a baseline:

<u>RUN NO.</u>	<u>RPM DEVIATION</u>	<u>INSPECTION RESULTS</u>
1	Plus 5 percent	Satisfactory
2	Plus 10 percent	Satisfactory
3	Plus 15 percent	Satisfactory
4	Plus 20 percent	Satisfactory
5	Plus 25 percent	Satisfactory
6	Plus 30 percent	Satisfactory
7*	Plus 35 percent	Satisfactory
8	Plus 40 percent	Reject, LOP
9	Plus 35 percent	Satisfactory

\*Threshold Value, 35 percent.

**Table 3.10 - Decreasing RPM Tests**

Tube size 3/4" x .109

Using the optimum RPM as a baseline:

<u>RUN NO.</u>	<u>RPM DEVIATION</u>	<u>INSPECTION RESULTS</u>
1*	Minus 5 percent	Satisfactory
2	Minus 10 percent	Reject, LOP
3	Minus 3 percent	Satisfactory

\*Threshold Value, 5 percent.

In comparing this narrow range with the wide range in the Increasing RPM Tests results, it becomes apparent that the optimum RPM value should be somewhat higher than the value selected. Since the total range of +35 percent and -5 percent is 40 percent, a more meaningful evaluation is a range of +20 percent and -20 percent.

**Table 3.11 - Increasing Shielding Gas Tests**

Tube size 3/4" x .109

Using the optimum shielding gas flow as a base-line:

<u>RUN NO.</u>	<u>GAS DEVIATION</u>	<u>INSPECTION RESULTS</u>
1	Plus 5 percent	Satisfactory
2	Plus 10 percent	Satisfactory
3*	Plus 15 percent	Satisfactory
4	Plus 20 percent	Reject, Concavity

\*Threshold Value, 15 percent.

**Table 3.12 - Decreasing Shielding Gas Tests**

Tube size 3/4" x .109

Using the optimum shielding gas flow as a base-line:

<u>RUN NO</u>	<u>GAS DEVIATION</u>	<u>INSPECTION RESULTS</u>
1	Minus 5 percent	Satisfactory
2*	Minus 10 percent	Satisfactory

\*Threshold Value, 10 percent.

The narrow range indicates that these parameters should be adjusted to a slight modification of the optimum value.

### Phase III

**Table 3.13 - Increasing Amperage Tests**

Tube size 1 1/2" x .049

Using the optimum amperage as a baseline:

<u>RUN NO.</u>	<u>AMPERAGE DEVIATION</u>	<u>INSPECTION RESULTS</u>
1	Plus 5 percent	Satisfactory
2	Plus 10 percent	Satisfactory
3	Plus 15 percent	Satisfactory
4	Plus 20 percent	Satisfactory
5*	Plus 25 percent	Satisfactory
6	Plus 30 percent	Reject, Concavity
7	Plus 25 percent	Satisfactory

\*Threshold Value, 25 percent.

**Table 3.14 - Decreasing Amperage Tests**

Tube size 1 1/2" x .049

Using the optimum amperage as a baseline:

<u>RUN NO.</u>	<u>AMPERAGE DEVIATION</u>	<u>INSPECTION RESULTS</u>
1	Minus 5 percent	Satisfactory
2	Minus 10 percent	Satisfactory
3*	Minus 15 percent	Satisfactory
4	Minus 20 percent	Reject, LOP
5	Minus 15 percent	Satisfactory

\*Threshold Value, 15 percent.

**Table 3.15 - Increasing RPM Tests**

Tube size 1 1/2" x .049

Using the optimum RPM as a baseline:

<u>RUN NO.</u>	<u>RPM DEVIATION</u>	<u>INSPECTION RESULTS</u>
1	Plus 5 percent	Satisfactory
2	Plus 10 percent	Satisfactory
3	Plus 15 percent	Satisfactory
4*	Plus 20 percent	Satisfactory
5	Plus 25 percent	Reject, LOP
6	Plus 20 percent	Satisfactory

\*Threshold Value, 20 percent.

**Table 3.16 - Decreasing RPM Tests**

Tube size 1 1/2" x .049

Using the optimum RPM as a baseline:

<u>RUN NO.</u>	<u>RPM DEVIATION</u>	<u>INSPECTION RESULTS</u>
1	Minus 5 percent	Satisfactory
2*	Minus 10 percent	Satisfactory
3	Minus 15 percent	Reject, LOP
4	Minus 10 percent	Satisfactory

\*Threshold Value, 10 percent.



**Table 3.17 - Increasing Shielding Gas Tests**

Tube size 1 1/2" x .049

Using the optimum shielding gas flow as a base-line:

<u>RUN NO.</u>	<u>GAS DEVIATION</u>	<u>INSPECTION RESULTS</u>
1	Plus 5 percent	Satisfactory
2	Plus 10 percent	Satisfactory
3	Plus 20 percent	Satisfactory
4	Plus 30 percent	Satisfactory
5	Plus 40 percent	Satisfactory

The results indicate an insensitivity to this parameter.

**Table 3.18 - Decreasing Shielding Gas Tests**

Tube size 1 1/2" x .049

Using the optimum shielding gas flow as a base-line:

<u>RUN NO.</u>	<u>GAS DEVIATION</u>	<u>INSPECTION RESULTS</u>
1	Minus 5 percent	Satisfactory
2	Minus 10 percent	Satisfactory
3	Minus 15 percent	Satisfactory
4	Minus 30 percent	Satisfactory
5	Minus 50 percent	Reject, oxidized.

At 50 percent of the optimum gas flow rate, the specimen oxidized.

## SUMMARY OF RESULTS

It was found that the following ranges of process variables from optimum produced good quality welds as determined by the radiographic inspection. Any greater deviation resulted in defective welds.

### Tube size 1/4" x .035

#### Amperage Deviation

Increasing . . . . . 10 percent

Decreasing . . . . . 15 percent

#### RPM Deviation

Increasing . . . . . 25 percent

Decreasing . . . . . 10 percent

#### Shielding Gas Flow Deviation

Increasing . . . . . 30 percent

Decreasing . . . . . 30 percent

### Tube size 3/4" x .109

#### Amperage Deviation

Increasing . . . . . 10 percent

Decreasing . . . . . 10 percent

#### RPM Deviation

Increasing . . . . . 20 percent

Decreasing . . . . . 20 percent

#### Shielding Gas Flow Deviation

Increasing . . . . . 15 percent

Decreasing . . . . . 10 percent

### Tube size 1 1/2" x .049

#### Amperage Deviation

Increasing . . . . . 25 percent

Decreasing . . . . . 15 percent

### RPM Deviation

Increasing . . . . . 20 percent

Decreasing . . . . . 10 percent

### Shielding Gas Flow Deviation

Increasing . . . . . 40 + percent

Decreasing . . . . . 30 + percent

The results obtained using the strip chart recordings revealed that this method of recording is not reliable for identifying good quality welds vs bad quality welds. All welding data sheets are included in the Appendix.

## CONCLUSION

The results of the testing show that when the optimum welding parameters are established by qualifying the welding procedures for specific sizes of tubing, and when welding machine operators are certified, then the automatic tube welding process repeatedly produces good quality welds with a high degree of reliability. Quality of the welds was determined by both radiographic and visual inspections. It was found that the welding parameters could be varied over a considerable range without jeopardizing the weld quality, although this is not a recommended practice. The correlation between the results of the radiographic and visual inspections was good. When the weld passed the visual inspection, there was a high probability that it would pass the radiographic inspection.

The reliability of the automatic tube welding process has been verified by its performance in the recent production welding of tube assemblies for the hypergolics ground support equipment for the Space Shuttle. Approximately 5000 welds were made using the automatic tube welding process at the Kennedy Space Center, and several thousand were made at Michoud in stainless steel tubing, in sizes ranging from 1/4 inch to 2 inch diameters. In both projects, the weld quality was found to be high, requiring very little repair welding. It is estimated that 3 percent of these production welds required minor repairs during their fabrication. This high degree of reliability and low rejection rate is attributed to the close control provided by the automatic process, minimizing human error.

In view of the consistently high quality of the welds reproduced by the automatic tube welding process, both in testing and in production welding, it is concluded that the 100 percent radiographic inspection requirement can be removed when tubing is welded by the automatic process. Good quality welds result when the automatic process parameters are controlled at optimum values. When this control is supplemented by weld visual inspection, good quality welds are assured.

## IMPLEMENTATION

Based on the findings of this investigation, the following procedures will be implemented in Kennedy Space Center specifications for welding tubing when the automatic process is used:

1. The Astro Arc Pulsed Gas Tungsten Arc Welding Process or equal will be used with butt weld tube fittings.
2. During the qualification of the welding procedures and the certification of welding operators, the 100 percent radiographic inspection requirement will remain in effect. The contractor will verify that satisfactory radiographic inspections are attained. During this period, the optimum welding parameters will be determined. The contractor will verify the optimum welding parameters in a qualified welding procedure and certify welding operators, based upon both radiographic and visual inspections.
3. During the production welding phase, after qualification and certification, the radiographic inspection will be eliminated. It will be replaced by a rigid control of process parameters, augmented by 100 percent visual inspection. The control of process parameters and the results of the visual inspection will become part of the inspection record, signed by the contractor. The data to be recorded is as follows:
  - a. Weld Number: To be recorded on the data sheet and etched on the tube adjacent to the weld.
  - b. Welder's Name and Certification Verification
  - c. Date of Welding
  - d. Government Specification Number
  - e. Contractor's Procedure Number
  - f. Contract or Project Number
  - g. Tube Material and Size
  - h. Welding Position
  - i. Machine Settings
    - (1) Arc Amperes (Weld Levels I, II, III, and IV)
    - (2) Time (Levels I, II, III, and IV)
    - (3) Pulse Low (Amperes)
    - (4) Pulse High (Time)

- (5) Pulse Low (Time)
- (6) Finish Slope
- (7) Rotation Delay
- (8) Head Speed, RPM
- (9) Shielding and Backup Gas Flow, CFH
- (10) Arc Voltage
- (11) Tungsten Electrode (Length, Bevel, Land, Arc Gap)
- (12) Machine Used (Equipment, Manufacturer, Serial Number)
- (13) Fitting Type and Manufacturer

**Note:** During the welding process, every effort must be made to maintain the machine settings (item i) at their optimum values. If more than one parameter varies measurably, from optimum, the weld shall be rejected. In the case where only one parameter varies not more than 5 percent the weld shall be acceptable.

- j. Inspection Report Number
  - k. Inspection's Signed Verification: Optimum settings maintained as specified in item i.
  - l. Weld Visual Inspection Results
  - m. Approvals or Rejections: Quality/Contractor Signatures, Government Inspector Approval or Rejection Stamp.
4. The following steps shall be performed during the automatic welding process:
- a. Turn gas on slowly at tank for torch and backup gas. Check for adequate tank pressure. Check for correct gas and gas flow per weld schedule by depressing gas flow button. Gas must be turned off at tank at the end of work shift. Seal backup gas tube to flow over inside diameter (ID) of weld joint.
  - b. Attach ground cable to tube when using A3500 head. A ground cable is not required with A2500 head.
  - c. Check for proper tungsten electrode grinding and gap on fitting. Regrind electrode if contaminated or if shape of point has changed. Point of electrode must be positioned in exact center of fitting lip.
  - d. Make sure that tube end is cut square and is free from burrs on outside and inside edges and that there is no gap when tube and fittings are clamped in weld head. Clean joint surfaces of finger prints with freon and lense cleaner tissue.

- e. Always start weld with gear teeth in housing to prevent arcing from gear ring. This applies to the A2500 weld head. Arc may be struck in any position with the A3500 head.
  - f. Check each item on weld schedule for proper control panel settings.
  - g. Check the following:
    - (1) Gear rotation switch is in forward position
    - (2) RPM setting is correct
    - (3) Panel and arc starter switches are on
    - (4) Pulse-step pulse switch is in correct position
    - (5) Arc voltage switch is on (A3500 head only)
  - h. Depress sequence start button and observe root drop-through when possible. Slight amp adjustment (within  $\pm 5$  percent) may be made during welding to assure uniformity. Time may be added to Level IV to provide overlap if weld start did not give full penetration. These adjustments are not to be considered as variations from optimum.
5. The visual inspection shall be a 100 percent coverage for each weld, including the weld root when it is accessible for viewing. When weld roots are inaccessible for viewing, then the record of process controls will govern acceptance or rejection of the weld root. Any of the following defects shall be unacceptable:
- a. Cracks
  - b. Porosity open to the surface
  - c. Concavity
6. KSC-SPEC-Z-0016, "Automatic Welding, Stainless Steel Pipe and Tubing, Invar 36 Pipe, Carbon Steel Pipe, Aluminum Pipe, Specification for" (revised to include items 1 through 5 above for tubing) will govern the application of the automatic tube welding process with implementation assuring good quality tube welds at reduced cost.

## **APPENDIX**

### **Qualification and Certification and Data Sheets**



# QUALIFICATION AND CERTIFICATION

ORIGINAL PAGE IS  
OF POOR QUALITY

## AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

WELDS Q-Q & R-R

IDP #23

WPS No. 404

MPP NUMBER	MPP-LO-0001	REVISION LETTER		PAGE	14 of 14
------------	-------------	-----------------	--	------	----------

SPECIFICATION NO. REVISION. DATE 7/7/77 OUT OF STA-028

BACK-UP	PURGE GAS	HEAD	TUBE DATA
INTERNAL GAS ARG	HEAD GAS ARG	O.D. .250	
FLOW CFH 5+2	FLOW CFH 15+5	WALL .035	
PRE-PURGE TIME 2 MIN(MIN)	PRE-PURGE TIME 15 SEC(MIN)	ALLOY 304 L	
POST-PURGE TIME 1 MIN(MIN)	POST-PURGE TIME 1 MIN(MIN)	FTG. P/N 79K80246-1	
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.			

### PROGRAMMER SETTINGS

WELD LEVEL I 5 to 199 Amps	WELD LEVEL II 5 to 199 Amps	WELD LEVEL III 5 to 199 Amps	WELD LEVEL IV 5 to 199 Amps	PULSE LOW 5 to 199 Amps
025	023	021	018	010
LEVEL I Time 1-299 Sec	LEVEL II Time 1-299 Sec	LEVEL III Time 1-299 Sec	LEVEL IV Time 1-299 Sec	FINISH SLOPE .1 to 9.9 Sec
007	005	005	009	4.0
	PULSE HIGH .1 to 9.9 Sec	PULSE LOW .1 to 9.9 Sec	ROTATION DELAY .1 to 9.9 Sec	HEAD SPEED RPM
	0.1	0.1	0.9	3.60

### QUALIFICATION POSITIONS

☒ HORIZONTAL ☒ VERTICAL

MACHINE E-200T4 S/N 328  
HEAD S/N 1328

	ELECTRODE (Sketch)
	A 80°
	B .015
	C 1.329
	D .030

WELDERS NAME TOOLEY STAMP

RADIOGRAPH ACCEPTANCE 22 JUL 12 1977

TENSILE TEST ACCEPTANCE ANN 562

REPORT NUMBER MTB-129-77

### APPROVALS:

MFG. D/821 [Signature] DATE 7/12/77

Q.E. D/814 [Signature] DATE 7-12-77





ENGR. D/836 [Signature] DATE 7/18/77

QUALITY CONTROL ANN 562 DATE JUL 12 1977

# QUALIFICATION AND CERTIFICATION

## AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)


WPS No. 1208

MPP NUMBER <b>MPP-LO-0001</b>		REVISION LETTER		PAGE <b>14 of 14</b>	
SPECIFICATION NO. REVISION. DATE					
BACK-UP		PURGE GAS		HEAD	
INTERNAL GAS <u>ARG</u>		HEAD GAS <u>ARG</u>		O.D. <u>.750</u>	
FLOW CFH <u>5+2</u>		FLOW CFH <u>15+5</u>		WALL <u>.109</u>	
PRE-PURGE TIME <u>2 MIN(MIN)</u> (1)		PRE-PURGE TIME <u>15 SEC(MIN)</u>		ALLOY <u>304</u>	
POST-PURGE TIME <u>1 MIN(MIN)</u>		POST-PURGE TIME <u>1 MIN(MIN)</u>		FTG. P/N <u>12-18-YHY</u>	
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.					
PROGRAMMER SETTINGS					
WELD LEVEL I 5 to 199 Amps	WELD LEVEL II 5 to 199 Amps	WELD LEVEL III 5 to 199 Amps	WELD LEVEL IV 5 to 199 Amps	PULSE LOW 5 to 199 Amps	
<u>074</u>	<u>073</u>	<u>073</u>	<u>072</u>	<u>042</u>	
LEVEL I Time 1-299 Sec	LEVEL II Time 1-299 Sec	LEVEL III Time 1-299 Sec	LEVEL IV Time 1-299 Sec	FINISH SLOPE .1 to 9.9 Sec	
<u>018</u>	<u>017</u>	<u>016</u>	<u>017</u>	<u>9.9</u>	
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec	
<u>0.2</u>		<u>0.1</u>		<u>3.6</u>	
				HEAD SPEED RPM <u>1.00</u>	
QUALIFICATION POSITIONS					
<input type="checkbox"/> HORIZONTAL NNNN		<input type="checkbox"/> VERTICAL MMMM			
MACHINE E-200T4 S/N <u>328</u>		HEAD S/N <u>1328</u>			
		ELECTRODE (Sketch)			
		A <u>80°</u>			
		B <u>.010</u>			
		C <u>1.073</u>			
		D <u>.020</u>			
WELDERS NAME <u>Tooley JT</u> STAMP					
RADIOGRAPH ACCEPTANCE 					
TENSILE TEST ACCEPTANCE 					
REPORT NUMBER <u>MTR-218-77</u>					
APPROVALS:					
MFG. D/821 <u>C.H. Adams</u>		DATE <u>10-14-77</u>			
Q.E. D/811 <u>J.H. Barber</u>		DATE <u>10/14/77</u>			
ENGR. D/839 <u>D.J. Jacke</u>		DATE <u>10/17/77</u>			
QUALITY CONTROL 		DATE <u>OCT 17 1977</u>			

# QUALIFICATION AND CERTIFICATION

ORIGINAL PAGE IS  
OF POOR QUALITY

## AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

WELD #CC & DD		IPD #16		WPS No. 2402	
MPP NUMBER MPP-LO-0001		REVISION LETTER			
		PAGE 14 of 14			
SPECIFICATION NO. REVISION. DATE					
BACK-UP		PURGE GAS		HEAD	
INTERNAL GAS ARG		HEAD GAS ARG		O.D. 1.50	
FLOW CFH 5+2		FLOW CFH 15+5		WALL .049	
PRE-PURGE TIME 2 MIN(MIN)		PRE-PURGE TIME 15 SEC(MIN)		ALLOY 304 L	
POST-PURGE TIME 1 MIN(MIN)		POST-PURGE TIME 1 MIN(MIN)		FTG. P/N 740021-2.049	
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.					
PROGRAMMER SETTINGS					
WELD LEVEL I 5 to 199 Amps	WELD LEVEL II 5 to 199 Amps	WELD LEVEL III 5 to 199 Amps	WELD LEVEL IV 5 to 199 Amps	PULSE LOW 5 to 199 Amps	
093	092	089	087	038	
LEVEL I Time 1-299 Sec	LEVEL II Time 1-299 Sec	LEVEL III Time 1-299 Sec	LEVEL IV Time 1-299 Sec	FINISH SLOPE .1 to 9.9 Sec	
009	012	009	010	9.9	
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec	
0.1		0.1		1.0	
				HEAD SPEED RPM	
				1.60	
QUALIFICATION POSITIONS					
<input checked="" type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL					
MACHINE E-200T4 S/N 328					
HEAD S/N 1262					
		ELECTRODE (Sketch) A 80° B .015 C 1.259 D .030			
WELDERS NAME <u>Tam Hughes</u> STAMP					
RADIOGRAPH ACCEPTANCE <u>5/4/77</u>					
TENSILE TEST ACCEPTANCE <u>5/6/77</u>					
REPORT NUMBER <u>MTB-063-77</u>					
APPROVALS:					
MFG. D/821 <u>Ed Wang</u> DATE <u>5-4-77</u>					
Q.E. D/814 <u>Ed Wang</u> DATE <u>5-4-77</u>					
ENGR. D/830 <u>Ed Wang</u> DATE <u>5-6-77</u>					
QUALITY CONTROL <u>ANN 503</u> DATE <u>5/6/77</u>					

# AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

MPP NUMBER <b>MPP-L0-0001</b>	REVISION LETTER <table border="1" style="width:100%; height: 20px;"> <tr> <td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> </table>																	PAGE <b>14 of 14</b>

SPECIFICATION NO.	REVISION.	DATE
		<b>TPS A/A 328-001 Sample #38 +5%</b>

BACK-UP	PURGE GAS	X-Ray Results: Accept
INTERNAL GAS <u>ARG</u>	HEAD GAS <u>ARG</u>	O.D. <u>0.250</u>
FLOW CFH <u>5+2</u>	FLOW CFH <u>15+5</u>	WALL <u>0.035</u>
PRE-PURGE TIME <u>2 MIN(MIN)</u> (1) PRE-PURGE TIME <u>15 SEC(MIN)</u> ALLOY _____		
POST-PURGE TIME <u>1 MIN(MIN)</u> POST-PURGE TIME <u>1 MIN(MIN)</u> FTG. P/W _____		
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.		


  

PROGRAMMER SETTINGS				
WELD LEVEL I 5 to 199 Amps	WELD LEVEL II 5 to 199 Amps	WELD LEVEL III 5 to 199 Amps	WELD LEVEL IV 5 to 199 Amps	PULSE LOW 5 to 199 Amps
026	024	022	019	010
LEVEL I Time 1-299 Sec	LEVEL II Time 1-299 Sec	LEVEL III Time 1-299 Sec	LEVEL IV Time 1-299 Sec	FINISH SLOPE .1 to 9.9 Sec
007	005	005	009	4.0
	PULSE HIGH .1 to 9.9 Sec	PULSE LOW .1 to 9.9 Sec	ROTATION DELAY .1 to 9.9 Sec	HEAD SPEED RPM
	0.1	0.1	0.9	3.60

QUALIFICATION POSITIONS	
<input type="checkbox"/> HORIZONTAL	<input checked="" type="checkbox"/> VERTICAL
MACHINE E-200T4 S/N <u>328</u>	
HEAD S/N <u>1328</u>	



ELECTRODE (Sketch)	
A	<u>080°</u>
B	<u>.015</u>
C	<u>1.329</u>
D	<u>.030</u>

WELDERS NAME _____	STAMP _____
RADIOGRAPH ACCEPTANCE _____	
TENSILE TEST ACCEPTANCE _____	
REPORT NUMBER _____	
APPROVALS:	
MFG. D/821 _____	DATE _____
Q.E. D/814 _____	DATE _____
ENGR. D/830 _____	DATE _____
QUALITY CONTROL _____	DATE _____
STAMP	

VISUAL ACCEPT

DATA SHEET  
1/4" Increasing Amps

ORIGINAL PAGE IS  
OF POOR QUALITY

AUTOMATIC BUTTWELD  
WELDING PROCEDURE SPECIFICATION (WPS)

WPS No.

MPP NUMBER <b>MPP-LO-0001</b>		REVISION LETTER								PAGE 14 of 14	
SPECIFICATION NO. REVISION.		DATE <b>TPS A/A-328-001</b> Sample #39 + 10%									
BACK-UP		PURGE GAS		X-Ray Results: Accept				TUBE DATA			
INTERNAL GAS ARG		HEAD GAS ARG		O.D.		.250					
FLOW CFH 5+2		FLOW CFH 15+5		WALL		.035					
PRE-PURGE TIME 2 MIN(MIN)		(1) PRE-PURGE TIME 15 SEC(MIN)		ALLOY							
POST-PURGE TIME 1 MIN(MIN)		POST-PURGE TIME 1 MIN(MIN)		FTG. P/N							
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.											
PROGRAMMER SETTINGS											
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps		PULSE LOW 5 to 199 Amps			
028		025		023		020		010			
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec		FINISH SLOPE .1 to 9.9 Sec			
007		005		005		009		4.0			
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM					
0.1		0.1		0.9		3.60					
<div style="display: flex; justify-content: space-between;"> <div> <p>QUALIFICATION POSITIONS</p> <p><input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL</p> <p>MACHINE E-200T4 S/N 328</p> <p>HEAD S/N 1328</p> </div> <div> <p>WELDERS NAME _____ STAMP _____</p> <p>RADIOGRAPH ACCEPTANCE _____</p> <p>TENSILE TEST ACCEPTANCE _____</p> <p>REPORT NUMBER _____</p> <p>APPROVALS:</p> <p>MFG. D/821 _____ DATE _____</p> <p>Q.E. D/814 _____ DATE _____</p> <p>ENGR. D/830 _____ DATE _____</p> <p>QUALITY CONTROL _____ DATE _____</p> <p>STAMP</p> <p>VISUAL ACCEPT</p> </div> </div>											
		<p>ELECTRODE (Sketch)</p> <p>A 80°</p> <p>B .015</p> <p>C 1.329</p> <p>D .030</p>									

**AUTOMATIC BUTTWELD  
WELDING PROCEDURE SPECIFICATION (WPS)**


32

DATA SHEET  
1/4" Increasing Amps

ORIGINAL PAGE IS  
OF POOR QUALITY


AUTOMATIC BUTTWELD  
WELDING PROCEDURE SPECIFICATION (WPS)

WPS No.

MPP NUMBER MPP-10-0001	REVISION LETTER	PAGE 14 of 14
SPECIFICATION NO. REVISION. DATE TPS A/A 328-001 Sample #41 +15%-2 amps		
X-Ray Results: Accept		
BACK-UP	PURGE GAS	HEAD
INTERNAL GAS ARG	HEAD GAS ARG	TUBE DATA
FLOW CFH 5+2	FLOW CFH 15+5	O.D. .250
PRE-PURGE TIME 2 MIN(MIN)(1)	PRE-PURGE TIME 15 SEC(MIN)	WALL .035
POST-PURGE TIME 1 MIN(MIN)	POST-PURGE TIME 1 MIN(MIN)	ALLOY
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.		
PROGRAMMER SETTINGS		
WELD LEVEL I 5 to 199 Amps	WELD LEVEL II 5 to 199 Amps	WELD LEVEL III 5 to 199 Amps
027	025	023
WELD LEVEL IV 5 to 199 Amps	PULSE LOW 5 to 199 Amps	
019	010	
LEVEL I Time 1-299 Sec	LEVEL II Time 1-299 Sec	LEVEL III Time 1-299 Sec
007	005	005
LEVEL IV Time 1-299 Sec	FINISH SLOPE .1 to 9.9 Sec	
009	4.0	
PULSE HIGH .1 to 9.9 Sec	PULSE LOW .1 to 9.9 Sec	ROTATION DELAY .1 to 9.9 Sec
0.1	0.1	0.9
HEAD SPEED RPM		
3.60		
QUALIFICATION POSITIONS		
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL		
MACHINE E-200T4 S/N 328		
HEAD S/N 1328		
WELDERS NAME _____ STAMP _____		
RADIOGRAPH ACCEPTANCE _____		
TENSILE TEST ACCEPTANCE _____		
REPORT NUMBER _____		
APPROVALS:		
MFG. D/821 _____ DATE _____		
Q.E. D/814 _____ DATE _____		
ENGR. D/830 _____ DATE _____		
QUALITY CONTROL _____ DATE _____		
STAMP		
		
ELECTRODE (Sketch)		
A 80°		
B .015		
C 1.329		
D .030		

# DATA SHEET 1/4" Increasing Amps

## AUTOMATIC BUTT WELD WELDING PROCEDURE SPECIFICATION (WPS)

WPS No.	
MPP NUMBER MPP-L0-0001	REVISION LETTER <div style="display: flex; justify-content: space-between;"> <div style="width: 100px; height: 15px; border: 1px solid black;"></div> <div style="width: 100px; height: 15px; border: 1px solid black;"></div> <div style="width: 100px; height: 15px; border: 1px solid black;"></div> <div style="width: 100px; height: 15px; border: 1px solid black;"></div> <div style="width: 100px; height: 15px; border: 1px solid black;"></div> <div style="width: 100px; height: 15px; border: 1px solid black;"></div> <div style="width: 100px; height: 15px; border: 1px solid black;"></div> <div style="width: 100px; height: 15px; border: 1px solid black;"></div> </div>
PAGE 14 of 14	
SPECIFICATION NO. REVISION. DATE TSP A/A 328-001 Sample #72 -5%	
X-Ray Results: Accept	
PURGE GAS	HEAD
BACK-UP	TUBE DATA
INTERNAL GAS ARG	HEAD GAS ARG
FLOW CFH 5+2	FLOW CFH 15+5
	WALL .035
PRE-PURGE TIME 2 MIN(MIN)	PRE-PURGE TIME 15 SEC(MIN) ALLOY
POST-PURGE TIME 1 MIN(MIN)	POST-PURGE TIME 1 MIN(MIN) FTG. P/N
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.	
PROGRAMMER SETTINGS	
WELD LEVEL I 5 to 199 Amps	WELD LEVEL II 5 to 199 Amps
WELD LEVEL III 5 to 199 Amps	WELD LEVEL IV 5 to 199 Amps
PULSE LOW 5 to 199 Amps	
026	024
022	019
010	
LEVEL I Time 1-299 Sec	LEVEL II Time 1-299 Sec
LEVEL III Time 1-299 Sec	LEVEL IV Time 1-299 Sec
FINISH SLOPE .1 to 9.9 Sec	
007	005
005	009
4.0	
PULSE HIGH .1 to 9.9 Sec	PULSE LOW .1 to 9.9 Sec
ROTATION DELAY .1 to 9.9 Sec	HEAD SPEED RPM
0.1	0.1
0.9	3.60
QUALIFICATION POSITIONS <input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL	
MACHINE E-200T4 S/N 328 HEAD S/N 1328	
	ELECTRODE (Sketch) A 80° B .015 C 1.329 D .030
WELDERS NAME _____ STAMP _____ RADIOGRAPH ACCEPTANCE _____ TENSILE TEST ACCEPTANCE _____ REPORT NUMBER _____ APPROVALS: MFG. D/821 _____ DATE _____ Q.E. D/814 _____ DATE _____ ENGR. D/830 _____ DATE _____ QUALITY CONTROL _____ DATE _____ VISUAL ACCEPT _____ STAMP _____	

FORM 3016-S-1 REV. 5-73



DATA SHEET  
1/4" Decreasing Amps

ORIGINAL PAGE IS  
OF POOR QUALITY

AUTOMATIC BUTTWELD  
WELDING PROCEDURE SPECIFICATION (WPS)

MPP-LO-0001

WPS No.

MPP NUMBER	MPP-LO-0001	REVISION LETTER		PAGE	14 of 14
------------	-------------	-----------------	--	------	----------

SPECIFICATION NO. REVISION. DATE TPS A/A 328-001 Sample #17 -5%

X-Ray Results: OK

BACK-UP	PURGE GAS	HEAD	TUBE DATA
INTERNAL GAS ARG	HEAD GAS ARG	O.D.	0.250
FLOW CFH 5+2	FLOW CFH 15+5	WALL	0.035

PRE-PURGE TIME 2 MIN(MIN)(1) PRE-PURGE TIME 15 SEC(MIN) ALLOY

POST-PURGE TIME 1 MIN(MIN) POST-PURGE TIME 1 MIN(MIN) FTG. P/N  
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.


PROGRAMMER SETTINGS

WELD LEVEL I 5 to 199 Amps	WELD LEVEL II 5 to 199 Amps	WELD LEVEL III 5 to 199 Amps	WELD LEVEL IV 5 to 199 Amps	PULSE LOW 5 to 199 Amps
024	022	020	017	010
LEVEL I Time 1-299 Sec	LEVEL II Time 1-299 Sec	LEVEL III Time 1-299 Sec	LEVEL IV Time 1-299 Sec	FINISH SLOPE .1 to 9.9 Sec
007	005	005	009	4.0
	PULSE HIGH .1 to 9.9 Sec	PULSE LOW .1 to 9.9 Sec	ROTATION DELAY .1 to 9.9 Sec	HEAD SPEED RPM
	0.1	0.1	0.9	3.60

QUALIFICATION POSITIONS

☐ HORIZONTAL ☒ VERTICAL

MACHINE E-200T4 S/N 328  
HEAD S/N 1328



WELDERS NAME \_\_\_\_\_ STAMP \_\_\_\_\_

RADIOGRAPH ACCEPTANCE \_\_\_\_\_

TENSILE TEST ACCEPTANCE \_\_\_\_\_

REPORT NUMBER \_\_\_\_\_

APPROVALS:

MFG. D/821 \_\_\_\_\_ DATE \_\_\_\_\_

Q.E. D/814 \_\_\_\_\_ DATE \_\_\_\_\_

ENGR. D/830 \_\_\_\_\_ DATE \_\_\_\_\_

QUALITY CONTROL \_\_\_\_\_ DATE \_\_\_\_\_

STAMP


VISUAL ACCEPT

# DATA SHEET 1/4" Decreasing Amps

## AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

MPP-LO-0001

WPS No.

WPS NUMBER <b>MPP-LO-0001</b>		REVISION LETTER		PAGE <b>14 of 14</b>	
SPECIFICATION NO. <b>REVISION.</b>		DATE <b>TPS A/A 328-001</b> Sample #18 -10%			
BACK-UP		PURGE GAS		X-Ray Results: <b>Accept</b>	
INTERNAL GAS. <b>ARG</b>		HEAD		TUBE DATA	
FLOW CFH <b>5±2</b>		HEAD GAS <b>ARG</b>		O.D. <b>0.250</b>	
PRE-PURGE TIME <b>2 MIN(MIN)</b>		PRE-PURGE TIME <b>15 SEC(MIN)</b>		ALLOY <b></b>	
POST-PURGE TIME <b>1 MIN(MIN)</b>		POST-PURGE TIME <b>1 MIN(MIN)</b>		FTG. P/N <b></b>	
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.					
PROGRAMMER SETTINGS					
WELD LEVEL I 5 to 199 Amps	WELD LEVEL II 5 to 199 Amps	WELD LEVEL III 5 to 199 Amps	WELD LEVEL IV 5 to 199 Amps	PULSE LOW 5 to 199 Amps	
022	021	019	016	010	
LEVEL I Time 1-299 Sec	LEVEL II Time 1-299 Sec	LEVEL III Time 1-299 Sec	LEVEL IV Time 1-299 Sec	FINISH SLOPE .1 to 9.9 Sec	
007	005	005	009	4.0	
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec	
0.1		0.1		0.9	
				HEAD SPEED RPM	
				3.60	
QUALIFICATION POSITIONS					
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL					
MACHINE E-200T4 S/N <u>328</u> HEAD S/N <u>1328</u>					
		ELECTRODE (Sketch) A <u>080°</u> B <u>.015</u> C <u>1.329</u> D <u>.030</u>			
WELDERS NAME _____ STAMP _____ RADIOGRAPH ACCEPTANCE _____ TENSILE TEST ACCEPTANCE _____ REPORT NUMBER _____ APPROVALS: MFG. D/821 _____ DATE _____ Q.E. D/814 _____ DATE _____ ENGR. D/830 _____ DATE _____ QUALITY CONTROL _____ DATE _____ VISUAL ACCEPT _____ STAMP _____					

FORM MPP-1 REV 5-73


ORIGINAL PAGE IS  
OF POOR QUALITY

DATA SHEET  
1/4" Decreasing Amps

AUTOMATIC BUTTWELD  
WELDING PROCEDURE SPECIFICATION (WPS)

MPP-LO-0001

WPS No.

MPP NUMBER MPP-LO-0001		REVISION LETTER										PAGE 14 of 14	
SPECIFICATION NO. REVISION. DATE TPS A/A 328-001 Sample #19 -15%													
X-Ray Results: Accept													
BACK-UP		PURGE GAS		HEAD		TUBE DATA							
INTERNAL GAS ARG		HEAD GAS ARG		O.D.		0.250							
FLOW CFH 5+2		FLOW CFH 15+5		WALL		.035							
PRE-PURGE TIME 2 MIN(MIN)(1) PRE-PURGE TIME 15 SEC(MIN) ALLOY													
POST-PURGE TIME 1 MIN(MIN) POST-PURGE TIME 1 MIN(MIN) FTG. P/N													
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.													
PROGRAMMER SETTINGS													
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps		PULSE LOW 5 to 199 Amps					
021		020		018		015		010					
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec		FINISH SLOPE .1 to 9.9 Sec					
007		005		005		009		4.0					
		PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM					
		0.1		0.1		0.9		3.60					
QUALIFICATION POSITIONS													
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL													
MACHINE E-200T4 S/N 328													
HEAD S/N 1328													
		ELECTRODE (Sketch)											
		A 80°											
		B .015											
		C 1.329											
		D .030											
WELDERS NAME _____ STAMP _____													
RADIOGRAPH ACCEPTANCE _____													
TENSILE TEST ACCEPTANCE _____													
REPORT NUMBER _____													
APPROVALS:													
MFG. D/821 _____ DATE _____													
Q.E. D/814 _____ DATE _____													
ENGR. D/830 _____ DATE _____													
QUALITY CONTROL _____ DATE _____													
VISUAL ACCEPT _____ STAMP _____													

FORM 3016-S-1 REV. 8-73

# DATA SHEET


## 1/4" Decreasing Amps

### AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

MPP-L0-0001

WPS No.

MPP NUMBER MPP-L0-0001		REVISION LETTER								PAGE 14 of 14
SPECIFICATION NO.		REVISION.		DATE		TPS A/A 328-001 Sample #20 -20%				
BACK-UP		PURGE GAS		X-Ray Results: Rej. Lop			TUBE DATA			
INTERNAL GAS ARG		HEAD GAS ARG		O.D.			0.250			
FLOW CFH 5+2		FLOW CFH 15+5		WALL			.035			
PRE-PURGE TIME 2 MIN(MIN)		(1) PRE-PURGE TIME 15 SEC(MIN)		ALLOY						
POST-PURGE TIME 1 MIN(MIN)		POST-PURGE TIME 1 MIN(MIN)		FTG. P/H						
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.										
PROGRAMMER SETTINGS										
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps		PULSE LOW 5 to 199 Amps		
020		013		017		014		010		
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec		FINISH SLOPE .1 to 9.9 Sec		
007		005		005		009		4.0		
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM				
0.1		0.1		0.9		3.60				
QUALIFICATION POSITIONS										
<input type="checkbox"/> HORIZONTAL		<input checked="" type="checkbox"/> VERTICAL								
MACHINE E-200T4 S/N 328		HEAD S/N 1328								
WELDERS NAME		STAMP								
RADIOGRAPH ACCEPTANCE										
TENSILE TEST ACCEPTANCE										
REPORT NUMBER 1328										
APPROVALS:										
MFG. D/821		DATE								
Q.E. D/814		DATE								
ENGR. D/830		DATE								
QUALITY CONTROL		DATE								
STAMP										
VISUAL REJ. LOP										



ELECTRODE (Sketch)	
A	80°
B	.015
C	1.329
D	.030


**DATA SHEET**  
**1/4" Decreasing Amps**

**ORIGINAL PAGE IS  
OF POOR QUALITY.**

**AUTOMATIC BUTTWELD  
WELDING PROCEDURE SPECIFICATION (WPS)**

MPP-LO-0001

WPS No.

WPS NUMBER <b>MPP-LO-0001</b>		REVISION LETTER 								PAGE <b>14 of 14</b>	
SPECIFICATION NO. REVISION. DATE <b>TPS A/A 328-001 Sample #21 - 25%</b>											
X-Ray Results: <b>Rej. LOP</b>											
BACK-UP		PURGE GAS		HEAD		TUBE DATA					
INTERNAL GAS <u>ARG</u>		HEAD GAS <u>ARG</u>		O.D. <u>0.250</u>							
FLOW CFH <u>5+2</u>		FLOW CFH <u>15+5</u>		WALL <u>.035</u>							
PRE-PURGE TIME <u>2 MIN(MIN)</u> (1)				PRE-PURGE TIME <u>15 SEC(MIN)</u>				ALLOY <u>          </u>			
POST-PURGE TIME <u>1 MIN(MIN)</u>				POST-PURGE TIME <u>1 MIN(MIN)</u>				FTG. P/N <u>          </u>			
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.											
<b>PROGRAMMER SETTINGS</b>											
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps		PULSE LOW 5 to 199 Amps			
<div style="border: 1px solid black; padding: 5px; width: 60px; margin: 0 auto;">019</div>		<div style="border: 1px solid black; padding: 5px; width: 60px; margin: 0 auto;">017</div>		<div style="border: 1px solid black; padding: 5px; width: 60px; margin: 0 auto;">015</div>		<div style="border: 1px solid black; padding: 5px; width: 60px; margin: 0 auto;">013</div>		<div style="border: 1px solid black; padding: 5px; width: 60px; margin: 0 auto;">010</div>			
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec		FINISH SLOPE .1 to 9.9 Sec			
<div style="border: 1px solid black; padding: 5px; width: 60px; margin: 0 auto;">007</div>		<div style="border: 1px solid black; padding: 5px; width: 60px; margin: 0 auto;">005</div>		<div style="border: 1px solid black; padding: 5px; width: 60px; margin: 0 auto;">005</div>		<div style="border: 1px solid black; padding: 5px; width: 60px; margin: 0 auto;">009</div>		<div style="border: 1px solid black; padding: 5px; width: 60px; margin: 0 auto;">4.0</div>			
PULSE HIGH .1 to 9.9 Sec				PULSE LOW .1 to 9.9 Sec				ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM	
<div style="border: 1px solid black; padding: 5px; width: 60px; margin: 0 auto;">0.1</div>				<div style="border: 1px solid black; padding: 5px; width: 60px; margin: 0 auto;">0.1</div>				<div style="border: 1px solid black; padding: 5px; width: 60px; margin: 0 auto;">0.9</div>		<div style="border: 1px solid black; padding: 5px; width: 60px; margin: 0 auto;">3.60</div>	
<div style="display: flex; justify-content: space-between;"> <div style="width: 45%;"> <p><b>QUALIFICATION POSITIONS</b></p> <p><input type="checkbox"/> HORIZONTAL    <input checked="" type="checkbox"/> VERTICAL</p> <p>MACHINE E-200T4 S/N <u>328</u></p> <p>HEAD S/N <u>1328</u></p> </div> <div style="width: 50%;"> <p>WELDERS NAME <u>                                </u> STAMP <u>          </u></p> <p>RADIOGRAPH ACCEPTANCE <u>                                </u></p> <p>TENSILE TEST ACCEPTANCE <u>                                </u></p> <p>REPORT NUMBER <u>                                </u></p> <p>APPROVALS:</p> <p>MFG. D/821 <u>                                </u> DATE <u>          </u></p> <p>Q.E. D/814 <u>                                </u> DATE <u>          </u></p> <p>ENGR. D/830 <u>                                </u> DATE <u>          </u></p> <p>QUALITY CONTROL <u>                                </u> DATE <u>          </u></p> <p align="center">STAMP</p> </div> </div>											
				<p><b>ELECTRODE (Sketch)</b></p> <p>A <u>080°</u></p> <p>B <u>.015</u></p> <p>C <u>1.329</u></p> <p>D <u>.030</u></p>							
REJECT LOP											


# DATA SHEET 1/4" Decreasing Amps

## AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

MPP-LO-0001

WPS No.

MPP NUMBER MPP-LO-0001		REVISION LETTER				PAGE 14 of 14	
SPECIFICATION NO. REVISION. DATE TPS A/A 328-001 Sample #22							
X-Ray Results: Accept							
BACK-UP		PURGE GAS		HEAD		TUBE DATA	
INTERNAL GAS ARG		HEAD GAS ARG		O.D. 0.250			
FLOW CFH 5+2		FLOW CFH 15+5		WALL 0.035			
PRE-PURGE TIME 2 MIN(MIN)(1) PRE-PURGE TIME 15 SEC(MIN) ALLOY							
POST-PURGE TIME 1 MIN(MIN) POST-PURGE TIME 1 MIN(MIN) FTG. P/N							
(1) Add 1 min (min) for each additional ft. or line between the gas inlet and the joint to be welded.							
PROGRAMMER SETTINGS							
WELD LEVEL I 5 to 199 Amps	WELD LEVEL II 5 to 199 Amps	WELD LEVEL III 5 to 199 Amps	WELD LEVEL IV 5 to 199 Amps	PULSE LOW 5 to 199 Amps			
021	019	017	015	010			
LEVEL I Time 1-299 Sec	LEVEL II Time 1-299 Sec	LEVEL III Time 1-299 Sec	LEVEL IV Time 1-299 Sec	FINISH SLOPE .1 to 9.9 Sec			
007	005	005	009	4.0			
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM	
0.1		0.1		0.9		3.60	
QUALIFICATION POSITIONS <input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL				WELDERS NAME _____ STAMP _____			
MACHINE E-200T4 S/N 328 HEAD S/N 1328				RADIOGRAPH ACCEPTANCE _____			
				TENSILE TEST ACCEPTANCE _____			
				REPORT NUMBER _____			
APPROVALS:							
MFG. D/821 _____ DATE _____							
Q.E. D/814 _____ DATE _____							
ENGR. D/830 _____ DATE _____							
QUALITY CONTROL _____ DATE _____				STAMP			
VISUAL ACCEPT							




ELECTRODE (Sketch)	
A	80°
B	015
C	1.329
D	030

FORM 3916-S-1 REV. 8-73

DATA SHEET  
1/4" Increasing RPM

ORIGINAL PAGE IS  
OF POOR QUALITY


AUTOMATIC BUTTWELD  
WELDING PROCEDURE SPECIFICATION (WPS)

WPS No.																					
MPP NUMBER <b>MPP-LO-0001</b>	REVISION LETTER <table border="1" style="width: 100%; height: 20px;"> <tr> <td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> </table>																				
PAGE 14 of 14																					
SPECIFICATION NO. <u>          </u> REVISION. <u>          </u> DATE <u>TPS A/A 328-001</u> Sample #78 +5%																					
BACK-UP	PURGE GAS																				
X-Ray Results: Accept	HEAD																				
TUBE DATA																					
INTERNAL GAS. <u>ARG</u>	HEAD GAS <u>ARG</u>																				
O.D. <u>.250</u>																					
FLOW CFH <u>5+2</u>	FLOW CFH <u>15+5</u>																				
WALL <u>.035</u>																					
PRE-PURGE TIME <u>2 MIN(MIN)</u> (1) PRE-PURGE TIME <u>15 SEC(MIN)</u> ALLOY <u>          </u>																					
POST-PURGE TIME <u>1 MIN(MIN)</u> POST-PURGE TIME <u>1 MIN(MIN)</u> FTG. P/N <u>          </u>																					
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.																					
PROGRAMMER SETTINGS																					
WELD LEVEL I 5 to 199 Amps	WELD LEVEL II 5 to 199 Amps																				
WELD LEVEL III 5 to 199 Amps	WELD LEVEL IV 5 to 199 Amps																				
PULSE LOW 5 to 199 Amps																					
025	023																				
021	018																				
010																					
LEVEL I Time 1-299 Sec	LEVEL II Time 1-299 Sec																				
LEVEL III Time 1-299 Sec	LEVEL IV Time 1-299 Sec																				
FINISH SLOPE .1 to 9.9 Sec																					
007	005																				
005	009																				
4.0																					
PULSE HIGH .1 to 9.9 Sec	PULSE LOW .1 to 9.9 Sec																				
ROTATION DELAY .1 to 9.9 Sec	HEAD SPEED RPM																				
0.1	0.1																				
0.9	3.78																				
QUALIFICATION POSITIONS																					
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL																					
MACHINE E-200T4 S/N <u>328</u> HEAD S/N <u>1328</u>																					
WELDERS NAME <u>          </u> STAMP <u>          </u>																					
RADIOGRAPH ACCEPTANCE <u>          </u>																					
TENSILE TEST ACCEPTANCE <u>          </u>																					
REPORT NUMBER <u>          </u>																					
APPROVALS:																					
MFG. D/821 <u>          </u> DATE <u>          </u>																					
Q.E. D/814 <u>          </u> DATE <u>          </u>																					
ENGR. D/830 <u>          </u> DATE <u>          </u>																					
QUALITY CONTROL <u>          </u> DATE <u>          </u>																					
STAMP																					
VISUAL ACCEPT <u>          </u>																					
<div style="display: flex; align-items: center;">  <div style="margin-left: 10px;">           ELECTRODE (Sketch)            A <u>80°</u>            B <u>.015</u>            C <u>1.329</u>            D <u>.030</u> </div> </div>																					

# DATA SHEET

## 1/4" Increasing RPM

### AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)


MPP NUMBER <b>MPP-LO-0001</b>		WPS No.		PAGE <b>14 of 14</b>	
SPECIFICATION NO. REVISION.		DATE		TPS A/A 328-001 Sample #79 +10%	
BACK-UP		PURGE GAS		X-Ray Results: Accept	
INTERNAL GAS <u>ARG</u>		HEAD GAS <u>ARG</u>		TUBE DATA	
FLOW CFH <u>5+2</u>		FLOW CFH <u>15+5</u>		O.D. <u>0.250</u>	
PRE-PURGE TIME <u>2 MIN(MIN)</u> (1)		PRE-PURGE TIME <u>15 SEC(MIN)</u>		WALL <u>.035</u>	
POST-PURGE TIME <u>1 MIN(MIN)</u>		POST-PURGE TIME <u>1 MIN(MIN)</u>		ALLOY _____	
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.					
PROGRAMMER SETTINGS					
WELD LEVEL I 5 to 199 Amps	WELD LEVEL II 5 to 199 Amps	WELD LEVEL III 5 to 199 Amps	WELD LEVEL IV 5 to 199 Amps	PULSE LOW 5 to 199 Amps	
025	023	021	018	010	
LEVEL I Time 1-299 Sec	LEVEL II Time 1-299 Sec	LEVEL III Time 1-299 Sec	LEVEL IV Time 1-299 Sec	FINISH SLOPE .1 to 9.9 Sec	
007	005	005	009	4.0	
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec	
0.1		0.1		0.9	
				HEAD SPEED RPM	
				3.96	
QUALIFICATION POSITIONS					
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL					
MACHINE E-200T4 S/N <u>328</u>					
HEAD S/N <u>1328</u>					
		ELECTRODE (Sketch) A <u>80°</u> B <u>.015</u> C <u>1.329</u> D <u>.030</u>			
WELDERS NAME _____ STAMP _____					
RADIOGRAPH ACCEPTANCE _____					
TENSILE TEST ACCEPTANCE _____					
REPORT NUMBER _____					
APPROVALS:					
MFG. D/821 _____ DATE _____					
Q.E. D/814 _____ DATE _____					
ENGR. D/830 _____ DATE _____					
QUALITY CONTROL _____ DATE _____					
VISUAL ACCEPT <span style="float: right;">STAMP</span>					



DATA SHEET  
1/4" Increasing RPM

ORIGINAL PAGE IS  
OF POOR QUALITY

AUTOMATIC BUTTWELD  
WELDING PROCEDURE SPECIFICATION (WPS)


MPP NUMBER MPP-L0-0001		REVISION LETTER				WPS No.		PAGE 14 of 14	
SPECIFICATION NO. REVISION. DATE TPS A/A 328-001 Sample #80 +15%									
BACK-UP		PURGE GAS		X-Ray Results: Accept		HEAD		TUBE DATA	
INTERNAL GAS ARG		HEAD GAS ARG		O.D. .250					
FLOW CFH 5+2		FLOW CFH 15+5		WALL .035					
PRE-PURGE TIME 2 MIN(MIN)(1)				PRE-PURGE TIME 15 SEC(MIN)		ALLOY			
POST-PURGE TIME 1 MIN(MIN)				POST-PURGE TIME 1 MIN(MIN)		FTG. P/N			
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.									
PROGRAMMER SETTINGS									
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps		PULSE LOW 5 to 199 Amps	
025		023		021		018		010	
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec		FINISH SLOPE .1 to 9.9 Sec	
007		005		005		009		4.0	
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM			
0.1		0.1		0.9		4.14			
<b>QUALIFICATION POSITIONS</b> <input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL									
MACHINE E-200T4 S/N 328 HEAD S/N 1328									
WELDERS NAME _____ STAMP _____ RADIOGRAPH ACCEPTANCE _____ TENSILE TEST ACCEPTANCE _____ REPORT NUMBER _____									
<b>APPROVALS:</b> MFG. D/821 _____ DATE _____ Q.E. D/814 _____ DATE _____ ENGR. D/830 _____ DATE _____ QUALITY CONTROL _____ DATE _____ VISUAL ACCEPT _____ STAMP _____									
		<b>ELECTRODE (Sketch)</b> A 80° B .015 C 1.329 D .030							

# DATA SHEET 1/4" Increasing RPM

## AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

WPS No. \_\_\_\_\_

MPP NUMBER <b>MPP-LO-0001</b>		REVISION LETTER								PAGE 14 of 14	
SPECIFICATION NO. REVISION.		DATE <b>TPS A/A 328-001 Sample #81 +20%</b>									
BACK-UP		PURGE GAS		X-Ray Results: <b>Accept</b>				TUBE DATA			
INTERNAL GAS <u>ARG</u>		HEAD GAS <u>ARG</u>		O.D. <u>.250</u>							
FLOW CFH <u>5+2</u>		FLOW CFH <u>15+5</u>		WALL <u>.035</u>							
PRE-PURGE TIME <u>2 MIN(MIN)</u>		PRE-PURGE TIME <u>15 SEC(MIN)</u>		ALLOY _____							
POST-PURGE TIME <u>1 MIN(MIN)</u>		POST-PURGE TIME <u>1 MIN(MIN)</u>		FTG. P/N _____							
(1) Add 1 min (min) for each additional ft. o' line between the gas inlet and the joint to be welded.											
PROGRAMMER SETTINGS											
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps		PULSE LOW 5 to 199 Amps			
025		023		021		018		010			
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec		FINISH SLOPE .1 to 9.9 Sec			
007		005		005		009		4.0			
		PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM			
		0.1		0.1		0.9		4.32			
QUALIFICATION POSITIONS											
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL											
MACHINE E-200T4 S/N <u>328</u>											
HEAD S/N <u>1328</u>											
WELDERS NAME _____ STAMP _____											
RADIOGRAPH ACCEPTANCE _____											
TENSILE TEST ACCEPTANCE _____											
REPORT NUMBER _____											
APPROVALS:											
MFG. D/821 _____ DATE _____											
Q.E. D/814 _____ DATE _____											
ENGR. D/830 _____ DATE _____											
QUALITY CONTROL _____ DATE _____											
VISUAL ACCEPT _____ STAMP _____											



ELECTRODE (Sketch)

A 80°

B .015

C 1.329

D .030


DATA SHEET  
1/4" Increasing RPM

ORIGINAL PAGE IS  
OF POOR QUALITY

AUTOMATIC BUTTWELD  
WELDING PROCEDURE SPECIFICATION (WPS)

WPS No.

MPP NUMBER MPP-L0-0001		REVISION LETTER										PAGE 14 of 14	
SPECIFICATION NO. REVISION. DATE <u>TPS A/A 328-001</u> Sample #82 +20% Repeat													
X-Ray Results: Accept													
BACK-UP		PURGE GAS				HEAD				TUBE DATA			
INTERNAL GAS <u>ARG</u>		HEAD GAS <u>ARG</u>				O.D. <u>.250</u>							
FLOW CFH <u>5+2</u>		FLOW CFH <u>15+5</u>				WALL <u>.035</u>							
PRE-PURGE TIME <u>2 MIN(MIN)</u> (1) PRE-PURGE TIME <u>15 SEC(MIN)</u> ALLOY <u>          </u>													
POST-PURGE TIME <u>1 MIN(MIN)</u> POST-PURGE TIME <u>1 MIN(MIN)</u> FTG. P/W <u>          </u>													
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.													
PROGRAMMER SETTINGS													
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps		PULSE LOW 5 to 199 Amps					
025		023		021		018		010					
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec		FINISH SLOPE .1 to 9.9 Sec					
007		005		005		009		4.0					
PULSE HIGH .1 to 9.9 Sec				PULSE LOW .1 to 9.9 Sec				ROTATION DELAY .1 to 9.9 Sec				HEAD SPEED RPM	
0.1				0.1				0.9				4.32	
QUALIFICATION POSITIONS <input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL													
MACHINE E-200T4 S/N <u>328</u> HEAD S/N <u>1328</u>													
WELDERS NAME <u>                                </u> STAMP <u>          </u>													
RADIOGRAPH ACCEPTANCE <u>                                </u>													
TENSILE TEST ACCEPTANCE <u>                                </u>													
REPORT NUMBER <u>                                </u>													
APPROVALS:													
MFG. D/821 <u>                                </u> DATE <u>          </u>													
Q.E. D/814 <u>                                </u> DATE <u>          </u>													
ENGR. D/830 <u>                                </u> DATE <u>          </u>													
QUALITY CONTROL <u>                                </u> DATE <u>          </u>													
VISUAL ACCEPT													



ELECTRODE (Sketch)

A 80°

B .015

C 1.329

D .030

# DATA SHEET 1/4" Increasing RPM

## AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

MPP NUMBER MPP-LO-0001		REVISION LETTER				WPS No.		PAGE 14 of 14	
SPECIFICATION NO. REVISION. DATE TPS A/A 328-001 Sample #83 +25%									
BACK-UP		PURGE GAS		X-Ray Results: Accept		HEAD		TUBE DATA	
INTERNAL GAS ARG		HEAD GAS ARG		O.D. .250		FLOW CFH 5+2		FLOW CFH 15+5	
WALL .035		PRE-PURGE TIME 2 MIN(MIN)		PRE-PURGE TIME 15 SEC(MIN)		ALLOY		POST-PURGE TIME 1 MIN(MIN)	
POST-PURGE TIME 1 MIN(MIN)		POST-PURGE TIME 1 MIN(MIN)		FTG. P/N		(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.			
PROGRAMMER SETTINGS									
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps		PULSE LOW 5 to 199 Amps	
025		023		021		018		010	
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec		FINISH SLOPE .1 to 9.9 Sec	
007		005		005		009		4.0	
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM			
0.1		0.1		0.9		4.50			
QUALIFICATION POSITIONS									
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL									
MACHINE E-200T4 S/N 328 HEAD S/N 1328									
				ELECTRODE (Sketch) A 80° B .015 C 1.329 D .030					
WELDERS NAME _____ STAMP _____ RADIOGRAPH ACCEPTANCE _____ TENSILE TEST ACCEPTANCE _____ REPORT NUMBER _____ APPROVALS: MFG. D/821 _____ DATE _____ Q.E. D/314 _____ DATE _____ ENGR. D/830 _____ DATE _____ QUALITY CONTROL _____ DATE _____ VISUAL ACCEPT _____ STAMP _____									


FORM 3016-S-1 REV. 5-73

DATA SHEET  
1/4" Increasing RPM

ORIGINAL PAGE IS  
OF POOR QUALITY


AUTOMATIC BUTTWELD  
WELDING PROCEDURE SPECIFICATION (WPS)

WPS No.

MPP NUMBER MPP-L0-0001		REVISION LETTER								PAGE 14 of 14			
SPECIFICATION NO. REVISION.		DATE TPS A/A 328-001 Sample #84 +30%											
BACK-UP		PURGE GAS		X-Ray Results: Accept				HEAD				TUBE DATA	
INTERNAL GAS ARG		HEAD GAS ARG		O.D. 0.250				WALL .035				FLOW CFH 5+2	
PRE-PURGE TIME 2 MIN(MIN)		PRE-PURGE TIME 15 SEC(MIN)		ALLOY				POST-PURGE TIME 1 MIN(MIN)				FTG. P/N	
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.													
PROGRAMMER SETTINGS													
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps		PULSE LOW 5 to 199 Amps					
025		023		021		018		010					
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec		FINISH SLOPE .1 to 9.9 Sec					
007		005		005		009		4.0					
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM							
0.1		0.1		0.9		4.68							
QUALIFICATION POSITIONS													
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL													
MACHINE E-200T4 S/N 328 HEAD S/N 1328													
WELDERS NAME _____ STAMP _____ RADIOGRAPH ACCEPTANCE _____ TENSILE TEST ACCEPTANCE _____ REPORT NUMBER _____													
APPROVALS: MFG. D/821 _____ DATE _____ Q.E. D/814 _____ DATE _____ ENGR. D/830 _____ DATE _____ QUALITY CONTROL _____ DATE _____ VISUAL REJECT LOP _____ STAMP _____													
				ELECTRODE (Sketch) A 80° B .015 C 1.329 D .030									

# DATA SHEET 1/4" Increasing RPM

## AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

MPP NUMBER <b>MPP-LO-0001</b>		REVISION LETTER 		WPS No. 		PAGE 14 of 14	
SPECIFICATION NO. REVISION.		DATE		TPS A/A 328-001		Sample #85 +25%	
BACK-UP		PURGE GAS		X-Ray Results: Accept		TUBE DATA	
INTERNAL GAS ARG		HEAD GAS ARG		O.D. 0.250			
FLOW CFH 5+2		FLOW CFH 15+5		WALL .035			
PRE-PURGE TIME 2 MIN(MIN)		(1) PRE-PURGE TIME 15 SEC(MIN)		ALLOY			
POST-PURGE TIME 1 MIN(MIN)		POST-PURGE TIME 1 MIN(MIN)		FTG. P/N			
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.							
PROGRAMMER SETTINGS							
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps	
PULSE LOW 5 to 199 Amps							
025		023		021		018	
010							
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec	
007		005		005		009	
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM	
0.1		0.1		0.9		4.50	
QUALIFICATION POSITIONS							
<input type="checkbox"/> HORIZONTAL		<input checked="" type="checkbox"/> VERTICAL					
MACHINE E-200T4 S/N		328					
HEAD S/N		1328					
		ELECTRODE (Sketch) A 80° B .015 C 1.329 D .030					
WELDERS NAME		STAMP					
RADIOGRAPH ACCEPTANCE							
TENSILE TEST ACCEPTANCE							
REPORT NUMBER							
APPROVALS:							
MFG. D/821		DATE					
Q.E. D/814		DATE					
ENGR. D/830		DATE					
QUALITY CONTROL		DATE					
		STAMP					
VISUAL ACCEPT							

**DATA SHEET**  
**1/4" Decreasing RPM**

**ORIGINAL PAGE IS  
OF POOR QUALITY**

**AUTOMATIC BUTTWELD  
WELDING PROCEDURE SPECIFICATION (WPS)**

WPS No. \_\_\_\_\_


MPP NUMBER <b>MPP-LO-0001</b>		REVISION LETTER <table border="1" style="width:100%; height: 15px; border-collapse: collapse;"> <tr> <td> </td><td> </td><td> </td><td> </td><td> </td><td> </td><td> </td><td> </td><td> </td><td> </td><td> </td><td> </td> </tr> </table>																						PAGE <b>14 of 14</b>	
<b>SPECIFICATION NO. REVISION. DATE</b> <b>TPS A/A 328-001 Sample #73 -5%</b>																									
<div style="display: flex; justify-content: space-between;"> <div> <b>BACK-UP</b>  INTERNAL GAS <u>ARG</u>  FLOW CFH <u>5+2</u> </div> <div> <b>PURGE GAS</b>  HEAD GAS <u>ARG</u>  FLOW CFH <u>15+5</u> </div> <div> <b>X-Ray Results: Accept</b>  <b>HEAD</b>  O.D. <u>.250</u>  WALL <u>.035</u> </div> <div> <b>TUBE DATA</b>  PRE-PURGE TIME <u>2 MIN(MIN)</u>(1) PRE-PURGE TIME <u>15 SEC(MIN)</u> ALLOY _____  POST-PURGE TIME <u>1 MIN(MIN)</u> POST-PURGE TIME <u>1 MIN(MIN)</u> FTG. P/N _____  (1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded. </div> </div>																									
<b>PROGRAMMER SETTINGS</b>																									
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps		PULSE LOW 5 to 199 Amps																	
<div style="border: 1px solid black; width: 40px; height: 20px; margin: 0 auto;">025</div>		<div style="border: 1px solid black; width: 40px; height: 20px; margin: 0 auto;">023</div>		<div style="border: 1px solid black; width: 40px; height: 20px; margin: 0 auto;">021</div>		<div style="border: 1px solid black; width: 40px; height: 20px; margin: 0 auto;">018</div>		<div style="border: 1px solid black; width: 40px; height: 20px; margin: 0 auto;">010</div>																	
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec		FINISH SLOPE .1 to 9.9 Sec																	
<div style="border: 1px solid black; width: 40px; height: 20px; margin: 0 auto;">007</div>		<div style="border: 1px solid black; width: 40px; height: 20px; margin: 0 auto;">005</div>		<div style="border: 1px solid black; width: 40px; height: 20px; margin: 0 auto;">005</div>		<div style="border: 1px solid black; width: 40px; height: 20px; margin: 0 auto;">009</div>		<div style="border: 1px solid black; width: 40px; height: 20px; margin: 0 auto;">4.0</div>																	
				PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM															
				<div style="border: 1px solid black; width: 40px; height: 20px; margin: 0 auto;">0.1</div>		<div style="border: 1px solid black; width: 40px; height: 20px; margin: 0 auto;">0.1</div>		<div style="border: 1px solid black; width: 40px; height: 20px; margin: 0 auto;">0.9</div>		<div style="border: 1px solid black; width: 40px; height: 20px; margin: 0 auto;">3.42</div>															

<b>QUALIFICATION POSITIONS</b> <input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL		<b>WELDERS NAME</b> _____ <b>STAMP</b> _____	
<b>MACHINE E-200T4 S/N</b> <u>328</u> <b>HEAD S/N</b> <u>1328</u>		<b>RADIOGRAPH ACCEPTANCE</b> _____ <b>TENSILE TEST ACCEPTANCE</b> _____ <b>REPORT NUMBER</b> _____	
<div style="display: flex; align-items: center;"> <div style="margin-left: 10px;"> <b>ELECTRODE (Sketch)</b>  A <u>080°</u>  B <u>.015</u>  C <u>1.329</u>  D <u>.030</u> </div> </div> <div style="text-align: center; margin-top: 10px;"> </div>		<b>APPROVALS:</b> MFG. D/821 _____ DATE _____ Q.E. D/814 _____ DATE _____ ENGR. D/830 _____ DATE _____ <b>QUALITY CONTROL</b> _____ DATE _____ <div style="text-align: right;">STAMP</div>	
<b>VISUAL ACCEPT</b>			

# DATA SHEET 1/4" Decreasing RPM

## AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

MPP NUMBER MPP-L0-0001		REVISION LETTER										PAGE 14 of 14	
SPECIFICATION NO.		REVISION.		DATE		TPS A/A 328-001 Sample #74 - 10%							
BACK-UP		PURGE GAS		X-Ray Results: Accept				HEAD		TUBE DATA			
INTERNAL GAS ARG		HEAD GAS ARG		O.D.		.250							
FLOW CFH 5+2		FLOW CFH 15+5		WALL		.035							
PRE-PURGE TIME 2 MIN(MIN)(1)		PRE-PURGE TIME 15 SEC(MIN)		ALLOY									
POST-PURGE TIME 1 MIN(MIN)		POST-PURGE TIME 1 MIN(MIN)		FTG. P/N									
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.													
PROGRAMMER SETTINGS													
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps		PULSE LOW 5 to 199 Amps					
025		023		021		018		010					
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec		FINISH SLOPE .1 to 9.9 Sec					
007		005		005		009		4.0					
		PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM					
		0.1		0.1		0.9		3.24					
<b>QUALIFICATION POSITIONS</b> <input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL MACHINE E-200T4 S/N 328 HEAD S/N 1328													
WELDERS NAME _____ STAMP _____ RADIOGRAPH ACCEPTANCE _____ TENSILE TEST ACCEPTANCE _____ REPORT NUMBER _____ APPROVALS: MFG. D/821 _____ DATE _____ Q.E. D/814 _____ DATE _____ ENGR. D/830 _____ DATE _____ QUALITY CONTROL _____ DATE _____ STAMP _____ VISUAL ACCEPT													
				ELECTRODE (Sketch) A 80° B .015 C 1.329 D .030									



DATA SHEET  
1/4" Decreasing RPM

ORIGINAL PAGE IS  
OF POOR QUALITY

AUTOMATIC BUTTWELD  
WELDING PROCEDURE SPECIFICATION (WPS)

WPS No.


MPP NUMBER MPP-LO-0001		REVISION LETTER				PAGE 14 of 14
SPECIFICATION NO. REVISION. DATE TPS A/A 328-001 Sample #75-15%						
X-Ray Results: Accept						
BACK-UP		PURGE GAS		HEAD		TUBE DATA
INTERNAL GAS ARG		HEAD GAS ARG		O.D.		.250
FLOW CFH 5+2		FLOW CFH 15+5		WALL		.035
PRE-PURGE TIME 2 MIN(MIN)(1) PRE-PURGE TIME 15 SEC(MIN) ALLOY						
POST-PURGE TIME 1 MIN(MIN) POST-PURGE TIME 1 MIN(MIN) FTG. P/N						
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.						
PROGRAMMER SETTINGS						
WELD LEVEL I 5 to 199 Amps	WELD LEVEL II 5 to 199 Amps	WELD LEVEL III 5 to 199 Amps	WELD LEVEL IV 5 to 199 Amps	PULSE LOW 5 to 199 Amps		
025	023	021	018	010		
LEVEL I Time 1-299 Sec	LEVEL II Time 1-299 Sec	LEVEL III Time 1-299 Sec	LEVEL IV Time 1-299 Sec	FINISH SLOPE .1 to 9.9 Sec		
007	005	005	009	4.0		
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM
0.1		0.1		0.9		3.06
QUALIFICATION POSITIONS						
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL						
WELDERS NAME _____ STAMP _____						
RADIOGRAPH ACCEPTANCE _____						
TENSILE TEST ACCEPTANCE _____						
REPORT NUMBER _____						
APPROVALS:						
MFG. D/821 _____ DATE _____						
Q.E. D/814 _____ DATE _____						
ENGR. D/830 _____ DATE _____						
QUALITY CONTROL _____ DATE _____						
STAMP						
VISUAL REJECT L.O.P.						

FORM 3012.1 REV 5.73

# DATA SHEET 1/4" Decreasing RPM

## AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

WPS No.

MPP NUMBER <b>MPP-LO-0001</b>		REVISION LETTER										PAGE <b>14 of 14</b>	
SPECIFICATION NO. REVISION. DATE <u>TPS A/A 328-001 Sample #76 -20%</u>													
BACK-UP		PURGE GAS		X-Ray Results: Accept						TUBE DATA			
INTERNAL GAS <u>ARG</u>		HEAD GAS <u>ARG</u>								O.D. <u>.250</u>			
FLOW CFH <u>5+2</u>		FLOW CFH <u>15+5</u>								WALL <u>.035</u>			
PRE-PURGE TIME <u>2 MIN(MIN)</u> (1) PRE-PURGE TIME <u>15 SEC(MIN)</u> ALLOY <u></u>													
POST-PURGE TIME <u>1 MIN(MIN)</u> POST-PURGE TIME <u>1 MIN(MIN)</u> FTG. P/N <u></u>													
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.													
PROGRAMMER SETTINGS													
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps		PULSE LOW 5 to 199 Amps					
<div style="border: 1px solid black; padding: 5px; width: 60px; margin: 0 auto;">025</div>		<div style="border: 1px solid black; padding: 5px; width: 60px; margin: 0 auto;">023</div>		<div style="border: 1px solid black; padding: 5px; width: 60px; margin: 0 auto;">021</div>		<div style="border: 1px solid black; padding: 5px; width: 60px; margin: 0 auto;">018</div>		<div style="border: 1px solid black; padding: 5px; width: 100px; margin: 0 auto;">010</div>					
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec		FINISH SLOPE .1 to 9.9 Sec					
<div style="border: 1px solid black; padding: 5px; width: 60px; margin: 0 auto;">007</div>		<div style="border: 1px solid black; padding: 5px; width: 60px; margin: 0 auto;">005</div>		<div style="border: 1px solid black; padding: 5px; width: 60px; margin: 0 auto;">005</div>		<div style="border: 1px solid black; padding: 5px; width: 60px; margin: 0 auto;">009</div>		<div style="border: 1px solid black; padding: 5px; width: 100px; margin: 0 auto;">4.0</div>					
				PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM			
				<div style="border: 1px solid black; padding: 5px; width: 60px; margin: 0 auto;">0.1</div>		<div style="border: 1px solid black; padding: 5px; width: 60px; margin: 0 auto;">0.1</div>		<div style="border: 1px solid black; padding: 5px; width: 60px; margin: 0 auto;">0.9</div>		<div style="border: 1px solid black; padding: 5px; width: 100px; margin: 0 auto;">2.88</div>			
QUALIFICATION POSITIONS													
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL													
MACHINE E-200T4 S/N <u>328</u>													
HEAD S/N <u>1328</u>													
				ELECTRODE (Sketch) A <u>80°</u> B <u>.015</u> C <u>1.329</u> D <u>.030</u>									
WELDERS NAME _____ STAMP _____ RADIOGRAPH ACCEPTANCE _____ TENSILE TEST ACCEPTANCE _____ REPORT NUMBER _____ APPROVALS: MFG. D/821 _____ DATE _____ Q.E. D/814 _____ DATE _____ ENGR. D/830 _____ DATE _____ QUALITY CONTROL _____ DATE _____ STAMP _____ VISUAL REJECT LOP _____													


FORM 3016-S-1 REV. 5-73

DATA SHEET  
1/4" Increasing Shielding Gas

MPP NUMBER MPP-LO-0001		REVISION LETTER <div style="display: flex; justify-content: space-between;"> <div style="width: 20px;"></div> <div style="width: 20px;"></div> <div style="width: 20px;"></div> <div style="width: 20px;"></div> <div style="width: 20px;"></div> <div style="width: 20px;"></div> <div style="width: 20px;"></div> <div style="width: 20px;"></div> <div style="width: 20px;"></div> <div style="width: 20px;"></div> <div style="width: 20px;"></div> <div style="width: 20px;"></div> </div>										WPS No. PAGE 14 of 14	
SPECIFICATION NO. REVISION. DATE <u>TPS A/A 328-001</u> Sample #93 +5%													
PURGE GAS				X-Ray Results: Accept									
BACK-UP				HEAD				TUBE DATA					
INTERNAL GAS <u>ARG</u>				HEAD GAS <u>ARG</u>				O.D. <u>.250</u>					
FLOW CFH <u>5+2</u>				FLOW CFH <u>16</u>				WALL <u>.035</u>					
PRE-PURGE TIME <u>2 MIN(MIN)</u> (1)				PRE-PURGE TIME <u>15 SEC(MIN)</u>				ALLOY <u></u>					
POST-PURGE TIME <u>1 MIN(MIN)</u>				POST-PURGE TIME <u>1 MIN(MIN)</u>				FTG. P/N <u></u>					
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.													
PROGRAMMER SETTINGS													
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps		PULSE LOW 5 to 199 Amps					
025		023		021		018		010					
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec		FINISH SLOPE .1 to 9.9 Sec					
007		005		005		009		4.0					
				PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM			
				0.1		0.1		0.9		3.60			
QUALIFICATION POSITIONS													
<input type="checkbox"/> HORIZONTAL		<input checked="" type="checkbox"/> VERTICAL											
MACHINE E-200T4 S/N <u>328</u>													
HEAD S/N <u>1328</u>													
				ELECTRODE (Sketch) A <u>80°</u> B <u>.015</u> C <u>1.329</u> D <u>.030</u>									
				WELDERS NAME _____ STAMP _____									
				RADIOGRAPH ACCEPTANCE _____									
				TENSILE TEST ACCEPTANCE _____									
				REPORT NUMBER _____									
				APPROVALS:									
				MFG. D/821 _____ DATE _____									
				Q.E. D/814 _____ DATE _____									
				ENGR. D/830 _____ DATE _____									
				QUALITY CONTROL _____ DATE _____									
				STAMP									
VISUAL ACCEPT													

# DATA SHEET 1/4" Increasing Shielding Gas

## AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

WPS No.																					
MPP NUMBER MPP-LO-0001	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td colspan="10" style="text-align: center;">REVISION LETTER</td> </tr> <tr> <td> </td><td> </td><td> </td><td> </td><td> </td><td> </td><td> </td><td> </td><td> </td><td> </td> </tr> </table>	REVISION LETTER																			
REVISION LETTER																					
PAGE 14 of 14																					
SPECIFICATION NO. REVISION.    DATE    TPS A/A 328-001 Sample #94 +10%																					
X-Ray Results: Accept																					
BACK-UP	PURGE GAS																				
INTERNAL GAS. ARG	HEAD    TUBE DATA																				
HEAD GAS ARG	O.D. .250																				
FLOW CFH 5+2	FLOW CFH 17    WALL .035																				
PRE-PURGE TIME 2 MIN(MIN) (1) PRE-PURGE TIME 15 SEC(MIN) ALLOY																					
POST-PURGE TIME 1 MIN(MIN) POST-PURGE TIME 1 MIN(MIN) FTG. P/N																					
(1) Add 1 min (min) for each additional ft. o' line between the gas inlet and the joint to be welded.																					
PROGRAMMER SETTINGS																					
WELD LEVEL I 5 to 199 Amps	WELD LEVEL II 5 to 199 Amps																				
WELD LEVEL III 5 to 199 Amps	WELD LEVEL IV 5 to 199 Amps																				
PULSE LOW 5 to 199 Amps	PULSE LOW 5 to 199 Amps																				
025	023																				
021	018																				
010																					
LEVEL I Time 1-299 Sec	LEVEL II Time 1-299 Sec																				
LEVEL III Time 1-299 Sec	LEVEL IV Time 1-299 Sec																				
FINISH SLOPE .1 to 9.9 Sec	FINISH SLOPE .1 to 9.9 Sec																				
007	005																				
005	009																				
4.0																					
PULSE HIGH .1 to 9.9 Sec	PULSE LOW .1 to 9.9 Sec																				
PULSE LOW .1 to 9.9 Sec	ROTATION DELAY .1 to 9.9 Sec																				
HEAD SPEED RPM	HEAD SPEED RPM																				
0.1	0.1																				
0.9	3.60																				
QUALIFICATION POSITIONS <input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL																					
MACHINE E-200T4 S/N 328 HEAD S/N 1328																					
WELDERS NAME _____ STAMP _____																					
RADIOGRAPH ACCEPTANCE _____																					
TENSILE TEST ACCEPTANCE _____																					
REPORT NUMBER _____																					
APPROVALS:																					
MFG. D/821 _____ DATE _____																					
Q.E. D/814 _____ DATE _____																					
ENGR. D/830 _____ DATE _____																					
QUALITY CONTROL _____ DATE _____																					
VISUAL ACCEPT _____ STAMP _____																					
<div style="display: flex; align-items: center;">  <div style="margin-left: 10px;">           ELECTRODE (Sketch)            A 80°            B .015            C 1.329            D .030         </div> </div>																					

FORM 3916-S-1 REV. 5-73

**ORIGINAL PAGE IS  
OF POOR QUALITY**

## WPS No.

55

# DATA SHEET

## 1/4" Increasing Shielding Gas

### AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

WPS No. \_\_\_\_\_

MPP NUMBER <u>MPP-LO-0001</u>		REVISION LETTER				PAGE 14 of 14	
SPECIFICATION NO. REVISION. DATE <u>TPS A/A 328-001</u> Sample #96 +30%							
BACK-UP _____ PURGE GAS _____		X-Ray Results: <u>Accept</u>					
INTERNAL GAS <u>ARG</u>		HEAD _____ HEAD GAS <u>ARG</u>		TUBE DATA O.D. <u>0.250</u>			
FLOW CFH <u>5+2</u>		FLOW CFH <u>20</u>		WALL <u>.035</u>			
PRE-PURGE TIME <u>2 MIN(MIN)</u> (1) PRE-PURGE TIME <u>15 SEC(MIN)</u> ALLOY _____							
POST-PURGE TIME <u>1 MIN(MIN)</u> POST-PURGE TIME <u>1 MIN(MIN)</u> FTG. P/N _____ (1) Add 1 min (min) for each additional ft. or line between the gas inlet and the joint to be welded.							
PROGRAMMER SETTINGS							
WELD LEVEL I 5 to 199 Amps <div style="border: 1px solid black; width: 60px; height: 30px; margin: 5px auto; text-align: center;">025</div>		WELD LEVEL II 5 to 199 Amps <div style="border: 1px solid black; width: 60px; height: 30px; margin: 5px auto; text-align: center;">023</div>		WELD LEVEL III 5 to 199 Amps <div style="border: 1px solid black; width: 60px; height: 30px; margin: 5px auto; text-align: center;">021</div>		WELD LEVEL IV 5 to 199 Amps <div style="border: 1px solid black; width: 60px; height: 30px; margin: 5px auto; text-align: center;">018</div>	
PULSE LOW 5 to 199 Amps <div style="border: 1px solid black; width: 60px; height: 30px; margin: 5px auto; text-align: center;">010</div>							
LEVEL I Time 1-299 Sec <div style="border: 1px solid black; width: 60px; height: 30px; margin: 5px auto; text-align: center;">007</div>		LEVEL II Time 1-299 Sec <div style="border: 1px solid black; width: 60px; height: 30px; margin: 5px auto; text-align: center;">005</div>		LEVEL III Time 1-299 Sec <div style="border: 1px solid black; width: 60px; height: 30px; margin: 5px auto; text-align: center;">005</div>		LEVEL IV Time 1-299 Sec <div style="border: 1px solid black; width: 60px; height: 30px; margin: 5px auto; text-align: center;">009</div>	
FINISH SLOPE .1 to 9.9 Sec <div style="border: 1px solid black; width: 60px; height: 30px; margin: 5px auto; text-align: center;">4.0</div>							
PULSE HIGH .1 to 9.9 Sec <div style="border: 1px solid black; width: 60px; height: 30px; margin: 5px auto; text-align: center;">0.1</div>		PULSE LOW .1 to 9.9 Sec <div style="border: 1px solid black; width: 60px; height: 30px; margin: 5px auto; text-align: center;">0.1</div>		ROTATION DELAY .1 to 9.9 Sec <div style="border: 1px solid black; width: 60px; height: 30px; margin: 5px auto; text-align: center;">0.9</div>		HEAD SPEED RPM <div style="border: 1px solid black; width: 60px; height: 30px; margin: 5px auto; text-align: center;">3.60</div>	
QUALIFICATION POSITIONS <input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL							
MACHINE E-200T4 S/N <u>328</u> HEAD S/N <u>1328</u>							
WELDERS NAME _____ STAMP _____ RADIOGRAPH ACCEPTANCE _____ TENSILE TEST ACCEPTANCE _____ REPORT NUMBER _____				APPROVALS: MFG. D/821 _____ DATE _____ Q.E. D/814 _____ DATE _____ ENGR. D/830 _____ DATE _____ QUALITY CONTROL _____ DATE _____ STAMP _____			
VISUAL ACCEPT				ELECTRODE (Sketch) A <u>80°</u> B <u>.015</u> C <u>1.329</u> D <u>.030</u>			

FORM 3916-S-1 REV. 5-73


**ORIGINAL PAGE IS  
OF POOR QUALITY**

## WPS No.

57

# DATA SHEET 1/4" Increasing Shielding Gas

## AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

MPP NUMBER <b>MPP-LO-0001</b>		REVISION LETTER		WPS No.		PAGE 14 of 14	
SPECIFICATION NO. REVISION.		DATE		TPS A/A 328-001 Sample #98 +50%			
BACK-UP		PURGE GAS		X-Ray Results: Reject L.O.F			
INTERNAL GAS <u>ARG</u>		HEAD GAS <u>ARG</u>		O.D. <u>.250</u>		TUBE DATA	
FLOW CFH <u>5+2</u>		FLOW CFH <u>22</u>		WALL <u>.035</u>			
PRE-PURGE TIME <u>2 MIN(MIN)</u> (1)		PRE-PURGE TIME <u>15 SEC(MIN)</u>		ALLOY			
POST-PURGE TIME <u>1 MIN(MIN)</u>		POST-PURGE TIME <u>1 MIN(MIN)</u>		FTG. P/N			
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.							
PROGRAMMER SETTINGS							
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps	
PULSE LOW 5 to 199 Amps							
<div style="border: 1px solid black; padding: 2px; text-align: center;">025</div>		<div style="border: 1px solid black; padding: 2px; text-align: center;">023</div>		<div style="border: 1px solid black; padding: 2px; text-align: center;">021</div>		<div style="border: 1px solid black; padding: 2px; text-align: center;">018</div>	
<div style="border: 1px solid black; padding: 2px; text-align: center;">010</div>							
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec	
FINISH SLOPE .1 to 9.9 Sec							
<div style="border: 1px solid black; padding: 2px; text-align: center;">007</div>		<div style="border: 1px solid black; padding: 2px; text-align: center;">005</div>		<div style="border: 1px solid black; padding: 2px; text-align: center;">005</div>		<div style="border: 1px solid black; padding: 2px; text-align: center;">009</div>	
<div style="border: 1px solid black; padding: 2px; text-align: center;">4.0</div>							
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM	
<div style="border: 1px solid black; padding: 2px; text-align: center;">0.1</div>		<div style="border: 1px solid black; padding: 2px; text-align: center;">0.1</div>		<div style="border: 1px solid black; padding: 2px; text-align: center;">0.9</div>		<div style="border: 1px solid black; padding: 2px; text-align: center;">3.60</div>	
<div> <div> <div>QUALIFICATION POSITIONS</div> <div> <input type="checkbox"/> HORIZONTAL           <input checked="" type="checkbox"/> VERTICAL         </div> </div> <div> <div>MACHINE E-200T4 S/N <u>328</u></div> <div>HEAD S/N <u>1328</u></div> </div> <div>  <div> <div>ELECTRODE (Sketch)</div> <div>A <u>80°</u></div> <div>B <u>.015</u></div> <div>C <u>1.329</u></div> <div>D <u>.030</u></div> </div> </div> </div> <div> <div>WELDERS NAME _____ STAMP _____</div> <div>RADIOGRAPH ACCEPTANCE _____</div> <div>TENSILE TEST ACCEPTANCE _____</div> <div>REPORT NUMBER _____</div> <div>APPROVALS:</div> <div> <div>MFG. D/821 _____ DATE _____</div> <div>Q.E. D/814 _____ DATE _____</div> <div>ENGR.D/830 _____ DATE _____</div> <div>           QUALITY CONTROL _____ DATE _____            STAMP         </div> </div> <div>VISUAL ACCEPT</div> </div>							


FORM 3016 S-1 REV. 5-73



DATA SHEET  
1/4" Increasing Shielding Gas


ORIGINAL PAGE IS  
OF POOR QUALITY

AUTOMATIC BUTTWELD  
WELDING PROCEDURE SPECIFICATION (WPS)

MPP NUMBER MPP-LO-0001		REVISION LETTER								PAGE 14 of 14	
SPECIFICATION NO. REVISION.		DATE TPS A/A 328-001 Sample #99 +60%									
BACK-UP		PURGE GAS		X-Ray Results: Reject L.O.F				HEAD			
INTERNAL GAS ARG		HEAD GAS ARG		O.D. .250				TUBE DATA			
FLOW CFH 5+2		FLOW CFH 24		WALL .035							
PRE-PURGE TIME 2 MIN(MIN)		(1) PRE-PURGE TIME 15 SEC(MIN)		ALLOY							
POST-PURGE TIME 1 MIN(MIN)		POST-PURGE TIME 1 MIN(MIN)		FTG. P/N							
(1) Add 1 min (min) for each additional ft. 0" line between the gas inlet and the joint to be welded.											
PROGRAMMER SETTINGS											
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps		PULSE LOW 5 to 199 Amps			
025		023		021		018		010			
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec		FINISH SLOPE .1 to 9.9 Sec			
007		005		005		009		4.0			
		PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM			
		0.1		0.1		0.9		3.60			
<div style="display: flex; justify-content: space-between;"> <div> <p>QUALIFICATION POSITIONS</p> <p><input type="checkbox"/> HORIZONTAL <input type="checkbox"/> VERTICAL</p> <p>MACHINE E-200T4 S/N 328</p> <p>HEAD S/N 1328</p> </div> <div> <p>WELDERS NAME _____ STAMP _____</p> <p>RADIOGRAPH ACCEPTANCE _____</p> <p>TENSILE TEST ACCEPTANCE _____</p> <p>REPORT NUMBER _____</p> <p>APPROVALS:</p> <p>MFG. D/821 _____ DATE _____</p> <p>Q.E. D/814 _____ DATE _____</p> <p>ENGR. D/830 _____ DATE _____</p> <p>QUALITY CONTROL _____ DATE _____</p> <p style="text-align: center;">STAMP</p> <p>VISUAL ACCEPT</p> </div> </div>											
		<p>ELECTRODE (Sketch)</p> <p>A 80°</p> <p>B .015</p> <p>C 1.329</p> <p>D .030</p> <p>FTG.</p>									

# DATA SHEET 1/4" Decreasing Shielding Gas

## AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

MPP NUMBER MPP-LO-0001		WPS No.	
REVISION LETTER		PAGE 14 of 14	
SPECIFICATION NO. REVISION. DATE TPS A/A 328-001 Sample #86 -5%			
X-Ray Results: Accept			
BACK-UP	PURGE GAS	HEAD	TUBE DATA
INTERNAL GAS ARG	HEAD GAS ARG	O.D.	.250
FLOW CFH 5+2	FLOW CFH 14*	WALL	.035
PRE-PURGE TIME 2 MIN(MIN)(1) PRE-PURGE TIME 15 SEC(MIN) ALLOY			
POST-PURGE TIME 1 MIN(MIN) POST-PURGE TIME 1 MIN(MIN) FTG. P/W			
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.			
PROGRAMMER SETTINGS			
WELD LEVEL I 5 to 199 Amps	WELD LEVEL II 5 to 199 Amps	WELD LEVEL III 5 to 199 Amps	WELD LEVEL IV 5 to 199 Amps
025	023	021	018
010			
LEVEL I Time 1-299 Sec	LEVEL II Time 1-299 Sec	LEVEL III Time 1-299 Sec	LEVEL IV Time 1-299 Sec
007	005	005	009
FINISH SLOPE .1 to 9.9 Sec			
4.0			
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec	
0.1		0.1	
ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM	
0.9		3.60	
QUALIFICATION POSITIONS			
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL			
WELDERS NAME _____ STAMP _____			
RADIOGRAPH ACCEPTANCE _____			
TENSILE TEST ACCEPTANCE _____			
REPORT NUMBER _____			
APPROVALS:			
MFG. D/821 _____ DATE _____			
Q.E. D/814 _____ DATE _____			
ENGR. D/830 _____ DATE _____			
QUALITY CONTROL _____ DATE _____			
*DECREASING SHIELD GAS STAMP			
		ELECTRODE (Sketch) A 80° B .015 C 1.329 D .030	

FORM 3016-S-1 REV. 5-73


**DATA SHEET**  
**1/4" Decreasing Shielding Gas**

**ORIGINAL PAGE IS  
 OF POOR QUALITY**

**AUTOMATIC BUTTWELD  
 WELDING PROCEDURE SPECIFICATION (WPS)**

WPS No. \_\_\_\_\_

<b>MPP NUMBER</b> MPP-LO-0001		<b>REVISION LETTER</b>										<b>PAGE</b> 14 of 14	
<b>SPECIFICATION NO.</b>		<b>REVISION.</b>		<b>DATE</b>		TPS A/A 328-001 Sample #87 -10%							
<b>BACK-UP</b>		<b>PURGE GAS</b>		<b>X-Ray Results:</b> Accept				<b>HEAD</b>		<b>TUBE DATA</b>			
INTERNAL GAS ARG		HEAD GAS ARG		O.D. .250									
FLOW CFH 5+2		FLOW CFH 12		WALL .035									
PRE-PURGE TIME 2 MIN(MIN)(1)				PRE-PURGE TIME 15 SEC(MIN)				ALLOY					
POST-PURGE TIME 1 MIN(MIN)				POST-PURGE TIME 1 MIN(MIN)				FTG. P/W					
(1) Add 1 min (min) for each additional ft. 0" line between the gas inlet and the joint to be welded.													
<b>PROGRAMMER SETTINGS</b>													
<b>WELD LEVEL I</b> 5 to 199 Amps		<b>WELD LEVEL II</b> 5 to 199 Amps		<b>WELD LEVEL III</b> 5 to 199 Amps		<b>WELD LEVEL IV</b> 5 to 199 Amps		<b>PULSE LOW</b> 5 to 199 Amps					
025		023		021		018		010					
<b>LEVEL I</b> Time 1-299 Sec		<b>LEVEL II</b> Time 1-299 Sec		<b>LEVEL III</b> Time 1-299 Sec		<b>LEVEL IV</b> Time 1-299 Sec		<b>FINISH SLOPE</b> .1 to 9.9 Sec					
007		005		005		009		4.0					
				<b>PULSE HIGH</b> .1 to 9.9 Sec		<b>PULSE LOW</b> .1 to 9.9 Sec		<b>ROTATION DELAY</b> .1 to 9.9 Sec		<b>HEAD SPEED</b> RPM			
				0.1		0.1		0.9		3.60			
<b>QUALIFICATION POSITIONS</b>													
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL													
MACHINE E-200T4 S/N 328 HEAD S/N 1328													
WELDERS NAME _____ STAMP _____ RADIOGRAPH ACCEPTANCE _____ TENSILE TEST ACCEPTANCE _____ REPORT NUMBER _____													
APPROVALS: MFG. D/821 _____ DATE _____ Q.E. D/814 _____ DATE _____ ENGR. D/830 _____ DATE _____ QUALITY CONTROL _____ DATE _____ STAMP _____													
VISUAL ACCEPT													




<b>ELECTRODE (Sketch)</b>	
A	80°
B	.015
C	1.329
D	.030

# DATA SHEET

## 1/4" Decreasing Shielding Gas

### AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

WPS No.																					
MPP NUMBER MPP-LO-0001	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td colspan="10" style="text-align: center;">REVISION LETTER</td> </tr> <tr> <td> </td><td> </td><td> </td><td> </td><td> </td><td> </td><td> </td><td> </td><td> </td><td> </td> </tr> </table>	REVISION LETTER																			
REVISION LETTER																					
PAGE 14 of 14																					
SPECIFICATION NO. REVISION. DATE <u>TPS A/A 328-001</u> Sample #88 -25%																					
X-Ray Results: Accept																					
BACK-UP	PURGE GAS																				
INTERNAL GAS <u>ARG</u>	HEAD <u>ARG</u>																				
FLOW CFH <u>5+2</u>	TUBE DATA																				
HEAD GAS <u>ARG</u>	O.D. <u>..250</u>																				
FLOW CFH <u>15+5 11</u>	WALL <u>.035</u>																				
PRE-PURGE TIME <u>2 MIN(MIN)</u> (1) PRE-PURGE TIME <u>15 SEC(MIN)</u> ALLOY <u> </u>																					
POST-PURGE TIME <u>1 MIN(MIN)</u> POST-PURGE TIME <u>1 MIN(MIN)</u> FTG. P/H <u> </u>																					
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.																					
PROGRAMMER SETTINGS																					
WELD LEVEL I 5 to 199 Amps	WELD LEVEL II 5 to 199 Amps																				
WELD LEVEL III 5 to 199 Amps	WELD LEVEL IV 5 to 199 Amps																				
PULSE LOW 5 to 199 Amps	PULSE LOW 5 to 199 Amps																				
025	023																				
021	018																				
010																					
LEVEL I Time 1-299 Sec	LEVEL II Time 1-299 Sec																				
LEVEL III Time 1-299 Sec	LEVEL IV Time 1-299 Sec																				
FINISH SLOPE .1 to 9.9 Sec	FINISH SLOPE .1 to 9.9 Sec																				
007	005																				
005	009																				
4.0																					
PULSE HIGH .1 to 9.9 Sec	PULSE LOW .1 to 9.9 Sec																				
PULSE LOW .1 to 9.9 Sec	ROTATION DELAY .1 to 9.9 Sec																				
HEAD SPEED RPM	HEAD SPEED RPM																				
0.1	0.1																				
0.9	3.60																				
QUALIFICATION POSITIONS <input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL																					
MACHINE E-200T4 S/N <u>328</u> HEAD S/N <u>1328</u>																					
WELDERS NAME <u> </u> STAMP <u> </u> RADIOGRAPH ACCEPTANCE <u> </u> TENSILE TEST ACCEPTANCE <u> </u> REPORT NUMBER <u> </u>																					
APPROVALS: MFG. D/821 <u> </u> DATE <u> </u> Q.E. D/814 <u> </u> DATE <u> </u> ENGR. D/830 <u> </u> DATE <u> </u> QUALITY CONTROL <u> </u> DATE <u> </u> STAMP <u> </u>																					
REJECT LOW CONCAVITY																					
<div style="display: flex; align-items: center;">  <div style="margin-left: 10px;">           ELECTRODE (Sketch)            A <u>80°</u>            B <u>.015</u>            C <u>1.329</u>            D <u>.030</u> </div> </div>																					

**DATA SHEET**  
**1/4" Decreasing Shielding Gas**

**ORIGINAL PAGE 13**  
**OF POOR QUALITY**

**AUTOMATIC BUTTWELD**  
**WELDING PROCEDURE SPECIFICATION (WPS)**

WPS No. _____																					
MPP NUMBER MPP-LO-0001	<table border="1" style="width:100%; border-collapse: collapse;"> <tr> <td align="center" colspan="10">REVISION LETTER</td> </tr> <tr> <td> </td><td> </td><td> </td><td> </td><td> </td><td> </td><td> </td><td> </td><td> </td><td> </td> </tr> </table>	REVISION LETTER																			
REVISION LETTER																					
SPECIFICATION NO. _____ REVISION. _____ DATE _____ TPS A/A 328-001 Sample #89 -30%																					
X-Ray Results: Accept																					
BACK-UP	PURGE GAS																				
INTERNAL GAS. ARG	HEAD GAS ARG																				
FLOW CFH 5+2	FLOW CFH 9																				
PRE-PURGE TIME 2 MIN(MIN)(1)	PRE-PURGE TIME 15 SEC(MIN) ALLOY _____																				
POST-PURGE TIME 1 MIN(MIN)	POST-PURGE TIME 1 MIN(MIN) FTG. P/W _____																				
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.																					
PROGRAMMER SETTINGS																					
WELD LEVEL I 5 to 199 Amps	WELD LEVEL II 5 to 199 Amps																				
WELD LEVEL III 5 to 199 Amps	WELD LEVEL IV 5 to 199 Amps																				
PULSE LOW 5 to 199 Amps																					
025	023																				
021	018																				
010																					
LEVEL I Time 1-299 Sec	LEVEL II Time 1-299 Sec																				
LEVEL III Time 1-299 Sec	LEVEL IV Time 1-299 Sec																				
FINISH SLOPE .1 to 9.9 Sec																					
007	005																				
005	009																				
4.0																					
PULSE HIGH .1 to 9.9 Sec	PULSE LOW .1 to 9.9 Sec																				
ROTATION DELAY .1 to 9.9 Sec	HEAD SPEED RPM																				
0.1	0.1																				
0.9	3.60																				
QUALIFICATION POSITIONS																					
<input type="checkbox"/> HORIZONTAL	<input checked="" type="checkbox"/> VERTICAL																				
MACHINE E-200T4 S/N 328	WELDERS NAME _____ STAMP _____																				
HEAD S/N 1328	RADIOGRAPH ACCEPTANCE _____																				
	TENSILE TEST ACCEPTANCE _____																				
	REPORT NUMBER _____																				
APPROVALS:																					
MFG. D/821 _____ DATE _____																					
Q.E. D/814 _____ DATE _____																					
ENGR.D/830 _____ DATE _____																					
QUALITY CONTROL _____ DATE _____																					
VISUAL ACCEPT																					

**ELECTRODE (Sketch)**

A 80°


B .015

C 1.329

D .030

# DATA SHEET 1/4" Decreasing Shielding Gas

## AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

MPP NUMBER <b>MPP-LO-0001</b>		REVISION LETTER 		WPS No. 		PAGE <b>14 of 14</b>	
SPECIFICATION NO. REVISION.		DATE		TPS A/A 328-001 Sample #90 -40%			
BACK-UP		PURGE GAS		X-Ray Results: REJECT L.O.P			
INTERNAL GAS. ARG		HEAD GAS ARG		O.D. .250		TUBE DATA	
FLOW CFH 5+2		FLOW CFH 8		WALL .035			
PRE-PURGE TIME 2 MIN(MIN)(1)		PRE-PURGE TIME 15 SEC(MIN)		ALLOY			
POST-PURGE TIME 1 MIN(MIN)		POST-PURGE TIME 1 MIN(MIN)		FTG. P/N			
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.							
PROGRAMMER SETTINGS							
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps	
PULSE LOW 5 to 199 Amps							
025		023		021		018	
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec	
007		005		005		009	
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		FINISH SLOPE .1 to 9.9 Sec	
0.1		0.1		0.9		4.0	
HEAD SPEED RPM						3.60	
QUALIFICATION POSITIONS							
<input type="checkbox"/> HORIZONTAL		<input checked="" type="checkbox"/> VERTICAL					
MACHINE E-200T4 S/N 328		WELDERS NAME _____ STAMP _____					
HEAD S/N 1328		RADIOGRAPH ACCEPTANCE _____					
		TENSILE TEST ACCEPTANCE _____					
		REPORT NUMBER _____					
		APPROVALS:					
		MFG. D/821 _____ DATE _____					
		Q.E. D/814 _____ DATE _____					
		ENGR. D/830 _____ DATE _____					
		QUALITY CONTROL _____ DATE _____					
		STAMP					
		VISUAL ACCEPT					
		ELECTRODE (Sketch) A 80° B .015 C 1.329 D .030					

FORM 3916-S-1 REV. 5-73


**ORIGINAL PAGE IS  
OF POOR QUALITY**

WPS No.

FORM 2016 S-1 REV. 5-73

# DATA SHEET 1/4" Decreasing Shielding Gas

## AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

MPP NUMBER MPP-LO-0001		WPS No.		REVISION LETTER		PAGE 14 of 14	
SPECIFICATION NO. REVISION.		DATE TPS A/A 328-001 Sample #92 -70%					
BACK-UP		PURGE GAS		X-Ray Results: Accept		HEAD	
INTERNAL GAS ARG		HEAD GAS ARG		O.D. .250		TUBE DATA	
FLOW CFH 5+2		FLOW CFH 5		WALL .035			
PRE-PURGE TIME 2 MIN(MIN)(1)		PRE-PURGE TIME 15 SEC(MIN)		ALLOY			
POST-PURGE TIME 1 MIN(MIN)		POST-PURGE TIME 1 MIN(MIN)		FTG. P/W			
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.							
PROGRAMMER SETTINGS							
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps	
PULSE LOW 5 to 199 Amps							
025		023		021		018	
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec	
007		005		005		009	
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		FINISH SLOPE .1 to 9.9 Sec	
0.1		0.1		0.9		4.0	
						HEAD SPEED RPM	
						3.60	
QUALIFICATION POSITIONS							
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL							
MACHINE E-200T4 S/N 328							
HEAD S/N 1328							
				ELECTRODE (Sketch) A 80° B .015 C 1.329 D .030			
WELDERS NAME _____ STAMP _____ RADIOGRAPH ACCEPTANCE _____ TENSILE TEST ACCEPTANCE _____ REPORT NUMBER _____ APPROVALS: MFG. D/821 _____ DATE _____ Q.E. D/814 _____ DATE _____ ENGR. D/830 _____ DATE _____ QUALITY CONTROL _____ DATE _____ STAMP _____				REJECT			

FORM 3016-S-1 REV. 5-73




DATA SHEET  
3/4" Increasing Amps

ORIGINAL PAGE IS  
OF POOR QUALITY

AUTOMATIC BUTTWELD  
WELDING PROCEDURE SPECIFICATION (WPS)

WPS No.												
MPP NUMBER MPP-LO-0001	REVISION LETTER <table border="1" style="width:100%; height: 20px;"><tr><td> </td><td> </td><td> </td><td> </td><td> </td><td> </td><td> </td><td> </td><td> </td><td> </td></tr></table>											PAGE 14 of 14
SPECIFICATION NO. REVISION. DATE TPS A/A 328-001 Sample #34 +5%												
X-Ray Results: Accept												
BACK-UP	PURGE GAS	HEAD										
INTERNAL GAS, ARG	HEAD GAS ARG	U.D. 0.750										
FLOW CFH 5+2	FLOW CFH 15+5	WALL 0.109										
PRE-PURGE TIME 2 MIN(MIN)(1) PRE-PURGE TIME 15 SEC(MIN) ALLOY												
POST-PURGE TIME 1 MIN(MIN) POST-PURGE TIME 1 MIN(MIN) FTG. P/N												
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.												
PROGRAMMER SETTINGS												
WELD LEVEL I 5 to 199 Amps	WELD LEVEL II 5 to 199 Amps	WELD LEVEL III 5 to 199 Amps	WELD LEVEL IV 5 to 199 Amps	PULSE LOW 5 to 199 Amps								
078	077	077	076	042								
LEVEL I Time 1-299 Sec	LEVEL II Time 1-299 Sec	LEVEL III Time 1-299 Sec	LEVEL IV Time 1-299 Sec	FINISH SLOPE .1 to 9.9 Sec								
018	017	016	017	9.9								
	PULSE HIGH .1 to 9.9 Sec	PULSE LOW .1 to 9.9 Sec	ROTATION DELAY .1 to 9.9 Sec	HEAD SPEED RPM								
	0.2	0.1	3.6	1.00								
QUALIFICATION POSITIONS												
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL												
MACHINE E-200T4 S/N 328												
HEAD S/N 1328												
WELDERS NAME _____ STAMP _____												
RADIOGRAPH ACCEPTANCE _____												
TENSILE TEST ACCEPTANCE _____												
REPORT NUMBER _____												
APPROVALS:												
MFG. D/821 _____ DATE _____												
Q.E. D/814 _____ DATE _____												
ENGR. D/830 _____ DATE _____												
QUALITY CONTROL _____ DATE _____												
STAMP												
REJ. CONCAVITY & EXCEPTS DROP THRU												



ELECTRODE (Sketch)

A 80°

B .010


C 1.073

D .020

# **DATA SHEET** **3/4" Increasing Amps**

## **AUTOMATIC BUTTWELD** **WELDING PROCEDURE SPECIFICATION (WPS)**

WPS No. \_\_\_\_\_


MPP NUMBER <b>MPP-LO-0001</b>		REVISION LETTER								PAGE <b>14 of 14</b>	
SPECIFICATION NO. REVISION. DATE <b>TPS A/A 328-001</b> Sample <b>#35 +10%</b>											
BACK-UP		PURGE GAS		X-Ray Results: <b>Accept</b>				TUBE DATA			
INTERNAL GAS <b>ARG</b>		HEAD GAS <b>ARG</b>		O.D. <b>0.750</b>							
FLOW CFH <b>5+2</b>		FLOW CFH <b>15+5</b>		WALL <b>0.109</b>							
PRE-PURGE TIME <b>2 MIN(MIN)</b> (1)						PRE-PURGE TIME <b>15 SEC(MIN)</b> ALLOY _____					
POST-PURGE TIME <b>1 MIN(MIN)</b>						POST-PURGE TIME <b>1 MIN(MIN)</b> FTG. P/H _____					
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.											
<b>PROGRAMMER SETTINGS</b>											
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps		PULSE LOW 5 to 199 Amps			
<div style="border: 1px solid black; padding: 5px;">081</div>		<div style="border: 1px solid black; padding: 5px;">080</div>		<div style="border: 1px solid black; padding: 5px;">080</div>		<div style="border: 1px solid black; padding: 5px;">079</div>		<div style="border: 1px solid black; padding: 5px;">042</div>			
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec		FINISH SLOPE .1 to 9.9 Sec			
<div style="border: 1px solid black; padding: 5px;">018</div>		<div style="border: 1px solid black; padding: 5px;">017</div>		<div style="border: 1px solid black; padding: 5px;">016</div>		<div style="border: 1px solid black; padding: 5px;">017</div>		<div style="border: 1px solid black; padding: 5px;">9.9</div>			
		PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM			
		<div style="border: 1px solid black; padding: 5px;">0.2</div>		<div style="border: 1px solid black; padding: 5px;">0.1</div>		<div style="border: 1px solid black; padding: 5px;">3.6</div>		<div style="border: 1px solid black; padding: 5px;">1.00</div>			
<b>QUALIFICATION POSITIONS</b> <input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL											
MACHINE E-200T4 S/N <b>328</b> HEAD S/N <b>1328</b>											
				ELECTRODE (Sketch) A <b>80°</b> B <b>.010</b> C <b>1.073</b> D <b>.020</b>							
WELDERS NAME _____ STAMP _____ RADIOGRAPH ACCEPTANCE _____ TENSILE TEST ACCEPTANCE _____ REPORT NUMBER _____ APPROVALS: MFG. D/821 _____ DATE _____ Q.E. D/814 _____ DATE _____ ENGR. D/830 _____ DATE _____ QUALITY CONTROL _____ DATE _____ STAMP _____ REJ. CONCAVITY & EXCESS DROP TRHU											

DATA SHEET  
3/4" Increasing Amps

ORIGINAL PAGE IS  
OF POOR QUALITY

AUTOMATIC BUTTWELD  
WELDING PROCEDURE SPECIFICATION (WPS)


WPS No.

MPP NUMBER <b>MPP-LO-0001</b>		REVISION LETTER								PAGE 14 of 14											
SPECIFICATION NO. REVISION.		DATE <u>TPS A/A 328-001</u> Sample #36 -4 Amps Below +10% Level																			
BACK-UP		PURGE GAS		X-Ray Results: Accept				HEAD				TUBE DATA									
INTERNAL GAS <u>ARG</u>		HEAD GAS <u>ARG</u>		O.D. <u>0.750</u>																	
FLOW CFH <u>5+2</u>		FLOW CFH <u>15+5</u>		WALL <u>0.105</u>																	
PRE-PURGE TIME <u>2 MIN(MIN)</u> (1)		PRE-PURGE TIME <u>15 SEC(MIN)</u>		ALLOY _____																	
POST-PURGE TIME <u>1 MIN(MIN)</u>		POST-PURGE TIME <u>1 MIN(MIN)</u>		FTG. P/N _____																	
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.																					
PROGRAMMER SETTINGS																					
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps		PULSE LOW 5 to 199 Amps													
<div style="border: 1px solid black; padding: 5px; text-align: center;">077</div>		<div style="border: 1px solid black; padding: 5px; text-align: center;">076</div>		<div style="border: 1px solid black; padding: 5px; text-align: center;">076</div>		<div style="border: 1px solid black; padding: 5px; text-align: center;">075</div>		<div style="border: 1px solid black; padding: 5px; text-align: center;">042</div>													
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec		FINISH SLOPE .1 to 9.9 Sec													
<div style="border: 1px solid black; padding: 5px; text-align: center;">018</div>		<div style="border: 1px solid black; padding: 5px; text-align: center;">017</div>		<div style="border: 1px solid black; padding: 5px; text-align: center;">016</div>		<div style="border: 1px solid black; padding: 5px; text-align: center;">017</div>		<div style="border: 1px solid black; padding: 5px; text-align: center;">9.9</div>													
		PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM													
		<div style="border: 1px solid black; padding: 5px; text-align: center;">0.2</div>		<div style="border: 1px solid black; padding: 5px; text-align: center;">0.1</div>		<div style="border: 1px solid black; padding: 5px; text-align: center;">3.6</div>		<div style="border: 1px solid black; padding: 5px; text-align: center;">1.00</div>													
<b>QUALIFICATION POSITIONS</b> <input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL MACHINE E-200T4 S/N <u>328</u> HEAD S/N <u>1328</u>																					
 <table style="margin-left: 20px;"> <tr><td colspan="2">ELECTRODE (Sketch)</td></tr> <tr><td>A</td><td><u>80°</u></td></tr> <tr><td>B</td><td><u>.010</u></td></tr> <tr><td>C</td><td><u>1.073</u></td></tr> <tr><td>D</td><td><u>.020</u></td></tr> </table>												ELECTRODE (Sketch)		A	<u>80°</u>	B	<u>.010</u>	C	<u>1.073</u>	D	<u>.020</u>
ELECTRODE (Sketch)																					
A	<u>80°</u>																				
B	<u>.010</u>																				
C	<u>1.073</u>																				
D	<u>.020</u>																				
WELDERS NAME _____ STAMP _____ RADIOGRAPH ACCEPTANCE _____ TENSILE TEST ACCEPTANCE _____ REPORT NUMBER _____ APPROVALS: MFG. D/821 _____ DATE _____ Q.E. D/814 _____ DATE _____ ENGR. D/830 _____ DATE _____ QUALITY CONTROL _____ DATE _____ STAMP _____ REJ. SLIGHT CONCAVITY																					

# DATA SHEET 3/4" Increasing Amps

## AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

WPS No.

MPP NUMBER <b>MPP-LO-0001</b>		REVISION LETTER <table border="1" style="width:100%; height: 15px; border-collapse: collapse;"> <tr> <td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> </table>																		PAGE <b>14 of 14</b>	
SPECIFICATION NO. REVISION.    DATE <u>TFS A/A 328-001</u> Sample <u>#37 -6 Amps</u> <div style="text-align: right;">Below +10% Level</div>																					
BACK-UP		PURGE GAS		X-Ray Results: <u>Accept</u>				TUBE DATA													
INTERNAL GAS: <u>ARG</u>		HEAD GAS <u>ARG</u>		O.D. <u>0.750</u>				WALL <u>0.109</u>													
FLOW CFH <u>5+2</u>		FLOW CFH <u>15+5</u>																			
PRE-PURGE TIME <u>2 MIN(MIN)</u> (1) PRE-PURGE TIME <u>15 SEC(MIN)</u> ALLOY _____																					
POST-PURGE TIME <u>1 MIN(MIN)</u> POST-PURGE TIME <u>1 MIN(MIN)</u> FTG. P/N _____ (1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.																					
PROGRAMMER SETTINGS																					
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps		PULSE LOW 5 to 199 Amps													
075		074		074		073		042													
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec		FINISH SLOPE .1 to 9.9 Sec													
018		017		016		017		9.9													
		PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM													
		0.2		0.1		3.6		1.00													
QUALIFICATION POSITIONS <input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL						WELDERS NAME _____ STAMP _____ RADIOGRAPH ACCEPTANCE _____ TENSILE TEST ACCEPTANCE _____ REPORT NUMBER _____															
MACHINE E-200T4 S/N <u>328</u> HEAD S/N <u>1328</u>						APPROVALS: MFG. D/821 _____ DATE _____ Q.E. D/814 _____ DATE _____ ENGR. D/830 _____ DATE _____ QUALITY CONTROL _____ DATE _____ <div style="text-align: right;">STAMP</div>															
 <div style="margin-top: 10px;">         ELECTRODE (Sketch)          A <u>80°</u>          B <u>.010</u>          C <u>1.073</u>          D <u>.020</u> </div>						ACCEPT															

FORM WPS-1 REV 5-73

ORIGINAL PAGE IS  
OF POOR QUALITY



## WPS No.

VISUAL ACCEPT

# DATA SHEET 3/4" Decreasing Amps

## AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

WPS No.


MPP NUMBER MPP-LO-0001		REVISION LETTER								PAGE 14 of 14	
SPECIFICATION NO. REVISION. DATE <u>TPS A/A 328-001</u> Sample #11 -10%											
BACK-UP		PURGE GAS		X-Ray Results: Accept				HEAD			
INTERVAL GAS <u>ARG</u>		HEAD GAS <u>ARG</u>		TUBE DATA							
FLOW CFH <u>5+2</u>		FLOW CFH <u>15+5</u>		O.D. <u>0.750</u>							
PRE-PURGE TIME <u>2 MIN(MIN)</u> (1)		PRE-PURGE TIME <u>15 SEC(MIN)</u>		ALLOY							
POST-PURGE TIME <u>1 MIN(MIN)</u>		POST-PURGE TIME <u>1 MIN(MIN)</u>		FTG. P/W							
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.											
PROGRAMMER SETTINGS											
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps		PULSE LOW 5 to 199 Amps			
067		066		066		065		042			
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec		FINISH SLOPE .1 to 9.9 Sec			
018		017		016		017		9.9			
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM					
0.2		0.1		3.6		1.00					
QUALIFICATION POSITIONS <input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL											
MACHINE E-200T4 S/N <u>328</u> HEAD S/N <u>1328</u>											
				ELECTRODE (Sketch) A <u>80°</u> B <u>.010</u> C <u>1.073</u> D <u>.020</u>							
				WELDERS NAME _____ STAMP _____ RADIOGRAPH ACCEPTANCE _____ TENSILE TEST ACCEPTANCE _____ REPORT NUMBER _____ APPROVALS: MFG. D/821 _____ DATE _____ Q.E. D/814 _____ DATE _____ ENGR. D/830 _____ DATE _____ QUALITY CONTROL _____ DATE _____ VISUAL ACCEPT _____ STAMP _____							

DATA SHEET  
3/4" Decreasing Amps

ORIGINAL PAGE IS  
OF POOR QUALITY

AUTOMATIC BUTTWELD  
WELDING PROCEDURE SPECIFICATION (WPS)

MPP NUMBER MPP-LO-0001		REVISION LETTER								WPS No.		PAGE 14 of 14	
SPECIFICATION NO. REVISION.		DATE TPS A/A 328-001 Sample #12 -15%											
X-Ray Results: Reject LOP													
BACK-UP		PURGE GAS				HEAD		TUBE DATA					
INTERNAL GAS: ARG		HEAD GAS: ARG				O.D. 0.750							
FLOW CFH 5+2		FLOW CFH 15+5				WALL 0.109							
PRE-PURGE TIME 2 MIN(MIN) (1) PRE-PURGE TIME 15 SEC(MIN) ALLOY													
POST-PURGE TIME 1 MIN(MIN) POST-PURGE TIME 1 MIN(MIN) FTG. P/N													
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.													
PROGRAMMER SETTINGS													
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps		PULSE LOW 5 to 199 Amps					
063		062		062		061		042					
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec		FINISH SLOPE .1 to 9.9 Sec					
018		017		016		017		9.9					
		PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM					
		0.2		0.1		3.6		1.00					
QUALIFICATION POSITIONS													
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL													
MACHINE E-200T4 S/N 328 HEAD S/N 1328													
WELDERS NAME _____ STAMP _____ RADIOGRAPH ACCEPTANCE _____ TENSILE TEST ACCEPTANCE _____ REPORT NUMBER _____													
APPROVALS: MFG. D/821 _____ DATE _____ Q.E. D/814 _____ DATE _____ ENGR. D/830 _____ DATE _____ QUALITY CONTROL _____ DATE _____ STAMP _____													
VISUAL REJECT LOP													



ELECTRODE (Sketch)	
A	80°
B	.010
C	1.073
D	.020

FORM WPS-1 REV 5-73

# AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

MPP NUMBER <b>MPP-LO-0001</b>		<div style="display: flex; justify-content: space-between;"> <div> REVISION LETTER  <div style="border: 1px solid black; width: 100px; height: 15px; margin-top: 5px;"></div> </div> <div> PAGE  14 of 14 </div> </div>									
SPECIFICATION NO. REVISION.		DATE <u>TPS A/A 328-001</u> Sample #13 -20%									
PURGE GAS		X-Ray Results: Reject LOP									
BACK-UP		HEAD				TUBE DATA					
INTERNAL GAS: <u>ARG</u>		HEAD GAS <u>ARG</u>				O.D. <u>0.750</u>					
FLOW CFH <u>5+2</u>		FLOW CFH <u>15+5</u>				WALL <u>0.109</u>					
PRE-PURGE TIME <u>2 MIN(MIN)</u> (1)		PRE-PURGE TIME <u>15 SEC(MIN)</u>				ALLOY <u></u>					
POST-PURGE TIME <u>1 MIN(MIN)</u>		POST-PURGE TIME <u>1 MIN(MIN)</u>				FTG. P/N <u></u>					
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.											
PROGRAMMER SETTINGS											
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps		PULSE LOW 5 to 199 Amps			
059		058		058		058		042			
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec		FINISH SLOPE .1 to 9.9 Sec			
018		017		016		017		9.9			
		PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM			
		0.2		0.1		3.6		1.00			
<div style="display: flex; justify-content: space-between;"> <div> QUALIFICATION POSITIONS  <div style="display: flex; align-items: center; margin-top: 10px;"> <input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL </div> </div> <div> WELDERS NAME <u></u> STAMP <u></u>  RADIOGRAPH ACCEPTANCE <u></u>  TENSILE TEST ACCEPTANCE <u></u>  REPORT NUMBER <u></u>  APPROVALS:  MFG. D/821 <u></u> DATE <u></u>  Q.E. D/814 <u></u> DATE <u></u>  ENGR. D/830 <u></u> DATE <u></u>  QUALITY CONTROL <u></u> DATE <u></u> </div> </div>											
<div style="display: flex; justify-content: space-between;"> <div> MACHINE E-200T4 S/N <u>328</u>  HEAD S/N <u>1328</u> </div> <div> <div style="display: flex; align-items: center;"> <div style="margin-left: 10px;"> ELECTRODE (Sketch)  A <u>80°</u>  B <u>.010</u>  C <u>1.073</u>  D <u>.020</u> </div> </div> </div> </div>											
VISUAL REJECT LOP <span style="float: right;">STAMP</span>											



**ORIGINAL PAGE IS  
OF POOR QUALITY**

## WPS No.


FORM 21A.C.1 REV 5.73

# DATA SHEET 3/4" Decreasing Amps

## AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

WPS No.

MPP NUMBER <b>MPP-LO-0001</b>		REVISION LETTER				PAGE 14 of 14
SPECIFICATION NO. REVISION.		DATE				
		TPS A/A 328-001 Sample #15				
X-Ray Results: Reject LOP						
BACK-UP		PURGE GAS		HEAD		TUBE DATA
INTERNAL GAS: ARG		HEAD GAS: ARG		O.D.		0.750
FLOW CFH 5+2		FLOW CFH 15+5		WALL		0.109
PRE-PURGE TIME 2 MIN(MIN)		(1) PRE-PURGE TIME 15 SEC(MIN)		ALLOY		
POST-PURGE TIME 1 MIN(MIN)		POST-PURGE TIME 1 MIN(MIN)		FTG. P/N		
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.						
PROGRAMMER SETTINGS						
WELD LEVEL I 5 to 199 Amps	WELD LEVEL II 5 to 199 Amps	WELD LEVEL III 5 to 199 Amps	WELD LEVEL IV 5 to 199 Amps	PULSE LOW 5 to 199 Amps		
063	068	062	062	042		
LEVEL I Time 1-299 Sec	LEVEL II Time 1-299 Sec	LEVEL III Time 1-299 Sec	LEVEL IV Time 1-299 Sec	FINISH SLOPE .1 to 9.9 Sec		
018	017	016	017	9.9		
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM
0.2		0.1		3.6		1.00
<b>QUALIFICATION POSITIONS</b> <input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL						
MACHINE E-200T4 S/N <u>328</u> HEAD S/N <u>1328</u>						
WELDERS NAME _____ STAMP _____ RADIOGRAPH ACCEPTANCE _____ TENSILE TEST ACCEPTANCE _____ REPORT NUMBER _____						
APPROVALS: MFG. D/821 _____ DATE _____ Q.E. D/814 _____ DATE _____ ENGR. D/830 _____ DATE _____ QUALITY CONTROL _____ DATE _____ STAMP _____						
VISUAL REJECT LOP						



ELECTRODE (Sketch)	
A	80°
B	.010
C	1.073
D	.020


FORM 7016.5-1 REV 5-73

DATA SHEET  
3/4" Decreasing Amps

ORIGINAL PAGE IS  
OF POOR QUALITY

AUTOMATIC BUTTWELD  
WELDING PROCEDURE SPECIFICATION (WPS)

WPS No.


MPP NUMBER <b>MPP-LO-0001</b>		REVISION LETTER								PAGE <b>14 of 14</b>	
SPECIFICATION NO. REVISION. DATE <b>TPS A/A 328-001 Sample #16</b>											
PURGE GAS				X-Ray Results: <b>Reject LOP</b>							
BACK-UP		HEAD		TUBE DATA							
INTERNAL GAS <u>ARG</u>		HEAD GAS <u>ARG</u>		O.D. <u>0.750</u>							
FLOW CFH <u>5+2</u>		FLOW CFH <u>15+5</u>		WALL <u>          </u>							
PRE-PURGE TIME <u>2 MIN(MIN)</u> (1)				PRE-PURGE TIME <u>15 SEC(MIN)</u>				ALLOY <u>          </u>			
POST-PURGE TIME <u>1 MIN(MIN)</u>				POST-PURGE TIME <u>1 MIN(MIN)</u>				FTG. P/N <u>          </u>			
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.											
PROGRAMMER SETTINGS											
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps		PULSE LOW 5 to 199 Amps			
065		064		064		064		042			
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec		FINISH SLOPE .1 to 9.9 Sec			
018		017		016		017		9.9			
PULSE HIGH .1 to 9.9 Sec				PULSE LOW .1 to 9.9 Sec				ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM	
0.2				0.1				3.6		1.00	
QUALIFICATION POSITIONS											
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL						WELDERS NAME <u>                                </u> STAMP <u>                                </u>					
MACHINE E-200T4 S/N <u>328</u>						RADIOGRAPH ACCEPTANCE <u>                                </u>					
HEAD S/N <u>1328</u>						TENSILE TEST ACCEPTANCE <u>                                </u>					
						REPORT NUMBER <u>                                </u>					
 <div style="margin-left: 10px;"> ELECTRODE (Sketch)  A <u>80°</u>  B <u>.010</u>  C <u>1.073</u>  D <u>.020</u> </div>						APPROVALS:					
						MFG. D/821 <u>                                </u> DATE <u>                                </u>					
						Q.E. D/814 <u>                                </u> DATE <u>                                </u>					
						ENGR. D/830 <u>                                </u> DATE <u>                                </u>					
						QUALITY CONTROL <u>                                </u> DATE <u>                                </u>					
VISUAL ACCEPT						STAMP					

FORM 216.5, REV 5.73

# DATA SHEET 3/4" Increasing RPM

## AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

WPS No.

MPP NUMBER MPP-LO-0001		REVISION LETTER								PAGE 14 of 14	
SPECIFICATION NO.		REVISION.		DATE		TPS A/A 328-001		Sample #46 +5%			
X-Ray Results: Accept											
BACK-UP		PURGE GAS		HEAD		TUBE DATA					
INTERNAL GAS: ARG		HEAD GAS: ARG		O.D.		0.750					
FLOW CFH 5+2		FLOW CFH 15+5		WALL		0.109					
PRE-PURGE TIME 2 MIN(MIN)(1)				PRE-PURGE TIME 15 SEC(MIN)				ALLOY			
POST-PURGE TIME 1 MIN(MIN)				POST-PURGE TIME 1 MIN(MIN)				FTG. P/N			
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.											
PROGRAMMER SETTINGS											
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps		PULSE LOW 5 to 199 Amps			
074		073		073		072		042			
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec		FINISH SLOPE .1 to 9.9 Sec			
018		017		016		017		9.9			
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM					
0.2		0.1		3.6		1.05					
QUALIFICATION POSITIONS											
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL											
MACHINE E-200T4 S/N 328 HEAD S/N 1328											
											
ELECTRODE (Sketch) A 80° B .010 C 1.073 D .020											
WELDERS NAME _____ STAMP _____ RADIOGRAPH ACCEPTANCE _____ TENSILE TEST ACCEPTANCE _____ REPORT NUMBER _____ APPROVALS: MFG. D/821 _____ DATE _____ Q.E. D/814 _____ DATE _____ ENGR. D/830 _____ DATE _____ QUALITY CONTROL _____ DATE _____ VISUAL ACCEPT _____ STAMP _____											

FORM MISC.1 REV. 4.73

DATA SHEET  
3/4" Increasing RPM

ORIGINAL PAGE IS  
OF POOR QUALITY

AUTOMATIC BUTTWELD  
WELDING PROCEDURE SPECIFICATION (WPS)

WPS No.

MPP NUMBER <b>MPP-LO-0001</b>		REVISION LETTER								PAGE <b>14 of 14</b>	
SPECIFICATION NO. REVISION.		DATE <b>TPS A/A 328-001</b> Sample #47 +10%									
X-Ray Results: <b>Accept</b>											
BACK-UP		PURGE GAS				HEAD		TUBE DATA			
INTERNAL GAS: <b>ARG</b>		HEAD GAS: <b>ARG</b>				O.D. <b>0.750</b>					
FLOW CFH <b>5+2</b>		FLOW CFH <b>15+5</b>				WALL <b>0.109</b>					
PRE-PURGE TIME <b>2 MIN(MIN)</b> (1)						PRE-PURGE TIME <b>15 SEC(MIN)</b>		ALLOY			
POST-PURGE TIME <b>1 MIN(MIN)</b>						POST-PURGE TIME <b>1 MIN(MIN)</b>		FTG. P/N			
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.											
PROGRAMMER SETTINGS											
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps		PULSE LOW 5 to 199 Amps			
074		073		073		072		042			
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec		FINISH SLOPE .1 to 9.9 Sec			
018		017		016		017		9.9			
				PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM	
				0.2		0.1		3.6		1.10	
QUALIFICATION POSITIONS											
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL											
MACHINE E-200T4 S/N <b>328</b> HEAD S/N <b>1328</b>											
				ELECTRODE (Sketch) A <b>80°</b> B <b>.010</b> C <b>1.073</b> D <b>.020</b>							
				WELDERS NAME _____ STAMP _____							
				RADIOGRAPH ACCEPTANCE _____							
				TENSILE TEST ACCEPTANCE _____							
REPORT NUMBER _____											
APPROVALS:											
MFG. D/821 _____ DATE _____											
Q.E. D/814 _____ DATE _____											
ENGR. D/830 _____ DATE _____											
QUALITY CONTROL _____ DATE _____											
VISUAL ACCEPT											

FORM WPS.1 REV 5.73

# DATA SHEET 3/4" Increasing RPM

## AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

WPS No.

MPP NUMBER MPP-L0-0001		REVISION LETTER										PAGE 14 of 14
SPECIFICATION NO. REVISION		DATE TPS A/A 328-001 Sample #48 +15%										
BACK-UP		PURGE GAS					X-Ray Results: Accept					
INTERNAL GAS ARG		HEAD GAS ARG					TUBE DATA					
FLOW CFH 5+2		FLOW CFH 15+5					O.D. 0.750					
PRE-PURGE TIME 2 MIN(MIN)		PRE-PURGE TIME 15 SEC(MIN)					ALLOY					
POST-PURGE TIME 1 MIN(MIN)		POST-PURGE TIME 1 MIN(MIN)					FTG. P/N					
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.												
PROGRAMMER SETTINGS												
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps		PULSE LOW 5 to 199 Amps				
074		073		073		072		042				
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec		FINISH SLOPE .1 to 9.9 Sec				
018		017		016		017		9.9				
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM						
0.2		0.1		3.6		1.15						
QUALIFICATION POSITIONS												
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL												
MACHINE E-200T4 S/N 328 HEAD S/N 1328												
WELDERS NAME _____ STAMP _____ RADIOGRAPH ACCEPTANCE _____ TENSILE TEST ACCEPTANCE _____ REPORT NUMBER _____												
APPROVALS: MFG. D/821 _____ DATE _____ Q.E. D/814 _____ DATE _____ ENGR. D/830 _____ DATE _____ QUALITY CONTROL _____ DATE _____ VISUAL ACCEPT _____ STAMP _____												
				ELECTRODE (Sketch) A 80° B .010 C 1.073 D .020								


DATA SHEET  
3/4" Increasing RPM

ORIGINAL PAGE IS  
OF POOR QUALITY

AUTOMATIC BUTTWELD  
WELDING PROCEDURE SPECIFICATION (WPS)

WPS No.

MPP NUMBER MPP-LO-0001		REVISION LETTER										PAGE 14 of 14	
SPECIFICATION NO. REVISION.		DATE TPS A/A 328-001 Sample #49 +20%											
X-Ray Results: Accept													
PURGE GAS				BACK-UP				HEAD				TUBE DATA	
INTERNAL GAS ARG				HEAD GAS ARG				O.D. 0.750					
FLOW CFH 5+2				FLOW CFH 15+5				WALL 0.109					
PRE-PURGE TIME 2 MIN(MIN)(1)				PRE-PURGE TIME 15 SEC(MIN)				ALLOY					
POST-PURGE TIME 1 MIN(MIN)				POST-PURGE TIME 1 MIN(MIN)				FTG. P/N					
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.													
PROGRAMMER SETTINGS													
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps		PULSE LOW 5 to 199 Amps					
074		073		073		072		042					
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec		FINISH SLOPE .1 to 9.9 Sec					
018		017		016		017		9.9					
				PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM			
				0.2		0.1		3.6		1.20			
QUALIFICATION POSITIONS													
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL													
MACHINE E-200T4 S/N 328 HEAD S/N 1328													
WELDERS NAME _____ STAMP _____ RADIOGRAPH ACCEPTANCE _____ TENSILE TEST ACCEPTANCE _____ REPORT NUMBER _____													
APPROVALS: MFG. D/821 _____ DATE _____ Q.E. D/814 _____ DATE _____ ENGR. D/830 _____ DATE _____ QUALITY CONTROL _____ DATE _____ STAMP _____													
VISUAL ACCEPT													




ELECTRODE (Sketch)	
A	80°
B	.010
C	1.073
D	.020

FORM 1016-S-1 REV. 5-73

# DATA SHEET 3/4" Increasing RPM

## AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

WPS No.	
MPP NUMBER MPP-L0-0001	REVISION LETTER
PAGE 14 of 14	
SPECIFICATION NO. REVISION. DATE TPS A/A 328-001 Sample #50 +25%	
X-Ray Results: Accept	
BACK-UP	PURGE GAS
INTERNAL GAS ARG	HEAD GAS ARG
FLOW CFH 5+2	FLOW CFH 15+5
PRE-PURGE TIME 2 MIN(MIN)	PRE-PURGE TIME 15 SEC(MIN)
POST-PURGE TIME 1 MIN(MIN)	POST-PURGE TIME 1 MIN(MIN)
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.	
PROGRAMMER SETTINGS	
WELD LEVEL I 5 to 199 Amps	WELD LEVEL II 5 to 199 Amps
WELD LEVEL III 5 to 199 Amps	WELD LEVEL IV 5 to 199 Amps
PULSE LOW 5 to 199 Amps	
074	073
073	072
042	
LEVEL I Time 1-299 Sec	LEVEL II Time 1-299 Sec
LEVEL III Time 1-299 Sec	LEVEL IV Time 1-299 Sec
FINISH SLOPE .1 to 9.9 Sec	
018	017
016	017
9.9	
PULSE HIGH .1 to 9.9 Sec	PULSE LOW .1 to 9.9 Sec
ROTATION DELAY .1 to 9.9 Sec	HEAD SPEED RPM
0.2	0.1
3.6	1.25
QUALIFICATION POSITIONS	
<input type="checkbox"/> HORIZONTAL	<input checked="" type="checkbox"/> VERTICAL
MACHINE E-200T4 S/N 328	WELDERS NAME _____ STAMP _____
HEAD S/N 1328	RADIOGRAPH ACCEPTANCE _____
	TENSILE TEST ACCEPTANCE _____
	REPORT NUMBER _____
	APPROVALS:
	MFG. D/821 _____ DATE _____
	Q.E. D/814 _____ DATE _____
	ENGR. D/830 _____ DATE _____
	QUALITY CONTROL _____ DATE _____
	STAMP
VISUAL ACCEPT	




ELECTRODE (Sketch)	
A	80°
B	.010
C	1.073
D	.020



DATA SHEET  
3/4" Increasing RPM

ORIGINAL PAGE IS  
OF POOR QUALITY

AUTOMATIC BUTTWELD  
WELDING PROCEDURE SPECIFICATION (WPS)


WPS No.																					
MPP NUMBER MPP-LO-0001	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td colspan="10" style="text-align: center;">REVISION LETTER</td> </tr> <tr> <td> </td><td> </td><td> </td><td> </td><td> </td><td> </td><td> </td><td> </td><td> </td><td> </td> </tr> </table>	REVISION LETTER																			
REVISION LETTER																					
PAGE 14 of 14																					
SPECIFICATION NO. REVISION. DATE TPS A/A 328-001 Sample #51 +30%																					
X-Ray Results: Accept																					
BACK-UP	PURGE GAS																				
HEAD	TUBE DATA																				
INTERNAL GAS. ARG	HEAD GAS ARG																				
O.D. 0.750																					
FLOW CFH 5+2	FLOW CFH 15+5																				
WALL 0.109																					
PRE-PURGE TIME 2 MIN(MIN) (1) PRE-PURGE TIME 15 SEC(MIN) ALLOY																					
POST-PURGE TIME 1 MIN(MIN) POST-PURGE TIME 1 MIN(MIN) FTG. P/N																					
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.																					
PROGRAMMER SETTINGS																					
WELD LEVEL I 5 to 199 Amps	WELD LEVEL II 5 to 199 Amps																				
WELD LEVEL III 5 to 199 Amps	WELD LEVEL IV 5 to 199 Amps																				
PULSE LOW 5 to 199 Amps																					
074	073																				
073	072																				
042																					
LEVEL I Time 1-299 Sec	LEVEL II Time 1-299 Sec																				
LEVEL III Time 1-299 Sec	LEVEL IV Time 1-299 Sec																				
FINISH SLOPE .1 to 9.9 Sec																					
018	017																				
016	017																				
9.9																					
PULSE HIGH .1 to 9.9 Sec	PULSE LOW .1 to 9.9 Sec																				
ROTATION DELAY .1 to 9.9 Sec	HEAD SPEED RPM																				
0.2	0.1																				
3.6	1.30																				
QUALIFICATION POSITIONS <input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL																					
MACHINE E-200T4 S/N 328 HEAD S/N 1328																					
WELDERS NAME _____ STAMP _____ RADIOGRAPH ACCEPTANCE _____ TENSILE TEST ACCEPTANCE _____ REPORT NUMBER _____																					
APPROVALS: MFG. D/821 _____ DATE _____ Q.E. D/814 _____ DATE _____ ENGR. D/830 _____ DATE _____ QUALITY CONTROL _____ DATE _____ STAMP _____																					
VISUAL ACCEPT																					
<div style="display: flex; align-items: center;">  <div style="margin-left: 10px;">           ELECTRODE (Sketch)            A 80°            B .010            C 1.073            D .020         </div> </div>																					

FORM 311A.1 REV 5-73

# DATA SHEET 3/4" Increasing RPM

## AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

WPS No.

MPP NUMBER MPP-LO-0001		REVISION LETTER				PAGE 14 of 14
SPECIFICATION NO. REVISION. DATE TPS A/A 328-001 Sample #52 +35%						
BACK-UP		PURGE GAS		X-Ray Results: Accept		
INTERNAL GAS ARG		HEAD GAS ARG		O.D. 0.750		
FLOW CFH 5+2		FLOW CFH 15+5		WALL 0.109		
PRE-PURGE TIME 2 MIN(MIN)(1) PRE-PURGE TIME 15 SEC(MIN) ALLOY						
POST-PURGE TIME 1 MIN(MIN) POST-PURGE TIME 1 MIN(MIN) FTG. P/N						
(1) Add 1 min (min) for each additional ft. or line between the gas inlet and the joint to be welded.						
PROGRAMMER SETTINGS						
WELD LEVEL I 5 to 199 Amps	WELD LEVEL II 5 to 199 Amps	WELD LEVEL III 5 to 199 Amps	WELD LEVEL IV 5 to 199 Amps	PULSE LOW 5 to 199 Amps		
074	073	073	072	042		
LEVEL I Time 1-299 Sec	LEVEL II Time 1-299 Sec	LEVEL III Time 1-299 Sec	LEVEL IV Time 1-299 Sec	FINISH SLOPE .1 to 9.9 Sec		
018	017	016	017	9.9		
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM
0.2		0.1		3.6		1.35
QUALIFICATION POSITIONS				WELDERS NAME _____ STAMP _____		
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL				RADIOGRAPH ACCEPTANCE _____		
MACHINE E-200T4 S/N 328				TENSILE TEST ACCEPTANCE _____		
HEAD S/N 1328				REPORT NUMBER _____		
				APPROVALS:		
ELECTRODE (Sketch)				MFG. D/821 _____ DATE _____		
A 80°				Q.E. D/814 _____ DATE _____		
B .010				ENGR. D/830 _____ DATE _____		
C 1.073				QUALITY CONTROL _____ DATE _____		
D .020				STAMP _____		


FORM 3000-1 REV 5.71

ORIGINAL PAGE IS  
OF POOR QUALITY

DATA SHEET  
3/4" Increasing RPM

AUTOMATIC BUTTWELD  
WELDING PROCEDURE SPECIFICATION (WPS)

WPS No.

MPP NUMBER MPP-LO-0001		REVISION LETTER										PAGE 14 of 14			
SPECIFICATION NO. REVISION.		DATE												TPS A/A 328-001 Sample #53 +40%	
BACK-UP		PURGE GAS				X-Ray Results: Accept				HEAD				TUBE DATA	
INTERNAL GAS- ARG		HEAD GAS ARG				O.D. 0.750									
FLOW CFH 5+2		FLOW CFH 15+5				WALL 0.109									
PRE-PURGE TIME 2 MIN(MIN)		(1) PRE-PURGE TIME 15 SEC(MIN)				ALLOY									
POST-PURGE TIME 1 MIN(MIN)		POST-PURGE TIME 1 MIN(MIN)				FTG. P/N									
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.															
PROGRAMMER SETTINGS															
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps		PULSE LOW 5 to 199 Amps							
074		073		073		072		042							
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec		FINISH SLOPE .1 to 9.9 Sec							
018		017		016		017		9.9							
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM									
0.2		0.1		3.6		1.40									
QUALIFICATION POSITIONS															
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL															
WELDERS NAME _____ STAMP _____															
RADIOGRAPH ACCEPTANCE _____															
TENSILE TEST ACCEPTANCE _____															
REPORT NUMBER _____															
APPROVALS:															
MFG. D/821 _____ DATE _____															
Q.E. D/814 _____ DATE _____															
ENGR. D/830 _____ DATE _____															
QUALITY CONTROL _____ DATE _____															
STAMP _____															
REJECT LOP															
		ELECTRODE (Sketch)													
		A 80°													
		B .010													
		C 1.073													
		D .020													

FORM WPS-1 REV. 5-73

# DATA SHEET 3/4" Increasing RPM

## AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

MPP NUMBER <b>MPP-LO-0001</b>		REVISION LETTER										WPS No.		PAGE 14 of 14	
SPECIFICATION NO.		REVISION.		DATE		TPS A/A 328-001 Sample #54 +33%									
BACK-UP		PURGE GAS		X-Ray Results: Accept											
INTERNAL GAS. ARG		HEAD		TUBE DATA											
FLOW CFH 5+2		HEAD GAS ARG		O.D. 0.750											
FLOW CFH 15+5		WALL 0.109													
PRE-PURGE TIME 2 MIN(MIN)		(1) PRE-PURGE TIME 15 SEC(MIN)		ALLOY											
POST-PURGE TIME 1 MIN(MIN)		POST-PURGE TIME 1 MIN(MIN)		FTG. P/N											
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.															
PROGRAMMER SETTINGS															
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps		PULSE LOW 5 to 199 Amps							
074		073		073		072		042							
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec		FINISH SLOPE .1 to 9.9 Sec							
018		017		016		017		9.9							
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM									
0.2		0.1		3.6		1.33									
QUALIFICATION POSITIONS															
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL															
WELDERS NAME _____ STAMP _____															
RADIOGRAPH ACCEPTANCE _____															
TENSILE TEST ACCEPTANCE _____															
REPORT NUMBER _____															
APPROVALS:															
MFG. D/821 _____ DATE _____															
Q.E. D/814 _____ DATE _____															
ENGR. D/830 _____ DATE _____															
QUALITY CONTROL _____ DATE _____															
STAMP _____															
REJECT LOP															
		ELECTRODE (Sketch) A 80° B .010 C 1.073 D .020 FTG.													

FORM WPS-1 REV 5-73


DATA SHEET  
3/4" Increasing RPM

ORIGINAL PAGE IS  
OF POOR QUALITY

AUTOMATIC BUTTWELD  
WELDING PROCEDURE SPECIFICATION (WPS)

WPS No.

MPP NUMBER MPP-LO-0001		REVISION LETTER										PAGE 14 of 14	
SPECIFICATION NO.		REVISION.		DATE		TPS A/A 328-001 Sample #55 +29%							
X-Ray Results: Accept													
BACK-UP		PURGE GAS				HEAD		TUBE DATA					
INTERNAL GAS. ARG		HEAD GAS ARG				O.D.		0.750					
FLOW CFH 5+2		FLOW CFH 15+5				WALL		0.109					
PRE-PURGE TIME 2 MIN(MIN)(1)						PRE-PURGE TIME 15 SEC(MIN) ALLOY							
POST-PURGE TIME 1 MIN(MIN)						POST-PURGE TIME 1 MIN(MIN) FTG. P/N							
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.													
PROGRAMMER SETTINGS													
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps		PULSE LOW 5 to 199 Amps					
074		073		073		072		042					
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec		FINISH SLOPE .1 to 9.9 Sec					
018		017		016		017		9.9					
PULSE HIGH .1 to 9.9 Sec				PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM					
0.2				0.1		3.6		1.29					
<b>QUALIFICATION POSITIONS</b> <input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL													
MACHINE E-200T4 S/N 328 HEAD S/N 1328													
WELDERS NAME _____ STAMP _____ RADIOGRAPH ACCEPTANCE _____ TENSILE TEST ACCEPTANCE _____ REPORT NUMBER _____													
<b>APPROVALS:</b> MFG. D/821 _____ DATE _____ Q.E. D/814 _____ DATE _____ ENGR. D/830 _____ DATE _____ QUALITY CONTROL _____ DATE _____ STAMP _____													
ACCEPT													



ELECTRODE (Sketch)	
A	80°
B	.010
C	1.073
D	.020

FORM 1016.5-1 REV. 5-73

# DATA SHEET 3/4" Decreasing RPM

## AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

WPS No.


MPP NUMBER MPP-LO-0001		REVISION LETTER										PAGE 14 of 14	
SPECIFICATION NO.		REVISION.		DATE		TPS A/A 328-001 Sample #56 -5%							
BACK-UP		PURGE GAS		X-Ray Results: Accept				TUBE DATA					
INTERVAL GAS: ARG		HEAD GAS: ARG		O.D. 0.750									
FLOW CFH 5+2		FLOW CFH 15+5		WALL 0.109									
PRE-PURGE TIME 2 MIN(MIN)		(1) PRE-PURGE TIME 15 SEC(MIN)		ALLOY									
POST-PURGE TIME 1 MIN(MIN)		POST-PURGE TIME 1 MIN(MIN)		FTG. P/N									
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.													
PROGRAMMER SETTINGS													
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps		PULSE LOW 5 to 199 Amps					
074		073		073		072		042					
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec		FINISH SLOPE .1 to 9.9 Sec					
018		017		016		017		9.9					
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM							
0.2		0.1		3.6		0.95							
QUALIFICATION POSITIONS													
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL													
MACHINE E-200T4 S/N 328 HEAD S/N 1328													
WELDERS NAME _____ STAMP _____ RADIOGRAPH ACCEPTANCE _____ TENSILE TEST ACCEPTANCE _____ REPORT NUMBER _____ APPROVALS: MFG. D/821 _____ DATE _____ Q.E. D/814 _____ DATE _____ ENGR. D/830 _____ DATE _____ QUALITY CONTROL _____ DATE _____ STAMP _____ REJ. LOW CONCAVITY													
				ELECTRODE (Sketch) A 80° B .010 C 1.073 D .020									

FORM 3016-1 REV 6-73

ORIGINAL PAGE IS  
OF POOR QUALITY

DATA SHEET  
3/4" Decreasing RPM

AUTOMATIC BUTTWELD  
WELDING PROCEDURE SPECIFICATION (WPS)

WPS No.			
MPP NUMBER MPP-LO-0001	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: center;">REVISION LETTER</td> </tr> <tr> <td style="text-align: center;">PAGE 14 of 14</td> </tr> </table>	REVISION LETTER	PAGE 14 of 14
REVISION LETTER			
PAGE 14 of 14			
SPECIFICATION NO. REVISION. DATE TPS A/A 328-001 Sample #57 -10%			
X-Ray Results: Reject L.O.P.			
BACK-UP	PURGE GAS		
INTERNAL GAS ARG	HEAD GAS ARG		
FLOW CFH 5+2	HEAD TUBE DATA		
PRE-PURGE TIME 2 MIN(MIN)(1)	O.D. 0.750		
PRE-PURGE TIME 15 SEC(MIN)	WALL 0.109		
ALLOY			
POST-PURGE TIME 1 MIN(MIN) POST-PURGE TIME 1 MIN(MIN) FTG. P/W (1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.			
PROGRAMMER SETTINGS			
WELD LEVEL I 5 to 199 Amps	WELD LEVEL II 5 to 199 Amps		
WELD LEVEL III 5 to 199 Amps	WELD LEVEL IV 5 to 199 Amps		
PULSE LOW 5 to 199 Amps			
074	073		
073	072		
042			
LEVEL I Time 1-299 Sec	LEVEL II Time 1-299 Sec		
LEVEL III Time 1-299 Sec	LEVEL IV Time 1-299 Sec		
FINISH SLOPE .1 to 9.9 Sec			
018	017		
016	017		
9.9			
PULSE HIGH .1 to 9.9 Sec	PULSE LOW .1 to 9.9 Sec		
ROTATION DELAY .1 to 9.9 Sec	HEAD SPEED RPM		
0.2	0.1		
3.6	0.90		
QUALIFICATION POSITIONS			
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL			
MACHINE E-200T4 S/N 328 HEAD S/N 1328			
WELDERS NAME _____ STAMP _____ RADIOGRAPH ACCEPTANCE _____ TENSILE TEST ACCEPTANCE _____ REPORT NUMBER _____			
APPROVALS: MFG. D/821 _____ DATE _____ Q.E. D/814 _____ DATE _____ ENGR. D/830 _____ DATE _____ QUALITY CONTROL _____ DATE _____ STAMP _____ REJECT CONCAVITY			
<div style="display: flex; align-items: center;">  <div style="margin-left: 10px;">           ELECTRODE (Sketch)            A 80°            B .010            C 1.073            D .020         </div> </div>			

FORM WIA.5.1 REV 5-73

# DATA SHEET 3/4" Decreasing RPM

## AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

MPP NUMBER <b>MPP-LO-0001</b>		REVISION LETTER 		WPS No. 		PAGE 14 of 14	
SPECIFICATION NO. REVISION.		DATE		TPS A/A 328-001 Sample #58			
BACK-UP		PURGE GAS		X-Ray Results: Accept			
INTERNAL GAS: ARG		HEAD GAS ARG		TUBE DATA			
FLOW CFH 5+2		FLOW CFH 15+5		O.D. 0.750			
PRE-PURGE TIME 2 MIN(MIN)		PRE-PURGE TIME 15 SEC(MIN)		ALLOY			
POST-PURGE TIME 1 MIN(MIN)		POST-PURGE TIME 1 MIN(MIN)		FTG. P/N			
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.							
PROGRAMMER SETTINGS							
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps	
PULSE LOW 5 to 199 Amps							
074		073		073		072	
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec	
018		017		016		017	
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		FINISH SLOPE .1 to 9.9 Sec	
0.2		0.1		3.6		9.9	
						HEAD SPEED RPM	
						0.97	
QUALIFICATION POSITIONS							
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL							
MACHINE E-200T4 S/N 328 HEAD S/N 1328							
				ELECTRODE (Sketch) A 80° B .010 C 1.073 D .020			
WELDERS NAME _____ STAMP _____ RADIOGRAPH ACCEPTANCE _____ TENSILE TEST ACCEPTANCE _____ REPORT NUMBER _____ APPROVALS: MFG. D/821 _____ DATE _____ Q.E. D/814 _____ DATE _____ ENGR. D/830 _____ DATE _____ QUALITY CONTROL _____ DATE _____ STAMP _____ REJECT CONCAVITY _____							

FORM 316.1 REV 5-73



DATA SHEET  
3/4" Decreasing RPM

ORIGINAL PAGE IS  
OF POOR QUALITY

AUTOMATIC BUTT WELD  
WELDING PROCEDURE SPECIFICATION (WPS)

WPS No.

MPP NUMBER MPP-L0-0001	REVISION LETTER 	PAGE 14 of 14
---------------------------	---------------------	------------------

SPECIFICATION NO. REVISION. DATE TPS A/A 328-001 Sample #59 -1%

X-Ray Results: Accept

BACK-UP	PURGE GAS	HEAD	TUBE DATA
INTERNAL GAS <u>ARG</u>	HEAD GAS <u>ARG</u>	O.D. <u>0.750</u>	
FLOW CFH <u>5+2</u>	FLOW CFH <u>15+5</u>	WALL <u>0.109</u>	
PRE-PURGE TIME <u>2 MIN(MIN)</u> (1) PRE-PURGE TIME <u>15 SEC(MIN)</u>		ALLOY <u> </u>	
POST-PURGE TIME <u>1 MIN(MIN)</u>		POST-PURGE TIME <u>1 MIN(MIN)</u> FTG. P/N <u> </u>	
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.			

PROGRAMMER SETTINGS

WELD LEVEL I 5 to 199 Amps	WELD LEVEL II 5 to 199 Amps	WELD LEVEL III 5 to 199 Amps	WELD LEVEL IV 5 to 199 Amps	PULSE LOW 5 to 199 Amps
074	073	073	072	042
LEVEL I Time 1-299 Sec	LEVEL II Time 1-299 Sec	LEVEL III Time 1-299 Sec	LEVEL IV Time 1-299 Sec	FINISH SLOPE .1 to 9.9 Sec
018	017	016	017	9.9
	PULSE HIGH .1 to 9.9 Sec	PULSE LOW .1 to 9.9 Sec	ROTATION DELAY .1 to 9.9 Sec	HEAD SPEED RPM
	0.2	0.1	3.60	0.99

**QUALIFICATION POSITIONS**

☐ HORIZONTAL ☒ VERTICAL

MACHINE E-200T4 S/N 328  
HEAD S/N 1328

ELECTRODE (Sketch)

A 80°

B .010

C 1.073

D .020

WELDERS NAME   STAMP  

RADIOGRAPH ACCEPTANCE  

TENSILE TEST ACCEPTANCE  

REPORT NUMBER  

APPROVALS:

MFG. D/821   DATE  

Q.E. D/814   DATE  


ENGR. D/830   DATE  

QUALITY CONTROL   DATE   STAMP  

ACCEPT

# **DATA SHEET** **3/4" Increasing Shielding Gas**

## **AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)**

WPS No.	
MPP NUMBER <b>MPP-LO-0001</b>	<div style="display: flex; justify-content: space-between;"> <div> REVISION LETTER  <div style="border: 1px solid black; width: 100px; height: 15px;"></div> </div> <div> PAGE  14 of 14 </div> </div>
SPECIFICATION NO. REVISION. DATE <b>TPS A/A 328-001 Sample #111 +5%</b>	
X-Ray Results: <b>Accept</b>	
BACK-UP	PURGE GAS
INTERNAL GAS. <u>ARG</u>	HEAD GAS <u>ARG</u>
FLOW CFH <u>5+2</u>	FLOW CFH <u>16</u>
PRE-PURGE TIME <u>2 MIN(MIN)</u> (1)	PRE-PURGE TIME <u>15 SEC(MIN)</u>
POST-PURGE TIME <u>1 MIN(MIN)</u>	POST-PURGE TIME <u>1 MIN(MIN)</u>
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.	
PROGRAMMER SETTINGS	
WELD LEVEL I 5 to 199 Amps <div style="border: 1px solid black; padding: 2px; width: 50px; margin: 5px auto;">074</div>	WELD LEVEL II 5 to 199 Amps <div style="border: 1px solid black; padding: 2px; width: 50px; margin: 5px auto;">073</div>
WELD LEVEL III 5 to 199 Amps <div style="border: 1px solid black; padding: 2px; width: 50px; margin: 5px auto;">073</div>	WELD LEVEL IV 5 to 199 Amps <div style="border: 1px solid black; padding: 2px; width: 50px; margin: 5px auto;">072</div>
LEVEL I Time 1-299 Sec <div style="border: 1px solid black; padding: 2px; width: 50px; margin: 5px auto;">018</div>	LEVEL II Time 1-299 Sec <div style="border: 1px solid black; padding: 2px; width: 50px; margin: 5px auto;">017</div>
LEVEL III Time 1-299 Sec <div style="border: 1px solid black; padding: 2px; width: 50px; margin: 5px auto;">016</div>	LEVEL IV Time 1-299 Sec <div style="border: 1px solid black; padding: 2px; width: 50px; margin: 5px auto;">017</div>
PULSE HIGH .1 to 9.9 Sec <div style="border: 1px solid black; padding: 2px; width: 50px; margin: 5px auto;">0.2</div>	PULSE LOW .1 to 9.9 Sec <div style="border: 1px solid black; padding: 2px; width: 50px; margin: 5px auto;">0.1</div>
ROTATION DELAY .1 to 9.9 Sec <div style="border: 1px solid black; padding: 2px; width: 50px; margin: 5px auto;">3.6</div>	FINISH SLOPE .1 to 9.9 Sec <div style="border: 1px solid black; padding: 2px; width: 50px; margin: 5px auto;">9.9</div>
HEAD SPEED RPM <div style="border: 1px solid black; padding: 2px; width: 50px; margin: 5px auto;">1.00</div>	
<b>QUALIFICATION POSITIONS</b> <input type="checkbox"/> HORIZONTAL <input type="checkbox"/> VERTICAL	
MACHINE E-200T4 S/N <u>328</u> HEAD S/N <u>1328</u>	
WELDERS NAME _____ STAMP _____ RADIOGRAPH ACCEPTANCE _____ TENSILE TEST ACCEPTANCE _____ REPORT NUMBER _____	
APPROVALS: MFG. D/821 _____ DATE _____ Q.E. D/814 _____ DATE _____ ENGR.D/830 _____ DATE _____ QUALITY CONTROL _____ DATE _____ <div style="text-align: center;">STAMP</div>	
	ELECTRODE (Sketch) A <u>80°</u> B <u>.010</u> C <u>1.073</u> D <u>.020</u>
ACCEPT	


FORM 116.5-1 REV. 5-73



# DATA SHEET 3/4" Increasing Shielding Gas

## AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

WPS No.

WPS NUMBER MPP-LO-0001		REVISION LETTER				PAGE 14 of 14
SPECIFICATION NO. REVISION.		DATE TPS A/A 328-001 Sample #113 +15%				
BACK-UP		PURGE GAS		X-Ray Results: Accept		
INTERVAL GAS: ARG		HEAD GAS: ARG		TUBE DATA		
FLOW CFH 5+2		FLOW CFH 18		O.D. 0.750		
PRE-PURGE TIME 2 MIN(MIN)		PRE-PURGE TIME 15 SEC(MIN)		ALLOY		
POST-PURGE TIME 1 MIN(MIN)		POST-PURGE TIME 1 MIN(MIN)		FTG. P/N		
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.						
PROGRAMMER SETTINGS						
WELD LEVEL I 5 to 199 Amps	WELD LEVEL II 5 to 199 Amps	WELD LEVEL III 5 to 199 Amps	WELD LEVEL IV 5 to 199 Amps	PULSE LOW 5 to 199 Amps		
074	073	073	072	042		
LEVEL I Time 1-299 Sec	LEVEL II Time 1-299 Sec	LEVEL III Time 1-299 Sec	LEVEL IV Time 1-299 Sec	FINISH SLOPE .1 to 9.9 Sec		
018	017	016	017	9.9		
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM
0.2		0.1		3.6		1.00
QUALIFICATION POSITIONS						
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL						
MACHINE E-200T4 S/N 328						
HEAD S/N 1328						
		ELECTRODE (Sketch) A 80° B .010 C 1.073 D .020				
WELDERS NAME _____ STAMP _____ RADIOGRAPH ACCEPTANCE _____ TENSILE TEST ACCEPTANCE _____ REPORT NUMBER _____ APPROVALS: MFG. D/821 _____ DATE _____ Q.E. D/814 _____ DATE _____ ENGR. D/830 _____ DATE _____ QUALITY CONTROL _____ DATE _____ ACCEPT _____ STAMP _____						


FORM 701A.S.1 REV. 5-73

DATA SHEET  
3/4" Increasing Shielding Gas

ORIGINAL PAGE IS  
OF POOR QUALITY

AUTOMATIC BUTTWELD  
WELDING PROCEDURE SPECIFICATION (WPS)

MPP NUMBER MPP-LO-0001		REVISION LETTER.		WPS No.		PAGE 14 of 14	
SPECIFICATION NO.		REVISION.		DATE		TPS A/A 328-001 Sample #114 +30%	
BACK-UP		PURGE GAS		X-Ray Results: Accept			
INTERNAL GAS: ARG		HEAD GAS: ARG		O.D.		TUBE DATA	
FLOW CFH 5+2		FLOW CFH 20		WALL		.109	
PRE-PURGE TIME 2 MIN(MIN)(1)		PRE-PURGE TIME 15 SEC(MIN)		ALLOY			
POST-PURGE TIME 1 MIN(MIN)		POST-PURGE TIME 1 MIN(MIN)		FTG. P/N			
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.							
PROGRAMMER SETTINGS							
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps	
PULSE LOW 5 to 199 Amps							
074		073		073		072	
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec	
018		017		016		017	
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		FINISH SLOPE .1 to 9.9 Sec	
0.2		0.1		3.6		9.9	
						HEAD SPEED RPM	
						1.00	
QUALIFICATION POSITIONS							
<input type="checkbox"/> HORIZONTAL		<input checked="" type="checkbox"/> VERTICAL					
MACHINE E-200T4 S/N 328		WELDERS NAME _____ STAMP _____					
HEAD S/N 1328		RADIOGRAPH ACCEPTANCE _____					
		TENSILE TEST ACCEPTANCE _____					
		REPORT NUMBER _____					
		APPROVALS:					
		MFG. D/821 _____ DATE _____					
		Q.E. D/814 _____ DATE _____					
		ENGR. D/830 _____ DATE _____					
		QUALITY CONTROL _____ DATE _____					
		REJECT CONCAVITY _____ STAMP _____					



ELECTRODE (Sketch)	
A	80°
B	.010
C	1.073
D	.020


FORM 116.5.1 REV 5.73

C-2

# DATA SHEET 3/4" Increasing Shielding Gas

## AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

WPS No.

MPP NUMBER	MPP-LO-0001	REVISION LETTER		PAGE	14 of 14
SPECIFICATION NO.	REVISION	DATE	TPS A/A 328-001 Sample #115 +20%		
X-Ray Results: Reject L.O.P.					
BACK-UP	PURGE GAS	HEAD	TUBE DATA		
INTERNAL GAS. ARG	HEAD GAS ARG	O.D.	0.750		
FLOW CFH 5+2	FLOW CFH 18	WALL	.109		
PRE-PURGE TIME 2 MIN(MIN)(1) PRE-PURGE TIME 15 SEC(MIN) ALLOY					
POST-PURGE TIME 1 MIN(MIN) POST-PURGE TIME 1 MIN(MIN) FTG. P/N					
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.					
PROGRAMMER SETTINGS					
WELD LEVEL I 5 to 199 Amps	WELD LEVEL II 5 to 199 Amps	WELD LEVEL III 5 to 199 Amps	WELD LEVEL IV 5 to 199 Amps	PULSE LOW 5 to 199 Amps	
074	073	073	072	042	
LEVEL I Time 1-299 Sec	LEVEL II Time 1-299 Sec	LEVEL III Time 1-299 Sec	LEVEL IV Time 1-299 Sec	FINISH SLOPE .1 to 9.9 Sec	
018	017	016	017	9.9	
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec	ROTATION DELAY .1 to 9.9 Sec	HEAD SPEED RPM	
0.2		0.1	3.6	1.00	
QUALIFICATION POSITIONS			WELDERS NAME _____ STAMP _____		
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL			RADIOGRAPH ACCEPTANCE _____		
MACHINE E-200T4 S/N 328			TENSILE TEST ACCEPTANCE _____		
HEAD S/N 1328			REPORT NUMBER _____		
			APPROVALS:		
ELECTRODE (Sketch)			MFG. D/821 _____ DATE _____		
A 80°			Q.E. D/814 _____ DATE _____		
B .010			ENGR. D/830 _____ DATE _____		
C 1.073			QUALITY CONTROL _____ DATE _____		
D .020			STAMP _____		
REJECT CONCAVITY					

FORM 3018-S-1 REV. 5-73


ORIGINAL PAGE IS  
OF POOR QUALITY

## WPS No.

97

# DATA SHEET 3/4" Increasing Shielding Gas

## AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

MPP NUMBER <b>MPP-L0-0001</b>		REVISION LETTER 		WPS No. 		PAGE 14 of 14	
SPECIFICATION NO.		REVISION.		DATE		TPS A/A 328-001 Sample #117 +5%	
BACK-UP		PURGE GAS		X-Ray Results: Accept			
INTERNAL GAS: ARG		HEAD GAS ARG		TUBE DATA			
FLOW CFH <u>5+2</u>		FLOW CFH <u>16</u>		O.D. <u>0.750</u>		WALL <u>.109</u>	
PRE-PURGE TIME <u>2 MIN(MIN)</u> (1)		PRE-PURGE TIME <u>15 SEC(MIN)</u>		ALLOY <u> </u>			
POST-PURGE TIME <u>1 MIN(MIN)</u>		POST-PURGE TIME <u>1 MIN(MIN)</u>		FTG. P/N <u> </u>			
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.							
PROGRAMMER SETTINGS							
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps	
074		073		073		072	
PULSE LOW 5 to 199 Amps		PULSE LOW 5 to 199 Amps		PULSE LOW 5 to 199 Amps		PULSE LOW 5 to 199 Amps	
074		073		073		072	
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec	
018		017		016		017	
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		FINISH SLOPE .1 to 9.9 Sec	
0.2		0.1		3.6		9.9	
HEAD SPEED RPM							
1.00							
QUALIFICATION POSITIONS							
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL							
MACHINE E-200T4 S/N <u>328</u> HEAD S/N <u>1328</u>							
WELDERS NAME <u> </u> STAMP <u> </u> RADIOGRAPH ACCEPTANCE <u> </u> TENSILE TEST ACCEPTANCE <u> </u> REPORT NUMBER <u> </u> APPROVALS: MFG. D/821 <u> </u> DATE <u> </u> Q.E. D/814 <u> </u> DATE <u> </u> ENGR. D/830 <u> </u> DATE <u> </u> QUALITY CONTROL <u> </u> DATE <u> </u>							
				ELECTRODE (Sketch) A <u>80°</u> B <u>.010</u> C <u>1.073</u> D <u>.020</u>			
ACCEPT <u> </u> STAMP <u> </u>							

FORM 3016.1 REV 5.73




**DATA SHEET**  
**3/4" Decreasing Shielding Gas**

**ORIGINAL PAGE IS  
OF POOR QUALITY**

**AUTOMATIC BUTTWELD  
WELDING PROCEDURE SPECIFICATION (WPS)**

MPP NUMBER <b>MPP-LO-0001</b>		REVISION LETTER <div style="border: 1px solid black; width: 100px; height: 1.2em; display: flex; justify-content: space-between;"><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div></div>		WPS No.		PAGE <b>14 of 14</b>	
SPECIFICATION NO. REVISION.		DATE		TPS A/A 328-001		Sample #108 -5%	
BACK-UP		PURGE GAS		X-Ray Result: Accept			
INTERNAL GAS: ARG		HEAD GAS ARG		O.D. 0.750			
FLOW CFH 5+2		FLOW CFH 14		WALL 0.109			
PRE-PURGE TIME 2 MIN(MIN)(1)		PRE-PURGE TIME 15 SEC(MIN)		ALLOY			
POST-PURGE TIME 1 MIN(MIN)		POST-PURGE TIME 1 MIN(MIN)		FTG. P/N			
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.							
<b>PROGRAMMER SETTINGS</b>							
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps	
PULSE LOW 5 to 199 Amps							
074		073		073		072	
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec	
018		017		016		017	
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM	
0.2		0.1		3.6		1.00	
<b>QUALIFICATION POSITIONS</b>							
<input type="checkbox"/> HORIZONTAL		<input checked="" type="checkbox"/> VERTICAL					
MACHINE E-200T4 S/N 328		HEAD S/N 1328					
WELDERS NAME		STAMP					
RADIOGRAPH ACCEPTANCE							
TENSILE TEST ACCEPTANCE							
REPORT NUMBER							
<b>APPROVALS:</b>							
MFG. D/821		DATE					
Q.E. D/814		DATE					
ENGR. D/830		DATE					
QUALITY CONTROL		DATE					
		STAMP					
REJECT LOW CONCAVITY							



ELECTRODE (Sketch)	
A	80°
B	.010
C	1.073
D	.020

FORM 1016.1 REV. 5-73

# DATA SHEET 3/4" Decreasing Shielding Gas

## AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

MPP NUMBER MPP-LO-0001		REVISION LETTER		WPS No.		PAGE 14 of 14	
SPECIFICATION NO.		REVISION.		DATE		TPS A/A 328-001 Sample #109 -10%	
BACK-UP		PURGE GAS		X-Ray Results: Accept			
INTERNAL GAS ARG		HEAD GAS ARG		O.D.		TUBE DATA	
FLOW CFH 5+2		FLOW CFH 13		WALL		0.109	
PRE-PURGE TIME 2 MIN(MIN)		(1) PRE-PURGE TIME 15 SEC(MIN)		ALLOY			
POST-PURGE TIME 1 MIN(MIN)		POST-PURGE TIME 1 MIN(MIN)		FTG. P/H			
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.							
PROGRAMMER SETTINGS							
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps	
PULSE LOW 5 to 199 Amps							
074		073		073		072	
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec	
018		017		016		017	
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		FINISH SLOPE .1 to 9.9 Sec	
0.2		0.1		3.6		9.9	
						HEAD SPEED RPM	
						1.00	
QUALIFICATION POSITIONS							
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL							
MACHINE E-200T4 S/N 328							
HEAD S/N 1328							
				ELECTRODE (Sketch) A 80° B .010 C 1.073 D .020			
				WELDERS NAME _____ STAMP _____			
				RADIOGRAPH ACCEPTANCE _____			
				TENSILE TEST ACCEPTANCE _____			
				REPORT NUMBER _____			
				APPROVALS:			
				MFG. D/821 _____ DATE _____			
				Q.E. D/814 _____ DATE _____			
				ENGR. D/830 _____ DATE _____			
				QUALITY CONTROL _____ DATE _____			
				STAMP			


ORIGINAL PAGE IS  
OF POOR QUALITY

## WPS No.

FORM 701A.9.1 REV. 5.73

# DATA SHEET 1 1/2" Increasing Amps

## AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

MPP NUMBER MPP-LO-0001		WPS No.		REVISION LETTER		PAGE 14 of 14	
SPECIFICATION NO. REVISION.		DATE		TPS A/A 328-001		Sample #24 +10%	
BACK-UP		PURGE GAS		X-Ray Results: Accept		TUBE DATA	
INTERNAL GAS		HEAD GAS		O.D.		1.500	
FLOW CFH 5+2		FLOW CFH 15+5		WALL		0.049	
PRE-PURGE TIME 2 MIN(MIN)		(1) PRE-PURGE TIME 15 SEC(MIN)		ALLOY			
POST-PURGE TIME 1 MIN(MIN)		POST-PURGE TIME 1 MIN(MIN)		FTG. P/N			
(1) Add 1 min (min) for each additional ft. o: line between the gas inlet and the joint to be welded.							
PROGRAMMER SETTINGS							
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps	
PULSE LOW 5 to 199 Amps							
102		101		98		96	
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec	
009		012		009		010	
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		FINISH SLOPE .1 to 9.9 Sec	
0.1		0.1		1.0		9.9	
HEAD SPEED RPM						1.60	
QUALIFICATION POSITIONS							
<input type="checkbox"/> HORIZONTAL		<input type="checkbox"/> VERTICAL		WELDERS NAME		STAMP	
MACHINE E-200T4 S/N 328		HEAD S/N		RADIOGRAPH ACCEPTANCE			
				TENSILE TEST ACCEPTANCE			
				REPORT NUMBER			
				APPROVALS:			
				MFG. D/821		DATE	
				Q.E. D/814		DATE	
				ENGR. D/830		DATE	
				QUALITY CONTROL		DATE	
				STAMP			
		ELECTRODE (Sketch) A 80° B .015 C 1.270 D .020					


FORM 2016.1 REV 6.73

DATA SHEET  
1 1/2" Increasing Amps

ORIGINAL PAGE IS  
OF POOR QUALITY

AUTOMATIC BUTTWELD  
WELDING PROCEDURE SPECIFICATION (WPS)

MPP NUMBER MPP-LO-0001		REVISION LETTER				WPS No.		PAGE 14 of 14	
SPECIFICATION NO.		REVISION.		DATE		TPS A/A 328-001 Sample #25 +5%			
BACK-UP		PURGE GAS		X-Ray Results: Accept					
INTERNAL GAS ARG		HEAD GAS ARG		HEAD		TUBE DATA			
FLOW CFH 5+2		FLOW CFH 15+5		O.D.		1.500			
PRE-PURGE TIME 2 MIN(MIN)		(1) PRE-PURGE TIME 15 SEC(MIN)		ALLOY					
POST-PURGE TIME 1 MIN(MIN)		POST-PURGE TIME 1 MIN(MIN)		FTG. P/N					
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.									
PROGRAMMER SETTINGS									
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps		PULSE LOW 5 to 199 Amps	
098		097		094		091		038	
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec		FINISH SLOPE .1 to 9.9 Sec	
009		012		009		010		9 9	
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM			
0.1		0.1		1.0		1.60			
QUALIFICATION POSITIONS									
<input type="checkbox"/> HORIZONTAL		<input checked="" type="checkbox"/> VERTICAL							
MACHINE E-200T4 S/N 328		WELDERS NAME _____ STAMP _____							
HEAD S/N 1262		RADIOGRAPH ACCEPTANCE _____							
		TENSILE TEST ACCEPTANCE _____							
		REPORT NUMBER _____							
		APPROVALS:							
		MFG. D/821 _____ DATE _____							
		Q.E. D/814 _____ DATE _____							
		ENGR. D/830 _____ DATE _____							
		QUALITY CONTROL _____ DATE _____							
		STAMP _____							
		VISUAL ACCEPT							



ELECTRODE (Sketch)	
A	080
B	.015
C	1.270
D	.020


# DATA SHEET 1 1/2" Increasing Amps

## AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

WPS No.	
MPP NUMBER MPP-LO-0001	<div style="display: flex; justify-content: space-between;"> <div> REVISION LETTER  <div style="border: 1px solid black; width: 100px; height: 15px;"></div> </div> <div> PAGE 14 of 14 </div> </div>
SPECIFICATION NO. REVISION. DATE <u>TPS A/A 328-001 Sample #26</u> *	
X-Ray Results: Accept	
BACK-UP	PURGE GAS
INTERNAL GAS <u>ARG</u>	HEAD <u>ARG</u>
FLOW CFH <u>5+2</u>	O.D. <u>1.500</u>
PRE-PURGE TIME <u>2 MIN(MIN)</u> (1)	HEAD GAS <u>ARG</u>
POST-PURGE TIME <u>1 MIN(MIN)</u>	FLOW CFH <u>15+5</u>
PRE-PURGE TIME <u>15 SEC(MIN)</u>	WALL <u>0.049</u>
POST-PURGE TIME <u>1 MIN(MIN)</u>	TUBE DATA
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.	
PROGRAMMER SETTINGS	
WELD LEVEL I 5 to 199 Amps	WELD LEVEL II 5 to 199 Amps
WELD LEVEL III 5 to 199 Amps	WELD LEVEL IV 5 to 199 Amps
PULSE LOW 5 to 199 Amps	PULSE LOW 5 to 199 Amps
100	099
96	94
038	038
LEVEL I Time 1-299 Sec	LEVEL II Time 1-299 Sec
LEVEL III Time 1-299 Sec	LEVEL IV Time 1-299 Sec
FINISH SLOPE .1 to 9.9 Sec	FINISH SLOPE .1 to 9.9 Sec
009	012
009	010
9.9	9.9
PULSE HIGH .1 to 9.9 Sec	PULSE LOW .1 to 9.9 Sec
ROTATION DELAY .1 to 9.9 Sec	HEAD SPEED RPM
0.1	0.1
1.0	1.60
QUALIFICATION POSITIONS	
<input type="checkbox"/> HORIZONTAL	<input checked="" type="checkbox"/> VERTICAL
WELDERS NAME _____	STAMP _____
RADIOGRAPH ACCEPTANCE _____	TENSILE TEST ACCEPTANCE _____
REPORT NUMBER _____	APPROVALS:
MFG. D/821 _____	DATE _____
Q.E. D/814 _____	DATE _____
ENGR. D/830 _____	DATE _____
QUALITY CONTROL _____	DATE _____
STAMP	DATE _____
* -2 AMPS BELOW SAMPLE #24	



# AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

MPP NUMBER <b>MPP-LO-0001</b>		REVISION LETTER <table border="1" style="width:100%; height: 20px;"> <tr> <td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> </table>																						WPS No. PAGE 14 of 14	
SPECIFICATION NO.		REVISION.		DATE		TPS A/A 328-001 Sample #28 +20%																			
				PURGE GAS		X-Ray Results: Accept																			
BACK-UP				HEAD		TUBE DATA																			
INTERNAL GAS: ARG				HEAD GAS ARG				O.D.		1.500															
FLOW CFH 5+2				FLOW CFH 15+5				WALL		.049															
PRE-PURGE TIME 2 MIN(MIN)(1)				PRE-PURGE TIME 15 SEC(MIN)				ALLOY																	
POST-PURGE TIME 1 MIN(MIN)				POST-PURGE TIME 1 MIN(MIN)				FTG. P/N																	
(1) Add 1 min (min) for each additional ft. o: line between the gas inlet and the joint to be welded.																									
PROGRAMMER SETTINGS																									
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps		PULSE LOW 5 to 199 Amps																	
112		110		107		104		038																	
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec		FINISH SLOPE .1 to 9.9 Sec																	
009		012		009		010		9.9																	
PULSE HIGH .1 to 9.9 Sec				PULSE LOW .1 to 9.9 Sec				ROTATION DELAY .1 to 9.9 Sec				HEAD SPEED RPM													
0.1				0.1				1.0				1.60													
QUALIFICATION POSITIONS																									
<input type="checkbox"/> HORIZONTAL		<input checked="" type="checkbox"/> VERTICAL																							
MACHINE E-200T4 S/N		328																							
HEAD S/N		1262																							
		ELECTRODE (Sketch) A 80° B .015 C 1.270 D .020																							
		WELDERS NAME _____ STAMP _____																							
		RADIOGRAPH ACCEPTANCE _____																							
		TENSILE TEST ACCEPTANCE _____																							
		REPORT NUMBER _____																							
		APPROVALS:																							
		MFG. D/821 _____ DATE _____																							
		Q.E. D/814 _____ DATE _____																							
		ENGR.D/830 _____ DATE _____																							
		QUALITY CONTROL _____ DATE _____																							
		STAMP																							
VISUAL ACCEPT																									




ORIGINAL PAGE IS  
OF POOR QUALITY

DATA SHEET  
1 1/2" Increasing Amps

AUTOMATIC BUTTWELD  
WELDING PROCEDURE SPECIFICATION (WPS)


WPS No.

MPP NUMBER MPP-LO-0001		REVISION LETTER								PAGE 14 of 14	
SPECIFICATION NO.		REVISION.		DATE		TPS A/A 328-001		Sample #29 +25%			
BACK-UP		PURGE GAS		X-Ray Results: Accept				HEAD		TUBE DATA	
INTERNAL GAS ARG		HEAD GAS ARG		O.D.		1.500					
FLOW CFH 5+2		FLOW CFH 15+5		WALL		.049					
PRE-PURGE TIME 2 MIN(MIN)		(1) PRE-PURGE TIME 15 SEC(MIN)		ALLOY							
POST-PURGE TIME 1 MIN(MIN)		POST-PURGE TIME 1 MIN(MIN)		FTG. P/W							
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.											
PROGRAMMER SETTINGS											
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps		PULSE LOW 5 to 199 Amps			
116		112		111		109		038			
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec		FINISH SLOPE .1 to 9.9 Sec			
009		012		009		010		9.9			
		PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM			
		0.1		0.1		1.0		1.60			
QUALIFICATION POSITIONS <input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL											
MACHINE E-200T4 S/N 328 HEAD S/N 1262											
				ELECTRODE (Sketch) A 080 B .015 C 1.270 D .020							
				WELDERS NAME _____ STAMP _____ RADIOGRAPH ACCEPTANCE _____ TENSILE TEST ACCEPTANCE _____ REPORT NUMBER _____ APPROVALS: MFG. D/821 _____ DATE _____ Q.E. D/814 _____ DATE _____ ENGR. D/830 _____ DATE _____ QUALITY CONTROL _____ DATE _____ VISUAL ACCEPT _____ STAMP _____							

# DATA SHEET

## 1 1/2" Increasing Amps

### AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)


MPP NUMBER <b>MPP-LO-0001</b>		WPS No.		REVISION LETTER		PAGE 14 of 14	
SPECIFICATION NO. REVISION. DATE <b>TPS A/A 328-001</b> Sample #30 +30%							
BACK-UP		PURGE GAS		X-Ray Results: Accept		HEAD	
INTERNAL GAS <b>ARG</b>		HEAD GAS <b>ARG</b>		O.D. <b>1.500</b>		TUBE DATA	
FLOW CFH <b>5+2</b>		FLOW CFH <b>15+5</b>		WALL <b>.049</b>			
PRE-PURGE TIME <b>2 MIN(MIN)</b> (1)				PRE-PURGE TIME <b>15 SEC(MIN)</b> ALLOY			
POST-PURGE TIME <b>1 MIN(MIN)</b>				POST-PURGE TIME <b>1 MIN(MIN)</b> FTG. P/H			
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.							
PROGRAMMER SETTINGS							
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps	
<b>120</b>		<b>120</b>		<b>116</b>		<b>115</b>	
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec	
<b>009</b>		<b>012</b>		<b>009</b>		<b>010</b>	
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		FINISH SLOPE .1 to 9.9 Sec	
<b>0.1</b>		<b>0.1</b>		<b>1.0</b>		<b>9.9</b>	
HEAD SPEED RPM		<b>1.60</b>					
QUALIFICATION POSITIONS							
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL							
MACHINE E-200T4 S/N <b>328</b>							
HEAD S/N <b>1262</b>							
		ELECTRODE (Sketch) A <b>80°</b> B <b>.015</b> C <b>1.270</b> D <b>.020</b>					
WELDERS NAME _____ STAMP _____ RADIOGRAPH ACCEPTANCE _____ TENSILE TEST ACCEPTANCE _____ REPORT NUMBER _____ APPROVALS: MFG. D/821 _____ DATE _____ Q.E. D/814 _____ DATE _____ ENGR. D/830 _____ DATE _____ QUALITY CONTROL _____ DATE _____ STAMP _____ REJECT CONCAVITY							

**DATA SHEET**  
**1 1/2" Increasing Amps**

**ORIGINAL PAGE IS  
OF POOR QUALITY**

**AUTOMATIC BUTTWELD  
WELDING PROCEDURE SPECIFICATION (WPS)**

WPS No. \_\_\_\_\_

MPP NUMBER MPP-LO-0001		REVISION LETTER 				PAGE 14 of 14	
SPECIFICATION NO. REVISION. DATE <u>TPS A/A 328-001</u> Sample #31 -2 Amps <div style="text-align: right;">Below +30%</div>							
BACK-UP		PURGE GAS		X-Ray Results: Accept		TUBE DATA	
INTERNAL GAS <u>ARG</u>		HEAD GAS <u>ARG</u>		O.D. <u>1.500</u>			
FLOW CFH <u>5+2</u>		FLOW CFH <u>15+5</u>		WALL <u>0.049</u>			
PRE-PURGE TIME <u>2 MIN(MIN)</u> (1) PRE-PURGE TIME <u>15 SEC(MIN)</u> ALLOY _____ POST-PURGE TIME <u>1 MIN(MIN)</u> POST-PURGE TIME <u>1 MIN(MIN)</u> FTG. P/N _____ (1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.							
<b>PROGRAMMER SETTINGS</b>							
WELD LEVEL I 5 to 199 Amps	WELD LEVEL II 5 to 199 Amps	WELD LEVEL III 5 to 199 Amps	WELD LEVEL IV 5 to 199 Amps	PULSE LOW 5 to 199 Amps			
<div style="border: 1px solid black; width: 40px; height: 20px; margin: 0 auto;">118</div>	<div style="border: 1px solid black; width: 40px; height: 20px; margin: 0 auto;">118</div>	<div style="border: 1px solid black; width: 40px; height: 20px; margin: 0 auto;">114</div>	<div style="border: 1px solid black; width: 40px; height: 20px; margin: 0 auto;">113</div>	<div style="border: 1px solid black; width: 40px; height: 20px; margin: 0 auto;">038</div>			
LEVEL I Time 1-299 Sec	LEVEL II Time 1-299 Sec	LEVEL III Time 1-299 Sec	LEVEL IV Time 1-299 Sec	FINISH SLOPE .1 to 9.9 Sec			
<div style="border: 1px solid black; width: 40px; height: 20px; margin: 0 auto;">009</div>	<div style="border: 1px solid black; width: 40px; height: 20px; margin: 0 auto;">012</div>	<div style="border: 1px solid black; width: 40px; height: 20px; margin: 0 auto;">009</div>	<div style="border: 1px solid black; width: 40px; height: 20px; margin: 0 auto;">010</div>	<div style="border: 1px solid black; width: 40px; height: 20px; margin: 0 auto;">9.9</div>			
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM	
<div style="border: 1px solid black; width: 40px; height: 20px; margin: 0 auto;">0.1</div>		<div style="border: 1px solid black; width: 40px; height: 20px; margin: 0 auto;">0.1</div>		<div style="border: 1px solid black; width: 40px; height: 20px; margin: 0 auto;">1.0</div>		<div style="border: 1px solid black; width: 40px; height: 20px; margin: 0 auto;">1.60</div>	
<b>QUALIFICATION POSITIONS</b> <input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL MACHINE E-200T4 S/N <u>328</u> HEAD S/N <u>1262</u>							
 <div style="margin-left: 10px;"> <b>ELECTRODE (Sketch)</b>            A <u>80°</u>            B <u>.015</u>            C <u>1.270</u>            D <u>.020</u> </div>				<b>WELDERS NAME</b> _____ <b>STAMP</b> _____ <b>RADIOGRAPH ACCEPTANCE</b> _____ <b>TENSILE TEST ACCEPTANCE</b> _____ <b>REPORT NUMBER</b> _____ <b>APPROVALS:</b> MFG. D/821 _____ DATE _____ Q.E. D/814 _____ DATE _____ ENGR. D/830 _____ DATE _____ <b>QUALITY CONTROL</b> _____ DATE _____ <div style="text-align: right;">STAMP</div>			
REJECT LOW CONCAVITY							

# DATA SHEET 1 1/2" Increasing Amps

## AUTOMATIC BUTT WELD WELDING PROCEDURE SPECIFICATION (WPS)

MPP NUMBER MPP-LO-0001		REVISION LETTER		WPS No.		PAGE 14 of 14	
SPECIFICATION NO. REVISION.		DATE		TPS A/A 328-001 Sample #32 -4 Amps of +30%			
BACK-UP		PURGE GAS		X-Ray Results: Accept		TUBE DATA	
INTERNAL GAS. ARG		HEAD GAS ARG		O.D. 1.500			
FLOW CFH 5+2		FLOW CFH 15+5		WALL 0.049			
PRE-PURGE TIME 2 MIN(MIN)(1)		PRE-PURGE TIME 15 SEC(MIN)		ALLOY			
POST-PURGE TIME 1 MIN(MIN)		POST-PURGE TIME 1 MIN(MIN)		FTG. P/N			
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.							
PROGRAMMER SETTINGS							
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps	
116		116		112		111	
PULSE LOW 5 to 199 Amps						038	
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec	
009		012		009		010	
FINISH SLOPE .1 to 9.9 Sec						9.9	
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM	
0.1		0.1		1.0		1.60	
QUALIFICATION POSITIONS							
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL    WELDERS NAME _____ STAMP _____							
MACHINE E-200T4 S/N 328    HEAD S/N 1262    RADIOGRAPH ACCEPTANCE _____							
TENSILE TEST ACCEPTANCE _____							
REPORT NUMBER _____							
APPROVALS:							
MFG. D/821 _____ DATE _____							
Q.E. D/814 _____ DATE _____							
ENGR. D/830 _____ DATE _____							
QUALITY CONTROL _____ DATE _____							
VISUAL ACCEPT _____ STAMP _____							
		ELECTRODE (Sketch) A 80 B .015 C 1.270 D .020					


FORM 2016.5-1 REV. 5-73

DATA SHEET  
1 1/2" Increasing Amps

ORIGINAL PAGE IS  
OF POOR QUALITY

AUTOMATIC BUTTWELD  
WELDING PROCEDURE SPECIFICATION (WPS)

WPS No.

MPP NUMBER <b>MPP-LO-0001</b>		REVISION LETTER										PAGE <b>14 of 14</b>			
SPECIFICATION NO.		REVISION.		DATE		TPS A/A 328-001 Sample #33 -6 Amps of + 30									
BACK-UP		PURGE GAS				X-Ray Results: Accept				TUBE DATA					
INTERNAL GAS		ARG		HEAD GAS		ARG		O.D.		1.500					
FLOW CFH		5+2		FLOW CFH		15+5		WALL		0.049					
PRE-PURGE TIME 2 MIN(MIN)(1)						PRE-PURGE TIME 15 SEC(MIN)						ALLOY			
POST-PURGE TIME 1 MIN(MIN)						POST-PURGE TIME 1 MIN(MIN)						FTG. P/W			
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.															
PROGRAMMER SETTINGS															
WELD LEVEL I 5 to 199 Amps			WELD LEVEL II 5 to 199 Amps			WELD LEVEL III 5 to 199 Amps			WELD LEVEL IV 5 to 199 Amps			PULSE LOW 5 to 199 Amps			
114			114			110			109			038			
LEVEL I Time 1-299 Sec			LEVEL II Time 1-299 Sec			LEVEL III Time 1-299 Sec			LEVEL IV Time 1-299 Sec			FINISH SLOPE .1 to 9.9 Sec			
009			012			009			010			9.9			
			PULSE HIGH .1 to 9.9 Sec			PULSE LOW .1 to 9.9 Sec			ROTATION DELAY .1 to 9.9 Sec			HEAD SPEED RPM			
			0.1			0.1			1.0			1.60			
QUALIFICATION POSITIONS															
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL															
MACHINE E-200T4 S/N <u>328</u> HEAD S/N <u>1262</u>															
				ELECTRODE (Sketch) A 80° B .015 C 1.270 D .020											
WELDERS NAME _____ STAMP _____ RADIOGRAPH ACCEPTANCE _____ TENSILE TEST ACCEPTANCE _____ REPORT NUMBER _____ APPROVALS: MFG. D/821 _____ DATE _____ Q.E. D/814 _____ DATE _____ ENGR. D/830 _____ DATE _____ QUALITY CONTROL _____ DATE _____ <div style="text-align: right;">STAMP</div>															

FORM WPS-1 REV 5-73

**AUTOMATIC BUTTWELD  
WELDING PROCEDURE SPECIFICATION (WPS)**

**WPS No.**

MPP NUMBER <b>MPP-10-0001</b>	REVISION LETTER <table border="1" style="width:100%; height: 20px;"> <tr> <td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> </table>																					PAGE <b>14 of 14</b>

SPECIFICATION NO. <b>REVISION.</b>	DATE <b>TPS A/A 328-001</b>	Sample #1 -5%
------------------------------------	-----------------------------	---------------

PURGE GAS	X-Ray Results: <b>Accept</b>	
BACK-UP	HEAD	TUBE DATA
INTERNAL GAS <u>ARG</u>	HEAD GAS <u>ARG</u>	O.D. <u>1.500</u>
FLOW CFH <u>5+2</u>	FLOW CFH <u>15+5</u>	WALL <u>0.049</u>
PRE-PURGE TIME <u>2 MIN(MIN)</u> (1)		PRE-PURGE TIME <u>15 SEC(MIN)</u>
POST-PURGE TIME <u>1 MIN(MIN)</u>		POST-PURGE TIME <u>1 MIN(MIN)</u>
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.		ALLOY <u>304 L</u>

PROGRAMMER SETTINGS				
WELD LEVEL I 5 to 199 Amps	WELD LEVEL II 5 to 199 Amps	WELD LEVEL III 5 to 199 Amps	WELD LEVEL IV 5 to 199 Amps	PULSE LOW 5 to 199 Amps
<div style="border: 1px solid black; padding: 5px; width: 100px; margin: 0 auto;">088</div>	<div style="border: 1px solid black; padding: 5px; width: 100px; margin: 0 auto;">087</div>	<div style="border: 1px solid black; padding: 5px; width: 100px; margin: 0 auto;">085</div>	<div style="border: 1px solid black; padding: 5px; width: 100px; margin: 0 auto;">083</div>	<div style="border: 1px solid black; padding: 5px; width: 100px; margin: 0 auto;">038</div>
LEVEL I Time 1-299 Sec	LEVEL II Time 1-299 Sec	LEVEL III Time 1-299 Sec	LEVEL IV Time 1-299 Sec	FINISH SLOPE .1 to 9.9 Sec
<div style="border: 1px solid black; padding: 5px; width: 100px; margin: 0 auto;">009</div>	<div style="border: 1px solid black; padding: 5px; width: 100px; margin: 0 auto;">012</div>	<div style="border: 1px solid black; padding: 5px; width: 100px; margin: 0 auto;">009</div>	<div style="border: 1px solid black; padding: 5px; width: 100px; margin: 0 auto;">010</div>	<div style="border: 1px solid black; padding: 5px; width: 100px; margin: 0 auto;">9.9</div>
	PULSE HIGH .1 to 9.9 Sec	PULSE LOW .1 to 9.9 Sec	ROTATION DELAY .1 to 9.9 Sec	HEAD SPEED RPM
	<div style="border: 1px solid black; padding: 5px; width: 100px; margin: 0 auto;">0.1</div>	<div style="border: 1px solid black; padding: 5px; width: 100px; margin: 0 auto;">0.1</div>	<div style="border: 1px solid black; padding: 5px; width: 100px; margin: 0 auto;">1.0</div>	<div style="border: 1px solid black; padding: 5px; width: 100px; margin: 0 auto;">1.60</div>


  

<b>QUALIFICATION POSITIONS</b> <input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL	<b>WELDERS NAME</b> _____ <b>STAMP</b> _____  <b>RADIOGRAPH ACCEPTANCE</b> _____  <b>TENSILE TEST ACCEPTANCE</b> _____  <b>REPORT NUMBER</b> _____
--	--

MACHINE E-200T4 S/N <u>328</u> HEAD S/N <u>1262</u>	<table border="1" style="width:100%; border-collapse: collapse;"> <tr> <th colspan="2" style="text-align: left;">ELECTRODE (Sketch)</th> </tr> <tr> <td style="width:50%;">A <u>80°</u></td> <td style="width:50%;"></td> </tr> <tr> <td>B <u>.015</u></td> <td></td> </tr> <tr> <td>C <u>1.270</u></td> <td></td> </tr> <tr> <td>D <u>.020</u></td> <td></td> </tr> </table>	ELECTRODE (Sketch)		A <u>80°</u>		B <u>.015</u>		C <u>1.270</u>		D <u>.020</u>	
ELECTRODE (Sketch)											
A <u>80°</u>											
B <u>.015</u>											
C <u>1.270</u>											
D <u>.020</u>											

	<b>APPROVALS:</b>  MFG. D/821 _____ DATE _____  Q.E. D/814 _____ DATE _____  ENGR.D/830 _____ DATE _____  QUALITY CONTROL _____ DATE _____ <div style="text-align: right;">STAMP</div>
---	---


VISUAL ACCEPT 1 1/2"

ORIGINAL PAGE IS  
OF POOR QUALITY

DATA SHEET  
1 1/2" Decreasing Amps

AUTOMATIC BUTTWELD  
WELDING PROCEDURE SPECIFICATION (WPS)

WPS No.

WPS NUMBER MPP-LO-0001		REVISION LETTER		PAGE 14 of 14	
SPECIFICATION NO. REVISION.		DATE TPS A/A 328-001 Sample #2 -10%			
BACK-UP		PURGE GAS		X-Ray Results: Accept	
INTERNAL GAS ARG		HEAD GAS ARG		TUBE DATA	
FLOW CFH 5+2		FLOW CFH 15+5		O.D. 1.500	
PRE-PURGE TIME 2 MIN(MIN)		PRE-PURGE TIME 15 SEC(MIN)		WALL 0.049	
POST-PURGE TIME 1 MIN(MIN)		POST-PURGE TIME 1 MIN(MIN)		ALLOY 304L	
FTG. P/W (1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.					
PROGRAMMER SETTINGS					
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps	
084		083		080	
WELD LEVEL IV 5 to 199 Amps		PULSE LOW 5 to 199 Amps		PULSE HIGH .1 to 9.9 Sec	
079		038		0.1	
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec	
009		012		009	
LEVEL IV Time 1-299 Sec		FINISH SLOPE .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec	
010		9.9		1.0	
PULSE LOW .1 to 9.9 Sec		PULSE HIGH .1 to 9.9 Sec		HEAD SPEED RPM	
0.1		0.1		1.60	
QUALIFICATION POSITIONS					
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL					
MACHINE E-200T4 S/N 328					
HEAD S/N 1262					
		ELECTRODE (Sketch)			
		A 80°			
		B .015			
		C 1.270			
		D .020			
		FTG.			
WELDERS NAME _____ STAMP _____					
RADIOGRAPH ACCEPTANCE _____					
TENSILE TEST ACCEPTANCE _____					
REPORT NUMBER _____					
APPROVALS:					
MFG. D/821 _____ DATE _____					
Q.E. D/814 _____ DATE _____					
ENGR. D/830 _____ DATE _____					
QUALITY CONTROL _____ DATE _____					
STAMP					
VISUAL ACCEPT 1 1/2"					


FORM 3016-S-1 REV. 5-73

# DATA SHEET 1 1/2" Decreasing Amps

## AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

WPS No.

MPP NUMBER MPP-LO-0001		REVISION LETTER				PAGE 14 of 14
SPECIFICATION NO. REVISION.		DATE TPS A/A 328-001 Sample #3 -15%				
BACK-UP		PURGE GAS		X-Ray Results: Accept		
INTERNAL GAS ARG	HEAD GAS ARG	O.D.		1.500		
FLOW CFH 5+2	FLOW CFH 15+5	WALL		0.049		
PRE-PURGE TIME 2 MIN(MIN)(1)		PRE-PURGE TIME 15 SEC(MIN)		ALLOY 304L		
POST-PURGE TIME 1 MIN(MIN)		POST-PURGE TIME 1 MIN(MIN)		FTG. P/N		
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.						
PROGRAMMER SETTINGS						
WELD LEVEL I 5 to 199 Amps	WELD LEVEL II 5 to 199 Amps	WELD LEVEL III 5 to 199 Amps	WELD LEVEL IV 5 to 199 Amps	PULSE LOW 5 to 199 Amps		
079	078	076	074	038		
LEVEL I Time 1-299 Sec	LEVEL II Time 1-299 Sec	LEVEL III Time 1-299 Sec	LEVEL IV Time 1-299 Sec	FINISH SLOPE .1 to 9.9 Sec		
009	012	009	010	9.9		
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM
0.1		0.1		1.0		1.60
QUALIFICATION POSITIONS						
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL						
MACHINE E-200T4 S/N 328 HEAD S/N 1262						
WELDERS NAME _____ STAMP _____ RADIOGRAPH ACCEPTANCE _____ TENSILE TEST ACCEPTANCE _____ REPORT NUMBER _____						
APPROVALS: MFG. D/821 _____ DATE _____ Q.E. D/814 _____ DATE _____ ENGR. D/830 _____ DATE _____ QUALITY CONTROL _____ DATE _____ STAMP _____						
VISUAL ACCEPT						



ELECTRODE (Sketch)	
A	80°
B	.015
C	1.270
D	.020



**ORIGINAL PAGE IS  
OF POOR QUALITY**


## WPS No.

115

# DATA SHEET 1 1/2" Decreasing Amps

## AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

WPS No.


MPP NUMBER MPP-LO-0001		REVISION LETTER										PAGE 14 of 14	
SPECIFICATION NO.		REVISION.		DATE		TPS A/A 328-001 Sample #5 -25%							
BACK-UP		PURGE GAS		X-Ray Results: Reject L.O.P.									
INTERNAL GAS		HEAD		TUBE DATA									
ARG		ARG		O.D.		1.500							
FLOW CFH		FLOW CFH		WALL		0.049							
5+2		15+5											
PRE-PURGE TIME 2 MIN(MIN)(1)				PRE-PURGE TIME 15 SEC(MIN)				ALLOY					
POST-PURGE TIME 1 MIN(MIN)				POST-PURGE TIME 1 MIN(MIN)				FTG. P/H					
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.													
PROGRAMMER SETTINGS													
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps		PULSE LOW 5 to 199 Amps					
070		069		067		065		038					
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec		FINISH SLOPE .1 to 9.9 Sec					
009		012		009		010		9.9					
PULSE HIGH .1 to 9.9 Sec				PULSE LOW .1 to 9.9 Sec				ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM			
0.1				0.1				1.0		1.60			
QUALIFICATION POSITIONS													
<input type="checkbox"/> HORIZONTAL		<input type="checkbox"/> VERTICAL											
MACHINE E-200T4 S/N		328											
HEAD S/N		1262											
		ELECTRODE (Sketch) A 80° B .015 C 1.270 D .020											
FTG.													
VISUAL REJECT		WELDERS NAME _____ STAMP _____ RADIOGRAPH ACCEPTANCE _____ TENSILE TEST ACCEPTANCE _____ REPORT NUMBER _____ APPROVALS: MFG. D/821 _____ DATE _____ Q.E. D/814 _____ DATE _____ ENGR. D/830 _____ DATE _____ QUALITY CONTROL _____ DATE _____ STAMP _____											

DATA SHEET  
1 1/2" Decreasing Amps

ORIGINAL PAGE IS  
OF POOR QUALITY


AUTOMATIC BUTTWELD  
WELDING PROCEDURE SPECIFICATION (WPS)

WPS No.

MPP NUMBER MPP-LO-0001		REVISION LETTER				PAGE 14 of 14
SPECIFICATION NO. REVISION.		DATE TPS A/A 328-001 Sample #6 -25% Repeat				
X-Ray Results: Reject LOP						
BACK-UP		PURGE GAS		HEAD		TUBE DATA
INTERVAL GAS ARG		HEAD GAS ARG		O.D.		1.500
FLOW CFH 5+2		FLOW CFH 15+5		WALL		0.049
PRE-PURGE TIME 2 MIN(MIN)(1)		PRE-PURGE TIME 15 SEC(MIN)		ALLOY		
POST-PURGE TIME 1 MIN(MIN)		POST-PURGE TIME 1 MIN(MIN)		FTG. P/H		
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.						
PROGRAMMER SETTINGS						
WELD LEVEL I 5 to 199 Amps	WELD LEVEL II 5 to 199 Amps	WELD LEVEL III 5 to 199 Amps	WELD LEVEL IV 5 to 199 Amps	PULSE LOW 5 to 199 Amps		
070	069	067	065	038		
LEVEL I Time 1-299 Sec	LEVEL II Time 1-299 Sec	LEVEL III Time 1-299 Sec	LEVEL IV Time 1-299 Sec	FINISH SLOPE .1 to 9.9 Sec		
009	012	009	010	9.9		
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM
0.1		0.1		1.0		1.60
QUALIFICATION POSITIONS				WELDERS NAME _____ STAMP _____		
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL				RADIOGRAPH ACCEPTANCE _____		
MACHINE E-200T4 S/N 328				TENSILE TEST ACCEPTANCE _____		
HEAD S/N 1262				REPORT NUMBER _____		
				APPROVALS:		
				MFG. D/821 _____ DATE _____		
				Q.E. D/814 _____ DATE _____		
				ENGR. D/830 _____ DATE _____		
				QUALITY CONTROL _____ DATE _____		
VISUAL REJECT				STAMP		

# **DATA SHEET** **1 1/2" Decreasing Amps**

## **AUTOMATIC BUTTWELD** **WELDING PROCEDURE SPECIFICATION (WPS)**


MPP NUMBER <b>MPP-LO-0001</b>		REVISION LETTER <div style="display: flex; justify-content: space-between;"> <div style="border: 1px solid black; width: 100px; height: 15px;"></div> <div style="border: 1px solid black; width: 100px; height: 15px;"></div> <div style="border: 1px solid black; width: 100px; height: 15px;"></div> <div style="border: 1px solid black; width: 100px; height: 15px;"></div> <div style="border: 1px solid black; width: 100px; height: 15px;"></div> <div style="border: 1px solid black; width: 100px; height: 15px;"></div> <div style="border: 1px solid black; width: 100px; height: 15px;"></div> <div style="border: 1px solid black; width: 100px; height: 15px;"></div> </div>		WPS No.	PAGE <b>14 of 14</b>
SPECIFICATION NO. REVISION. DATE <b>TSP A/A 328-001 Sample #7</b>					
<div style="display: flex; justify-content: space-between;"> <div> <p>BACK-UP</p> <p>INTERNAL GAS <u>ARG</u></p> <p>FLOW CFH <u>5+2</u></p> <p>PRE-PURGE TIME <u>2 MIN(MIN)</u>(1)</p> <p>POST-PURGE TIME <u>1 MIN(MIN)</u></p> </div> <div> <p>PURGE GAS</p> <p>HEAD GAS <u>ARG</u></p> <p>FLOW CFH <u>15+5</u></p> <p>PRE-PURGE TIME <u>15 SEC(MIN)</u></p> <p>POST-PURGE TIME <u>1 MIN(MIN)</u></p> </div> <div> <p>X-Ray Results: <u>Reject LOP</u></p> <p>HEAD</p> <p>WALL <u>0.049</u></p> <p>FTG. P/W</p> </div> <div> <p>TUBE DATA</p> <p>O.D. <u>1.500</u></p> </div> </div>					
<p>(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.</p>					
<b>PROGRAMMER SETTINGS</b>					
<p><b>WELD LEVEL I</b> 5 to 199 Amps</p> <div style="border: 1px solid black; padding: 5px; text-align: center;">072</div>	<p><b>WELD LEVEL II</b> 5 to 199 Amps</p> <div style="border: 1px solid black; padding: 5px; text-align: center;">071</div>	<p><b>WELD LEVEL III</b> 5 to 199 Amps</p> <div style="border: 1px solid black; padding: 5px; text-align: center;">069</div>	<p><b>WELD LEVEL IV</b> 5 to 199 Amps</p> <div style="border: 1px solid black; padding: 5px; text-align: center;">067</div>		
<p><b>LEVEL I</b> Time 1-299 Sec</p> <div style="border: 1px solid black; padding: 5px; text-align: center;">009</div>	<p><b>LEVEL II</b> Time 1-299 Sec</p> <div style="border: 1px solid black; padding: 5px; text-align: center;">012</div>	<p><b>LEVEL III</b> Time 1-299 Sec</p> <div style="border: 1px solid black; padding: 5px; text-align: center;">009</div>	<p><b>LEVEL IV</b> Time 1-299 Sec</p> <div style="border: 1px solid black; padding: 5px; text-align: center;">010</div>		
<p><b>PULSE HIGH</b> .1 to 9.9 Sec</p> <div style="border: 1px solid black; padding: 5px; text-align: center;">0.1</div>		<p><b>PULSE LOW</b> .1 to 9.9 Sec</p> <div style="border: 1px solid black; padding: 5px; text-align: center;">0.1</div>			
<p><b>ROTATION DELAY</b> .1 to 9.9 Sec</p> <div style="border: 1px solid black; padding: 5px; text-align: center;">1.0</div>		<p><b>FINISH SLOPE</b> .1 to 9.9 Sec</p> <div style="border: 1px solid black; padding: 5px; text-align: center;">9.9</div>			
<p><b>HEAD SPEED</b> RPM</p> <div style="border: 1px solid black; padding: 5px; text-align: center;">1.60</div>					
<p><b>QUALIFICATION POSITIONS</b></p> <p><input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL</p> <p>MACHINE E-200T4 S/N <u>328</u></p> <p>HEAD S/N <u>1262</u></p>					
<div style="display: flex;"> <div style="flex: 1;">  <p><b>ELECTRODE (Sketch)</b></p> <p>A <u>80°</u></p> <p>B <u>.015</u></p> <p>C <u>1.270</u></p> <p>D <u>.020</u></p> </div> <div style="flex: 1;"> <p>WELDERS NAME _____ STAMP _____</p> <p>RADIOGRAPH ACCEPTANCE _____</p> <p>TENSILE TEST ACCEPTANCE _____</p> <p>REPORT NUMBER _____</p> <p>APPROVALS:</p> <p>MFG. D/821 _____ DATE _____</p> <p>Q.E. D/814 _____ DATE _____</p> <p>ENGR. D/830 _____ DATE _____</p> <p>QUALITY CONTROL _____ DATE _____</p> <p align="center">STAMP</p> <p>VISUAL REJECT LOP</p> </div> </div>					

ORIGINAL PAGE IS  
OF POOR QUALITY

DATA SHEET  
1 1/2" Decreasing Amps

AUTOMATIC BUTTWELD  
WELDING PROCEDURE SPECIFICATION (WPS)



WPS No.

MPP NUMBER <b>MPP-LO-0001</b>		REVISION LETTERS <table border="1" style="width:100%; height: 20px;"> <tr> <td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> </table>																						PAGE <b>14 of 14</b>	
SPECIFICATION NO. REVISION. DATE <b>TPS A/A 328-001 Sample #8</b>																									
X-Ray Results: Reject LOP																									
BACK-UP		PURGE GAS				HEAD				TUBE DATA															
INTERNAL GAS <u>ARG</u>		HEAD GAS <u>ARG</u>				O.D. <u>1.500</u>																			
FLOW CFH <u>5+2</u>		FLOW CFH <u>15+5</u>				WALL <u>0.049</u>																			
PRE-PURGE TIME <u>2 MIN(MIN)</u> (1)						PRE-PURGE TIME <u>15 SEC(MIN)</u>						ALLOY <u></u>													
POST-PURGE TIME <u>1 MIN(MIN)</u>						POST-PURGE TIME <u>1 MIN(MIN)</u>						FTG. P/H <u></u>													
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.																									
PROGRAMMER SETTINGS																									
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps		PULSE LOW 5 to 199 Amps																	
074		073		071		069		038																	
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec		FINISH SLOPE .1 to 9.9 Sec																	
009		012		009		010		9.9																	
PULSE HIGH .1 to 9.9 Sec				PULSE LOW .1 to 9.9 Sec				ROTATION DELAY .1 to 9.9 Sec				HEAD SPEED RPM													
0.1				0.1				1.0				1.60													
QUALIFICATION POSITIONS																									
<input type="checkbox"/> HORIZONTAL <input type="checkbox"/> VERTICAL																									
MACHINE E-200T4 S/N <u>328</u> HEAD S/N <u>1262</u>																									
WELDERS NAME _____ STAMP _____ RADIOGRAPH ACCEPTANCE _____ TENSILE TEST ACCEPTANCE _____ REPORT NUMBER _____																									
APPROVALS: MFG. D/821 _____ DATE _____ Q.E. D/814 _____ DATE _____ ENGR. D/830 _____ DATE _____ NOTE QUALITY CONTROL _____ DATE _____ VISUAL INDICATES MINUTE STAMP AREA NO DROP THRU. WELD IS FUSED.																									
				ELECTRODE (Sketch) A <u>80°</u> B <u>.015</u> C <u>1.270</u> D <u>.020</u>																					

# DATA SHEET 1 1/2" Decreasing Amps

## AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

WPS No.

MPP NUMBER <b>MPP-LO-0001</b>		REVISION LETTER				PAGE 14 of 14	
SPECIFICATION NO. REVISION.		DATE <b>TPS A/A 328-001 Sample #9</b>					
BACK-UP		PURGE GAS		X-Ray Results: Reject LOP		TUBE DATA	
INTERNAL GAS <u>ARG</u>		HEAD GAS <u>ARG</u>		O.D. <u>1.500</u>		WALL <u>0.049</u>	
FLOW CFH <u>5+2</u>		FLOW CFH <u>15+5</u>		PRE-PURGE TIME <u>2 MIN(MIN)</u> (1)		PRE-PURGE TIME <u>15 SEC(MIN)</u> ALLOY	
POST-PURGE TIME <u>1 MIN(MIN)</u>		POST-PURGE TIME <u>1 MIN(MIN)</u>		FTG. P/N		(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.	
PROGRAMMER SETTINGS							
WELD LEVEL I 5 to 199 Amps	WELD LEVEL II 5 to 199 Amps	WELD LEVEL III 5 to 199 Amps	WELD LEVEL IV 5 to 199 Amps	PULSE LOW 5 to 199 Amps			
<div style="border: 1px solid black; width: 40px; height: 20px; margin: 0 auto;">076</div>	<div style="border: 1px solid black; width: 40px; height: 20px; margin: 0 auto;">075</div>	<div style="border: 1px solid black; width: 40px; height: 20px; margin: 0 auto;">073</div>	<div style="border: 1px solid black; width: 40px; height: 20px; margin: 0 auto;">071</div>	<div style="border: 1px solid black; width: 40px; height: 20px; margin: 0 auto;">038</div>			
LEVEL I Time 1-299 Sec	LEVEL II Time 1-299 Sec	LEVEL III Time 1-299 Sec	LEVEL IV Time 1-299 Sec	FINISH SLOPE .1 to 9.9 Sec			
<div style="border: 1px solid black; width: 40px; height: 20px; margin: 0 auto;">009</div>	<div style="border: 1px solid black; width: 40px; height: 20px; margin: 0 auto;">012</div>	<div style="border: 1px solid black; width: 40px; height: 20px; margin: 0 auto;">009</div>	<div style="border: 1px solid black; width: 40px; height: 20px; margin: 0 auto;">010</div>	<div style="border: 1px solid black; width: 40px; height: 20px; margin: 0 auto;">9.9</div>			
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM	
<div style="border: 1px solid black; width: 40px; height: 20px; margin: 0 auto;">0.1</div>		<div style="border: 1px solid black; width: 40px; height: 20px; margin: 0 auto;">0.1</div>		<div style="border: 1px solid black; width: 40px; height: 20px; margin: 0 auto;">1.0</div>		<div style="border: 1px solid black; width: 40px; height: 20px; margin: 0 auto;">1.60</div>	
QUALIFICATION POSITIONS				WELDERS NAME _____ STAMP _____			
<input type="checkbox"/> HORIZONTAL <input type="checkbox"/> VERTICAL				RADIOGRAPH ACCEPTANCE _____			
MACHINE E-200T4 S/N <u>328</u>				TENSILE TEST ACCEPTANCE _____			
HEAD S/N <u>1262</u>				REPORT NUMBER _____			
 <div style="margin-left: 10px;"> <p>ELECTRODE (Sketch)</p> <p>A <u>80°</u></p> <p>B <u>.015</u></p> <p>C <u>1.270</u></p> <p>D <u>.020</u></p> </div>				<p>APPROVALS:</p> <p>MFG. D/821 _____ DATE _____</p> <p>Q.E. D/814 _____ DATE _____</p> <p>ENGR. D/830 _____ DATE _____</p> <p>QUALITY CONTROL _____ DATE _____</p> <p style="text-align: center;">STAMP</p>			
				VISUAL ACCEPT			

FORM 3016 S-1 REV. 5-73

ORIGINAL PAGE IS  
OF POOR QUALITY

DATA SHEET  
1 1/2" Decreasing Amps

AUTOMATIC BUTTWELD  
WELDING PROCEDURE SPECIFICATION (WPS)

WPS No.

MPP NUMBER MPP-LO-0001		REVISION LETTER										PAGE 14 of 14			
SPECIFICATION NO.		REVISION.		DATE		TPS A/A 328-001 Sample #42 -25% + 8 Amps									
BACK-UP		PURGE GAS		X-Ray Results: Accept *											
INTERNAL GAS		ARG		HEAD GAS		ARG		O.D.		1.500		TUBE DATA			
FLOW CFH		5+2		FLOW CFH		15+5		WALL		0.049					
PRE-PURGE TIME		2 MIN(MIN)		(1)		PRE-PURGE TIME		15 SEC(MIN)		ALLOY					
POST-PURGE TIME		1 MIN(MIN)		POST-PURGE TIME		1 MIN(MIN)		FTG. P/N							
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.															
PROGRAMMER SETTINGS															
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps		PULSE LOW 5 to 199 Amps							
078		077		075		073		038							
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec		FINISH SLOPE .1 to 9.9 Sec							
009		012		009		010		9.9							
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM									
0.1		0.1		1.0		1.60									
QUALIFICATION POSITIONS															
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL															
MACHINE E-200T4 S/N 328															
HEAD S/N 1262															
WELDERS NAME _____ STAMP _____															
RADIOGRAPH ACCEPTANCE _____															
TENSILE TEST ACCEPTANCE _____															
REPORT NUMBER _____															
APPROVALS:															
MFG. D/821 _____ DATE _____															
Q.E. D/814 _____ DATE _____															
ENGR. D/830 _____ DATE _____															
QUALITY CONTROL _____ DATE _____															
STAMP															
VISUAL ACCEPT *BORDERLINE ON POROSITY															

ELECTRODE (Sketch)

A 80°

B .015

C 1.270

D .020

FTG.

# DATA SHEET 1 1/2" Increasing RPM

## AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

WPS No.

MPP NUMBER MPP-LO-0001		REVISION LETTER								PAGE 14 of 14	
SPECIFICATION NO. REVISION. . DATE TPS A/A 328-001 Sample #43 +5% RPM											
X-Ray Results: Accept											
BACK-UP		PURGE GAS				HEAD		TUBE DATA			
INTERNAL GAS ARG		HEAD GAS ARG		O.D.		1.500					
FLOW CFH 5+2		FLOW CFH 15+5		WALL		0.049					
PRE-PURGE TIME 2 MIN(MIN) (1) PRE-PURGE TIME 15 SEC(MIN) ALLOY											
POST-PURGE TIME 1 MIN(MIN) POST-PURGE TIME 1 MIN(MIN) FTG. P/W											
(1) Add 1 min (min) for each additional ft. o' line between the gas inlet and the joint to be welded.											
PROGRAMMER SETTINGS											
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps		PULSE LOW 5 to 199 Amps			
093		092		089		087		038			
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec		FINISH SLOPE .1 to 9.9 Sec			
009		012		009		010		9.9			
		PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM			
		0.1		0.1		1.0		1.68			
QUALIFICATION POSITIONS											
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL											
MACHINE E-200T4 S/N 328 HEAD S/N 1262											
WELDERS NAME _____ STAMP _____ RADIOGRAPH ACCEPTANCE _____ TENSILE TEST ACCEPTANCE _____ REPORT NUMBER _____											
APPROVALS: MFG. D/821 _____ DATE _____ Q.E. D/814 _____ DATE _____ ENGR. D/830 _____ DATE _____ QUALITY CONTROL _____ DATE _____ VISUAL ACCEPT _____ STAMP _____											
		ELECTRODE (Sketch) A 80° B .015 C 1.270 D .020									

FORM 3016 S-1 REV. 5-73




ORIGINAL PAGE IS  
OF POOR QUALITY

DATA SHEET  
1 1/2" Increasing RPM

AUTOMATIC BUTTWELD  
WELDING PROCEDURE SPECIFICATION (WPS)

WPS No.

MPP NUMBER	REVISION LETTER	PAGE		
MPP-LO-0001		14 of 14		
SPECIFICATION NO. REVISION. DATE TPS A/A 328-001 Sample #44 +10%				
X-Ray Results: Accept				
BACK-UP	PURGE GAS	HEAD		
INTERNAL GAS ARG	HEAD GAS ARG	TUBE DATA		
FLOW CFH 5+2	FLOW CFH 15+5	O.D. 1.500		
PRE-PURGE TIME 2 MIN(MIN)	PRE-PURGE TIME 15 SEC(MIN)	WALL 0.049		
ALLOY				
POST-PURGE TIME 1 MIN(MIN) POST-PURGE TIME 1 MIN(MIN) FTG. P/N				
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.				
PROGRAMMER SETTINGS				
WELD LEVEL I 5 to 199 Amps	WELD LEVEL II 5 to 199 Amps	WELD LEVEL III 5 to 199 Amps	WELD LEVEL IV 5 to 199 Amps	PULSE LOW 5 to 199 Amps
093	092	089	087	038
LEVEL I Time 1-299 Sec	LEVEL II Time 1-299 Sec	LEVEL III Time 1-299 Sec	LEVEL IV Time 1-299 Sec	FINISH SLOPE .1 to 9.9 Sec
009	012	009	010	9.9
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec
0.1		0.1		HEAD SPEED RPM
		1.0		1.76
QUALIFICATION POSITIONS				
<input type="checkbox"/> HORIZONTAL <input type="checkbox"/> VERTICAL				
MACHINE E-200T4 S/N 328				
HEAD S/N 1262				
WELDERS NAME _____ STAMP _____				
RADIOGRAPH ACCEPTANCE _____				
TENSILE TEST ACCEPTANCE _____				
REPORT NUMBER _____				
APPROVALS:				
MFG. D/821 _____ DATE _____				
Q.E. D/814 _____ DATE _____				
ENGR. D/830 _____ DATE _____				
QUALITY CONTROL _____ DATE _____				
VISUAL ACCEPT _____ STAMP _____				
		ELECTRODE (Sketch)		
		A 80°		
		B .015		
		C 1.270		
		D .020		

FORM 3016 S-1 REV. 5-73

# DATA SHEET 1 1/2" Increasing RPM

## AUTOMATIC BUTT WELD WELDING PROCEDURE SPECIFICATION (WPS)

WPS No.

MPP NUMBER MPP-LO-0001		REVISION LETTER								PAGE 14 of 14	
SPECIFICATION NO.		REVISION.		DATE		TPS A/A 328-001 Sample #45 +15%					
BACK-UP		PURGE GAS		X-Ray Results: Accept				HEAD			
INTERNAL GAS		ARG		HEAD GAS		ARG		O.D.		1.500	
FLOW CFH		5+2		FLOW CFH		15+5		WALL		0.049	
PRE-PURGE TIME		2 MIN(MIN)		(1) PRE-PURGE TIME		15 SEC(MIN)		ALLOY			
POST-PURGE TIME		1 MIN(MIN)		POST-PURGE TIME		1 MIN(MIN)		FTG. P/N			
(1) Add 1 min (min) for each additional ft. o <sup>+</sup> line between the gas inlet and the joint to be welded.											
PROGRAMMER SETTINGS											
WELD LEVEL I		WELD LEVEL II		WELD LEVEL III		WELD LEVEL IV		PULSE LOW			
5 to 199 Amps		5 to 199 Amps		5 to 199 Amps		5 to 199 Amps		5 to 199 Amps			
093		092		089		087		038			
LEVEL I		LEVEL II		LEVEL III		LEVEL IV		FINISH SLOPE			
Time 1-299 Sec		Time 1-299 Sec		Time 1-299 Sec		Time 1-299 Sec		.1 to 9.9 Sec			
009		012		009		010		9.9			
PULSE HIGH		PULSE LOW		ROTATION		DELAY		HEAD SPEED		RPM	
.1 to 9.9 Sec		.1 to 9.9 Sec		.1 to 9.9 Sec		.1 to 9.9 Sec		1.00		1.84	
0.1		0.1		1.00		1.84					
QUALIFICATION POSITIONS											
<input type="checkbox"/> HORIZONTAL		<input checked="" type="checkbox"/> VERTICAL									
MACHINE E-200T4 S/N		328		WELDERS NAME		STAMP					
HEAD S/N		1262		RADIOGRAPH ACCEPTANCE							
				TENSILE TEST ACCEPTANCE							
				REPORT NUMBER							
				APPROVALS:							
				MFG. D/821		DATE					
				Q.E. D/814		DATE					
				ENGR. D/830		DATE					
				QUALITY CONTROL		STAMP					
				VISUAL ACCEPT							

FORM 3016-S-1 REV. 5-73

DATA SHEET  
1 1/2" Increasing RPM

## WPS No.

125

# DATA SHEET 1 1/2" Increasing RPM

## AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

WPS No.

WPS NUMBER MPP-LO-0001		REVISION LETTER				PAGE 14 of 14
SPECIFICATION NO. REVISION.		DATE TPS A/A 328-001 Sample #61 +25%				
BACK-UP		PURGE GAS		X-Ray Results: Accept		
INTERNAL GAS ARG		HEAD GAS ARG		O.D. 1.500		
FLOW CFH 5+2		FLOW CFH 15+5		WALL 0.049		
PRE-PURGE TIME 2 MIN(MIN)		(1) PRE-PURGE TIME 15 SEC(MIN)		ALLOY		
POST-PURGE TIME 1 MIN(MIN)		POST-PURGE TIME 1 MIN(MIN)		FTG. P/N		
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.						
PROGRAMMER SETTINGS						
WELD LEVEL I 5 to 199 Amps	WELD LEVEL II 5 to 199 Amps	WELD LEVEL III 5 to 199 Amps	WELD LEVEL IV 5 to 199 Amps	PULSE LOW 5 to 199 Amps		
093	092	089	087	038		
LEVEL I Time 1-299 Sec	LEVEL II Time 1-299 Sec	LEVEL III Time 1-299 Sec	LEVEL IV Time 1-299 Sec	FINISH SLOPE .1 to 9.9 Sec		
009	012	009	010	9.9		
	PULSE HIGH .1 to 9.9 Sec	PULSE LOW .1 to 9.9 Sec	ROTATION DELAY .1 to 9.9 Sec	HEAD SPEED RPM		
	0.1	0.1	1.0	2.00		
QUALIFICATION POSITIONS						
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL						
MACHINE E-200T4 S/N 328						
HEAD S/N 1328						
		ELECTRODE (Sketch) A 80° B .015 C 1.270 D .020				
WELDERS NAME _____ STAMP _____						
RADIOGRAPH ACCEPTANCE _____						
TENSILE TEST ACCEPTANCE _____						
REPORT NUMBER _____						
APPROVALS:						
MFG. D/821 _____ DATE _____						
Q.E. D/814 _____ DATE _____						
ENGR. D/830 _____ DATE _____						
QUALITY CONTROL _____ DATE _____						
STAMP						
REJECT LOP						


ORIGINAL PAGE IS  
OF POOR QUALITY

DATA SHEET  
1 1/2" Increasing RPM

AUTOMATIC BUTTWELD  
WELDING PROCEDURE SPECIFICATION (WPS)

WPS No.

MPP NUMBER MPP-LO-0001		REVISION LETTER								PAGE 14 of 14			
SPECIFICATION NO. REVISION.		DATE TPS A/A 328-001 Samples #62 +30%											
BACK-UP		PURGE GAS		X-Ray Results: Reject L.O.P.				HEAD				TUBE DATA	
INTERNAL GAS ARG		HEAD GAS ARG		O.D. 1.500				FLOW CFH 5+2				WALL 0.049	
PRE-PURGE TIME 2 MIN(MIN)(1)		PRE-PURGE TIME 15 SEC(MIN)		ALLOY									
POST-PURGE TIME 1 MIN(MIN)		POST-PURGE TIME 1 MIN(MIN)		FTG. P/N									
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.													
PROGRAMMER SETTINGS													
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps		PULSE LOW 5 to 199 Amps					
093		092		089		087		088					
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec		FINISH SLOPE .1 to 9.9 Sec					
009		012		009		010		9.9					
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM							
0.1		0.1		1.0		2.08							
QUALIFICATION POSITIONS													
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL													
MACHINE E-200T4 S/N 328													
HEAD S/N 1262													
WELDERS NAME _____ STAMP _____													
RADIOGRAPH ACCEPTANCE _____													
TENSILE TEST ACCEPTANCE _____													
REPORT NUMBER _____													
APPROVALS:													
MFG. D/821 _____ DATE _____													
Q.E. D/814 _____ DATE _____													
ENGR. D/830 _____ DATE _____													
QUALITY CONTROL _____ DATE _____													
STAMP													
REJECT LOP & WELD TOO HIGH													




ELECTRODE  
(Sketch)  
A 80°  
B .015  
C 1.270  
D .020

# DATA SHEET 1 1/2" Increasing RPM

## AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

MPP NUMBER MPP-LO-0001		REVISION LETTER										WPS No.		PAGE 14 of 14	
SPECIFICATION NO.		REVISION.		DATE		TPS A/A 328-001 Sample #63 +25%									
BACK-UP		PURGE GAS		X-Ray Results: Reject for L.O.P											
INTERNAL GAS		ARG		HEAD GAS		ARG		O.D.		1.500		TUBE DATA			
FLOW CFH		5+2		FLOW CFH		15+5		WALL		0.049					
PRE-PURGE TIME		2 MIN(MIN)(1)		PRE-PURGE TIME		15 SEC(MIN)		ALLOY							
POST-PURGE TIME		1 MIN(MIN)		POST-PURGE TIME		1 MIN(MIN)		FTG. P/H							
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.															
PROGRAMMER SETTINGS															
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps		PULSE LOW 5 to 199 Amps							
093		092		089		087		038							
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec		FINISH SLOPE .1 to 9.9 Sec							
009		012		009		010		9.9							
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM									
0.1		0.1		1.0		1.95									
QUALIFICATION POSITIONS															
<input type="checkbox"/> HORIZONTAL		<input checked="" type="checkbox"/> VERTICAL		WELDERS NAME _____ STAMP _____											
MACHINE E-200T4 S/N		328		RADIOGRAPH ACCEPTANCE _____											
HEAD S/N		1262		TENSILE TEST ACCEPTANCE _____											
				REPORT NUMBER _____											
				APPROVALS:											
				MFG. D/821 _____ DATE _____											
				Q.E. D/814 _____ DATE _____											
				ENGR. D/830 _____ DATE _____											
				QUALITY CONTROL _____ DATE _____											
				STAMP _____											
REJECT LOP & COLD WELD ON INSP.															




ELECTRODE (Sketch)	
A	80
B	.015
C	1.270
D	.020

ORIGINAL PAGE IS  
OF POOR QUALITY

DATA SHEET  
1 1/2" Increasing RPM

AUTOMATIC BUTTWELD  
WELDING PROCEDURE SPECIFICATION (WPS)

MPP NUMBER MPP-LO-0001		WPS No.		
REVISION LETTER		PAGE 14 of 14		
SPECIFICATION NO. REVISION. DATE TPS A/A 328-001 Sample #64 +20%				
BACK-UP		PURGE GAS		
INTERNAL GAS ARG		HEAD		
FLOW CFH 5+2		O.D. 1.500		
PRE-PURGE TIME 2 MIN(MIN)(1)		HEAD GAS ARG		
POST-PURGE TIME 1 MIN(MIN)		FLOW CFH 15+5		
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.		WALL 0.049		
PRE-PURGE TIME 15 SEC(MIN) ALLOY				
POST-PURGE TIME 1 MIN(MIN) FTG. P/N				
PROGRAMMER SETTINGS				
WELD LEVEL I 5 to 199 Amps	WELD LEVEL II 5 to 199 Amps	WELD LEVEL III 5 to 199 Amps	WELD LEVEL IV 5 to 199 Amps	PULSE LOW 5 to 199 Amps
093	092	089	087	038
LEVEL I Time 1-299 Sec	LEVEL II Time 1-299 Sec	LEVEL III Time 1-299 Sec	LEVEL IV Time 1-299 Sec	FINISH SLOPE .1 to 9.9 Sec
009	012	009	010	9.9
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec
0.1		0.1		HEAD SPEED RPM
		1.0		1.92
QUALIFICATION POSITIONS				
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL				
WELDERS NAME _____ STAMP _____				
MACHINE E-200T4 S/N 328				
HEAD S/N 1262				
RADIOGRAPH ACCEPTANCE _____				
TENSILE TEST ACCEPTANCE _____				
REPORT NUMBER _____				
APPROVALS:				
MFG. D/821 _____ DATE _____				
Q.E. D/814 _____ DATE _____				
ENGR. D/830 _____ DATE _____				
QUALITY CONTROL _____ DATE _____				
ACCEPT _____ STAMP _____				
		ELECTRODE (Sketch)		
		A 80°		
		B .015		
		C 1.270		
		D .020		

FORM 3016-S-1 REV. 8-73

# AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

WPS No.

MPP NUMBER <b>MPP-L0-0001</b>	REVISION LETTER <div style="display: flex; justify-content: space-around;"> <div style="border: 1px solid black; width: 20px; height: 20px;"></div> <div style="border: 1px solid black; width: 20px; height: 20px;"></div> <div style="border: 1px solid black; width: 20px; height: 20px;"></div> <div style="border: 1px solid black; width: 20px; height: 20px;"></div> <div style="border: 1px solid black; width: 20px; height: 20px;"></div> <div style="border: 1px solid black; width: 20px; height: 20px;"></div> <div style="border: 1px solid black; width: 20px; height: 20px;"></div> <div style="border: 1px solid black; width: 20px; height: 20px;"></div> <div style="border: 1px solid black; width: 20px; height: 20px;"></div> <div style="border: 1px solid black; width: 20px; height: 20px;"></div> </div>	PAGE <b>14 of 14</b>
----------------------------------	---	-------------------------

**SPECIFICATION NO. REVISION.      DATE      TPS A/A 328-001      Sample #65 -5%**

**BACK-UP**

INTERNAL GAS ARG

FLOW CFH 5+2

**PURGE GAS**

HEAD GAS ARG

FLOW CFH 15+5

**X-Ray Results: Accept**

**HEAD**

O.D. 1.500

WALL 0.049

**TUBE DATA**

PRE-PURGE TIME 2 MIN(MIN)(1) PRE-PURGE TIME 15 SEC(MIN) ALLOY \_\_\_\_\_

POST-PURGE TIME 1 MIN(MIN) POST-PURGE TIME 1 MIN(MIN) FTG. P/N \_\_\_\_\_

(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.


**PROGRAMMER SETTINGS**

<b>WELD LEVEL I</b> 5 to 199 Amps <div style="border: 1px solid black; padding: 5px; text-align: center;">093</div>	<b>WELD LEVEL II</b> 5 to 199 Amps <div style="border: 1px solid black; padding: 5px; text-align: center;">092</div>	<b>WELD LEVEL III</b> 5 to 199 Amps <div style="border: 1px solid black; padding: 5px; text-align: center;">089</div>	<b>WELD LEVEL IV</b> 5 to 199 Amps <div style="border: 1px solid black; padding: 5px; text-align: center;">087</div>	<b>PULSE LOW</b> 5 to 199 Amps <div style="border: 1px solid black; padding: 5px; text-align: center;">038</div>
<b>LEVEL I</b> Time 1-299 Sec <div style="border: 1px solid black; padding: 5px; text-align: center;">009</div>	<b>LEVEL II</b> Time 1-299 Sec <div style="border: 1px solid black; padding: 5px; text-align: center;">012</div>	<b>LEVEL III</b> Time 1-299 Sec <div style="border: 1px solid black; padding: 5px; text-align: center;">009</div>	<b>LEVEL IV</b> Time 1-299 Sec <div style="border: 1px solid black; padding: 5px; text-align: center;">010</div>	<b>FINISH SLOPE</b> .1 to 9.9 Sec <div style="border: 1px solid black; padding: 5px; text-align: center;">9.9</div>
		<b>PULSE HIGH</b> .1 to 9.9 Sec <div style="border: 1px solid black; padding: 5px; text-align: center;">0.1</div>	<b>PULSE LOW</b> .1 to 9.9 Sec <div style="border: 1px solid black; padding: 5px; text-align: center;">0.1</div>	<b>ROTATION DELAY</b> .1 to 9.9 Sec <div style="border: 1px solid black; padding: 5px; text-align: center;">1.0</div>
			<b>HEAD SPEED</b> RPM <div style="border: 1px solid black; padding: 5px; text-align: center;">1.52</div>	

**QUALIFICATION POSITIONS**  
☐ HORIZONTAL      ☒ VERTICAL

MACHINE E-200T4 S/N 328

HEAD S/N 1262



ELECTRODE (Sketch)

A 80°

B .015

C 1.270

D .020

FTG.

WELDERS NAME \_\_\_\_\_ STAMP \_\_\_\_\_

RADIOGRAPH ACCEPTANCE \_\_\_\_\_

TENSILE TEST ACCEPTANCE \_\_\_\_\_

REPORT NUMBER \_\_\_\_\_

APPROVALS:

MFG. D/821 \_\_\_\_\_ DATE \_\_\_\_\_

Q.E. D/814 \_\_\_\_\_ DATE \_\_\_\_\_

ENGR.D/830 \_\_\_\_\_ DATE \_\_\_\_\_

QUALITY CONTROL \_\_\_\_\_ DATE \_\_\_\_\_

STAMP

VISUAL ACCEPT




**DATA SHEET**  
**1 1/2" Decreasing RPM**

**ORIGINAL PAGE IS  
OF POOR QUALITY**

**AUTOMATIC BUTT WELD  
WELDING PROCEDURE SPECIFICATION (WPS)**



WPS No. \_\_\_\_\_

MPP NUMBER <b>MPP-L0-0001</b>		REVISION LETTER <div style="display: flex; justify-content: space-between;"> <div style="border: 1px solid black; width: 15px; height: 15px;"></div> <div style="border: 1px solid black; width: 15px; height: 15px;"></div> <div style="border: 1px solid black; width: 15px; height: 15px;"></div> <div style="border: 1px solid black; width: 15px; height: 15px;"></div> <div style="border: 1px solid black; width: 15px; height: 15px;"></div> <div style="border: 1px solid black; width: 15px; height: 15px;"></div> <div style="border: 1px solid black; width: 15px; height: 15px;"></div> <div style="border: 1px solid black; width: 15px; height: 15px;"></div> <div style="border: 1px solid black; width: 15px; height: 15px;"></div> <div style="border: 1px solid black; width: 15px; height: 15px;"></div> </div>								PAGE <b>14 of 14</b>	
SPECIFICATION NO. REVISION. DATE <b>TPS A/A 328-001 Sample #66 -10% RPM</b>											
BACK-UP				PURGE GAS				X-Ray Results: <b>Accept</b>			
INTERNAL GAS <b>ARG</b>				HEAD GAS <b>ARG</b>				TUBE DATA			
FLOW CFH <b>5+2</b>				FLOW CFH <b>15+5</b>				O.D. <b>1.500</b>			
PRE-PURGE TIME <b>2 MIN(MIN)</b> (1)				PRE-PURGE TIME <b>15 SEC(MIN)</b>				ALLOY _____			
POST-PURGE TIME <b>1 MIN(MIN)</b>				POST-PURGE TIME <b>1 MIN(MIN)</b>				FTG. P/W _____			
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.											
<b>PROGRAMMER SETTINGS</b>											
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps		PULSE LOW 5 to 199 Amps			
<div style="border: 1px solid black; padding: 5px;">093</div>		<div style="border: 1px solid black; padding: 5px;">092</div>		<div style="border: 1px solid black; padding: 5px;">089</div>		<div style="border: 1px solid black; padding: 5px;">087</div>		<div style="border: 1px solid black; padding: 5px;">038</div>			
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec		FINISH SLOPE .1 to 9.9 Sec			
<div style="border: 1px solid black; padding: 5px;">009</div>		<div style="border: 1px solid black; padding: 5px;">012</div>		<div style="border: 1px solid black; padding: 5px;">009</div>		<div style="border: 1px solid black; padding: 5px;">010</div>		<div style="border: 1px solid black; padding: 5px;">9.9</div>			
PULSE HIGH .1 to 9.9 Sec				PULSE LOW .1 to 9.9 Sec				ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM	
<div style="border: 1px solid black; padding: 5px;">0.1</div>				<div style="border: 1px solid black; padding: 5px;">0.1</div>				<div style="border: 1px solid black; padding: 5px;">1.0</div>		<div style="border: 1px solid black; padding: 5px;">1.44</div>	
<b>QUALIFICATION POSITIONS</b> <input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL											
MACHINE E-200T4 S/N <b>328</b> HEAD S/N <b>1262</b>											
				<b>ELECTRODE (Sketch)</b> A <b>80°</b> B <b>.015</b> C <b>1.270</b> D <b>.020</b>							
				WELDERS NAME _____ STAMP _____ RADIOGRAPH ACCEPTANCE _____ TENSILE TEST ACCEPTANCE _____ REPORT NUMBER _____ APPROVALS: MFG. D/821 _____ DATE _____ Q.E. D/814 _____ DATE _____ ENGR. D/830 _____ DATE _____ QUALITY CONTROL _____ DATE _____ <div style="text-align: right;">STAMP</div>							
VISUAL ACCEPT											

# DATA SHEET 1 1/2" Decreasing RPM

## AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

WPS No.

MPP NUMBER <b>MPP-LO-0001</b>		REVISION LETTER				PAGE <b>14 of 14</b>
SPECIFICATION NO. REVISION.		DATE <b>TPS A/A 328-001 Sample #67 -15% RPM</b>				
X-Ray Results: <b>Reject L.O.P.</b>						
BACK-UP		PURGE GAS		HEAD		TUBE DATA
INTERNAL GAS <b>ARG</b>		HEAD GAS <b>ARG</b>		O.D.	<b>1.500</b>	
FLOW CFH <b>5+2</b>		FLOW CFH <b>15+5</b>		WALL	<b>0.049</b>	
PRE-PURGE TIME <b>2 MIN(MIN)</b> (1) PRE-PURGE TIME <b>15 SEC(MIN)</b> ALLOY _____						
POST-PURGE TIME <b>1 MIN(MIN)</b> POST-PURGE TIME <b>1 MIN(MIN)</b> FTG. P/N _____						
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.						
PROGRAMMER SETTINGS						
WELD LEVEL I 5 to 199 Amps	WELD LEVEL II 5 to 199 Amps	WELD LEVEL III 5 to 199 Amps	WELD LEVEL IV 5 to 199 Amps	PULSE LOW 5 to 199 Amps		
<b>093</b>	<b>092</b>	<b>089</b>	<b>087</b>	<b>038</b>		
LEVEL I Time 1-299 Sec	LEVEL II Time 1-299 Sec	LEVEL III Time 1-299 Sec	LEVEL IV Time 1-299 Sec	FINISH SLOPE .1 to 9.9 Sec		
<b>009</b>	<b>012</b>	<b>009</b>	<b>010</b>	<b>9.9</b>		
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec	ROTATION DELAY .1 to 9.9 Sec	HEAD SPEED RPM		
<b>0.1</b>		<b>0.1</b>	<b>1.0</b>	<b>1.36</b>		
QUALIFICATION POSITIONS						
<input type="checkbox"/> HORIZONTAL <input type="checkbox"/> VERTICAL						
MACHINE E-200T4 S/N <b>328</b>						
HEAD S/N <b>1262</b>						
		ELECTRODE (Sketch) A <b>80°</b> B <b>.015</b> C <b>1.270</b> D <b>.020</b>				
						
WELDERS NAME _____ STAMP _____						
RADIOGRAPH ACCEPTANCE _____						
TENSILE TEST ACCEPTANCE _____						
REPORT NUMBER _____						
APPROVALS:						
MFG. D/821 _____ DATE _____						
Q.E. D/814 _____ DATE _____						
ENGR. D/830 _____ DATE _____						
QUALITY CONTROL _____ DATE _____						
ACCEPT _____ STAMP _____						

ORIGINAL PAGE IS  
OF POOR QUALITY

DATA SHEET  
1 1/2" Decreasing RPM

AUTOMATIC BUTTWELD  
WELDING PROCEDURE SPECIFICATION (WPS)

WPS No.

MPP NUMBER MPP-LO-0001		REVISION LETTER										PAGE 14 of 14			
SPECIFICATION NO.		REVISION.		DATE		TPS A/A 328-001 Sample #68 -20%									
BACK-UP		PURGE GAS		X-Ray Results: Reject L.O.P.		HEAD		TUBE DATA							
INTERNAL GAS		ARG		HEAD GAS		ARG		O.D.		1.500					
FLOW CFH		5+2		FLOW CFH		15+5		WALL		.049					
PRE-PURGE TIME		2 MIN(MIN)		(1) PRE-PURGE TIME		15 SEC(MIN)		ALLOY							
POST-PURGE TIME		1 MIN(MIN)		POST-PURGE TIME		1 MIN(MIN)		FTG. P/N							
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.															
PROGRAMMER SETTINGS															
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps		PULSE LOW 5 to 199 Amps							
093		092		089		087		038							
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec		FINISH SLOPE .1 to 9.9 Sec							
009		012		009		010		9.9							
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM									
0.1		0.1		1.0		1.28									
QUALIFICATION POSITIONS															
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL															
MACHINE E-200T4 S/N 328															
HEAD S/N 1262															
WELDERS NAME _____ STAMP _____															
RADIOGRAPH ACCEPTANCE _____															
TENSILE TEST ACCEPTANCE _____															
REPORT NUMBER _____															
APPROVALS:															
MFG. D/821 _____ DATE _____															
Q.E. D/814 _____ DATE _____															
ENGR. D/830 _____ DATE _____															
QUALITY CONTROL _____ DATE _____															
STAMP															
VISUAL REJECT L.O.P. & TRAIL OFF NO GOOD															

ELECTRODE (Sketch)

A 80°

B .015

C 1.270


D .020

FTG.

# DATA SHEET 1 1/2" Decreasing RPM

## AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

WPS No.

MPP NUMBER MPP-LO-0001		REVISION LETTER		PAGE 14 of 14	
SPECIFICATION NO.		REVISION.		DATE	
				TPS A/A 328-001 Sample #69 -17%	
BACK-UP		PURGE GAS		X-Ray Results: Reject L.O.P.	
INTERNAL GAS		HEAD GAS		TUBE DATA	
ARG		ARG		O.D. 1.500	
FLOW CFH 5+2		FLOW CFH 15+5		WALL .049	
PRE-PURGE TIME 2 MIN(MIN)		PRE-PURGE TIME 15 SEC(MIN)		ALLOY	
POST-PURGE TIME 1 MIN(MIN)		POST-PURGE TIME 1 MIN(MIN)		FTG. P/H	
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.					
PROGRAMMER SETTINGS					
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps	
093		092		089	
WELD LEVEL IV 5 to 199 Amps		PULSE LOW 5 to 199 Amps			
087		038			
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec	
009		012		009	
LEVEL IV Time 1-299 Sec		FINISH SLOPE .1 to 9.9 Sec			
010		9.9			
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec	
0.1		0.1		1.0	
		HEAD SPEED RPM		1.30	
QUALIFICATION POSITIONS					
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL					
MACHINE E-200T4 S/N 328					
HEAD S/N 1262					
		ELECTRODE (Sketch)			
		A 80°			
		B .015			
		C 1.270			
		D .020			
FTG.					
WELDERS NAME _____ STAMP _____					
RADIOGRAPH ACCEPTANCE _____					
TENSILE TEST ACCEPTANCE _____					
REPORT NUMBER _____					
APPROVALS:					
MFG. D/821 _____ DATE _____					
Q.E. D/814 _____ DATE _____					
ENGR. D/830 _____ DATE _____					
QUALITY CONTROL _____ DATE _____					
STAMP					
VISUAL REJECT L.O.P.					

DATA SHEET  
1 1/2" Decreasing RPM

## WPS No.

FORM 7016.5.1 REV. 5.73

# DATA SHEET 1 1/2" Decreasing RPM

## AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

WPS No.


MPP NUMBER MPP-LO-0001		REVISION LETTER										PAGE 14 of 14
SPECIFICATION NO.		REVISION.		DATE		TPS A/A 328-001 Sample #71 -13%						
BACK-UP		PURGE GAS		X-Ray Results: Accept				TUBE DATA				
INTERNAL GAS ARG		HEAD GAS ARG		O.D.		1.500						
FLOW CFH 5+2		FLOW CFH 15+5		WALL		.049						
PRE-PURGE TIME 2 MIN(MIN)		(1) PRE-PURGE TIME 15 SEC(MIN)		ALLOY								
POST-PURGE TIME 1 MIN(MIN)		POST-PURGE TIME 1 MIN(MIN)		FTG. P/H								
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.												
PROGRAMMER SETTINGS												
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps		PULSE LOW 5 to 199 Amps				
093		092		089		087		038				
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec		FINISH SLOPE .1 to 9.9 Sec				
009		012		009		010		9.9				
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM						
0.1		0.1		1.0		1.40						
QUALIFICATION POSITIONS												
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL												
MACHINE E-200T4 S/N 328 HEAD S/N 1262												
				ELECTRODE (Sketch) A 80° B .015 C 1.270 D .020								
				WELDERS NAME _____ STAMP _____ RADIOGRAPH ACCEPTANCE _____ TENSILE TEST ACCEPTANCE _____ REPORT NUMBER _____ APPROVALS: MFG. D/821 _____ DATE _____ Q.E. D/814 _____ DATE _____ ENGR. D/830 _____ DATE _____ QUALITY CONTROL _____ DATE _____ STAMP								

**DATA SHEET**  
**1 1/2" Increasing Shielding Gas**

**ORIGINAL PAGE IS  
OF POOR QUALITY**

**AUTOMATIC BUTTWELD  
WELDING PROCEDURE SPECIFICATION (WPS)**

WPS No. \_\_\_\_\_

MPP NUMBER <b>MPP-L0-0001</b>		REVISION LETTER				PAGE <b>14 of 14</b>
SPECIFICATION NO. REVISION.		DATE <b>TPS A/A 328-001</b> Sample #106 +5%				
PURGE GAS		X-Ray Results: <b>Accept</b>				
BACK-UP	HEAD	TUBE DATA				
INTERNAL GAS <b>ARG</b>	HEAD GAS <b>ARG</b>	Q.D. <b>1.500</b>				
FLOW CFH <b>5+2</b>	FLOW CFH <b>16</b>	WALL <b>0.049</b>				
PRE-PURGE TIME <b>2 MIN(MIN)</b> (1)		PRE-PURGE TIME <b>15 SEC(MIN)</b>			ALLOY _____	
POST-PURGE TIME <b>1 MIN(MIN)</b>		POST-PURGE TIME <b>1 MIN(MIN)</b>			FTG. P/N _____	
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.						
PROGRAMMER SETTINGS						
WELD LEVEL I 5 to 199 Amps	WELD LEVEL II 5 to 199 Amps	WELD LEVEL III 5 to 199 Amps	WELD LEVEL IV 5 to 199 Amps	PULSE LOW 5 to 199 Amps		
<b>093</b>	<b>092</b>	<b>089</b>	<b>087</b>	<b>038</b>		
LEVEL I Time 1-299 Sec	LEVEL II Time 1-299 Sec	LEVEL III Time 1-299 Sec	LEVEL IV Time 1-299 Sec	FINISH SLOPE .1 to 9.9 Sec		
<b>009</b>	<b>012</b>	<b>009</b>	<b>010</b>	<b>9.9</b>		
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM
<b>0.1</b>		<b>0.1</b>		<b>1.00</b>		<b>1.60</b>
QUALIFICATION POSITIONS				WELDERS NAME _____ STAMP _____		
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL				RADIOGRAPH ACCEPTANCE _____		
MACHINE E-200T4 S/N <b>328</b>				TENSILE TEST ACCEPTANCE _____		
HEAD S/N <b>1328</b>				REPORT NUMBER _____		
 <div style="margin-left: 10px;"> ELECTRODE (Sketch)  A <b>80°</b>  B <b>.015</b>  C <b>1.270</b>  D <b>.020</b> </div>				APPROVALS:		
				MFG. D/821 _____ DATE _____		
				Q.E. D/814 _____ DATE _____		
				ENGR. D/830 _____ DATE _____		
				QUALITY CONTROL _____ DATE _____		
				STAMP		
VISUAL ACCEPT						

FORM 3916-S-1 REV. 5-73

# DATA SHEET

## 1 1/2" Increasing Shielding Gas

### AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)


WPS No. \_\_\_\_\_

MPP NUMBER <b>MPP-LO-0001</b>		REVISION LETTER <div style="display: flex; justify-content: space-between;"> <div style="border: 1px solid black; width: 15px; height: 15px;"></div> <div style="border: 1px solid black; width: 15px; height: 15px;"></div> <div style="border: 1px solid black; width: 15px; height: 15px;"></div> <div style="border: 1px solid black; width: 15px; height: 15px;"></div> <div style="border: 1px solid black; width: 15px; height: 15px;"></div> <div style="border: 1px solid black; width: 15px; height: 15px;"></div> <div style="border: 1px solid black; width: 15px; height: 15px;"></div> <div style="border: 1px solid black; width: 15px; height: 15px;"></div> <div style="border: 1px solid black; width: 15px; height: 15px;"></div> <div style="border: 1px solid black; width: 15px; height: 15px;"></div> </div>								PAGE <b>14 of 14</b>	
<b>SPECIFICATION NO. REVISION. DATE</b> <b>TPS A/A 328-001 Sample #107 +10%</b>											
<div style="display: flex; justify-content: space-between;"> <div> <b>PURGE GAS</b>            BACK-UP    <b>ARG</b>            INTERNAL GAS    <b>ARG</b>            FLOW CFH    <b>5+2</b> </div> <div> <b>HEAD</b>            HEAD GAS    <b>ARG</b>            FLOW CFH    <b>17</b> </div> <div> <b>TUBE DATA</b>            O.D.    <b>1.500</b>            WALL    <b>0.049</b> </div> </div>											
<b>X-Ray Results: Accept</b>											
<b>PRE-PURGE TIME</b> <u>2 MIN(MIN)</u> (1) <b>PRE-PURGE TIME</b> <u>15 SEC(MIN)</u> <b>ALLOY</b> _____											
<b>POST-PURGE TIME</b> <u>1 MIN(MIN)</u> <b>POST-PURGE TIME</b> <u>1 MIN(MIN)</u> <b>FTG. P/N</b> _____ (1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.											
<b>PROGRAMMER SETTINGS</b>											
<b>WELD LEVEL I</b> 5 to 199 Amps <div style="border: 1px solid black; padding: 5px; text-align: center;">093</div>		<b>WELD LEVEL II</b> 5 to 199 Amps <div style="border: 1px solid black; padding: 5px; text-align: center;">092</div>		<b>WELD LEVEL III</b> 5 to 199 Amps <div style="border: 1px solid black; padding: 5px; text-align: center;">089</div>		<b>WELD LEVEL IV</b> 5 to 199 Amps <div style="border: 1px solid black; padding: 5px; text-align: center;">087</div>		<b>PULSE LOW</b> 5 to 199 Amps <div style="border: 1px solid black; padding: 5px; text-align: center;">038</div>			
<b>LEVEL I</b> Time 1-299 Sec <div style="border: 1px solid black; padding: 5px; text-align: center;">009</div>		<b>LEVEL II</b> Time 1-299 Sec <div style="border: 1px solid black; padding: 5px; text-align: center;">012</div>		<b>LEVEL III</b> Time 1-299 Sec <div style="border: 1px solid black; padding: 5px; text-align: center;">009</div>		<b>LEVEL IV</b> Time 1-299 Sec <div style="border: 1px solid black; padding: 5px; text-align: center;">010</div>		<b>FINISH SLOPE</b> .1 to 9.9 Sec <div style="border: 1px solid black; padding: 5px; text-align: center;">9.9</div>			
<b>PULSE HIGH</b> .1 to 9.9 Sec <div style="border: 1px solid black; padding: 5px; text-align: center;">0.1</div>				<b>PULSE LOW</b> .1 to 9.9 Sec <div style="border: 1px solid black; padding: 5px; text-align: center;">0.1</div>				<b>ROTATION DELAY</b> .1 to 9.9 Sec <div style="border: 1px solid black; padding: 5px; text-align: center;">1.00</div>		<b>HEAD SPEED</b> RPM <div style="border: 1px solid black; padding: 5px; text-align: center;">1.60</div>	

**QUALIFICATION POSITIONS**

☐ HORIZONTAL    ☒ VERTICAL

**MACHINE** E-200T4 S/N 328  
**HEAD** S/N 1628



**ELECTRODE (Sketch)**

A 80°

B .015

C 1.270

D .020

**WELDERS NAME** \_\_\_\_\_ **STAMP** \_\_\_\_\_

**RADIOGRAPH ACCEPTANCE** \_\_\_\_\_

**TENSILE TEST ACCEPTANCE** \_\_\_\_\_

**REPORT NUMBER** \_\_\_\_\_

**APPROVALS:**

**MFG.** D/821 \_\_\_\_\_ **DATE** \_\_\_\_\_  
**Q.E.** D/814 \_\_\_\_\_ **DATE** \_\_\_\_\_  
**ENGR.** D/830 \_\_\_\_\_ **DATE** \_\_\_\_\_  
**QUALITY CONTROL** \_\_\_\_\_ **DATE** \_\_\_\_\_

**STAMP**

**VISUAL ACCEPT**

FORM 7016.5-1 REV 5-73



**DATA SHEET**  
**1 1/2" Increasing Shielding Gas**

**ORIGINAL PAGE IS  
OF POOR QUALITY**

**AUTOMATIC BUTT WELD  
WELDING PROCEDURE SPECIFICATION (WPS)**

<b>MPP NUMBER</b> MPP-LO-0001		<b>REVISION LETTER</b>				<b>PAGE</b> 14 of 14
<b>SPECIFICATION NO.</b>		<b>REVISION.</b>		<b>DATE</b>		<b>TPS A/A 328-001 Sample #118 +20%</b>
<b>BACK-UP</b>		<b>PURGE GAS</b>		<b>X-Ray Results:</b>		<b>Accept</b>
<b>INTERNAL GAS:</b> ARG		<b>HEAD GAS:</b> ARG		<b>TUBE DATA</b>		
<b>FLOW CFH</b> 5+2		<b>FLOW CFH</b> 18		<b>O.D.</b> 1.500		
				<b>WALL</b> .049		
<b>PRE-PURGE TIME</b> 2 MIN(MIN)		<b>(1) PRE-PURGE TIME</b> 15 SEC(MIN)		<b>ALLOY</b>		
<b>POST-PURGE TIME</b> 1 MIN(MIN)		<b>POST-PURGE TIME</b> 1 MIN(MIN)		<b>FTG. P/N</b>		
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.						
<b>PROGRAMMER SETTINGS</b>						
<b>WELD LEVEL I</b> 5 to 199 Amps	<b>WELD LEVEL II</b> 5 to 199 Amps	<b>WELD LEVEL III</b> 5 to 199 Amps	<b>WELD LEVEL IV</b> 5 to 199 Amps	<b>PULSE LOW</b> 5 to 199 Amps		
093	092	089	087	038		
<b>LEVEL I</b> Time 1-299 Sec	<b>LEVEL II</b> Time 1-299 Sec	<b>LEVEL III</b> Time 1-299 Sec	<b>LEVEL IV</b> Time 1-299 Sec	<b>FINISH SLOPE</b> .1 to 9.9 Sec		
009	012	009	010	9.9		
<b>PULSE HIGH</b> .1 to 9.9 Sec		<b>PULSE LOW</b> .1 to 9.9 Sec		<b>ROTATION DELAY</b> .1 to 9.9 Sec		<b>HEAD SPEED</b> RPM
0.1		0.1		1.0		1.60
<b>QUALIFICATION POSITIONS</b>						
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL						
<b>MACHINE</b> E-200T4 S/N 328						
<b>HEAD S/N</b> 1262						
		<b>ELECTRODE (Sketch)</b>				
		A 80°				
		B .015				
		C 1.270				
		D .020				
<b>WELDERS NAME</b> _____ <b>STAMP</b> _____						
<b>RADIOGRAPH ACCEPTANCE</b> _____						
<b>TENSILE TEST ACCEPTANCE</b> _____						
<b>REPORT NUMBER</b> _____						
<b>APPROVALS:</b>						
MFG. D/821 _____ <b>DATE</b> _____						
Q.E. D/814 _____ <b>DATE</b> _____						
ENGR. D/830 _____ <b>DATE</b> _____						
<b>QUALITY CONTROL</b> _____ <b>DATE</b> _____						
<b>ACCEPT</b> _____ <b>STAMP</b> _____						

FORM 111.1 REV. 5-73

# DATA SHEET 1 1/2" Increasing Shielding Gas


## AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

MPP NUMBER MPP-LO-0001		WPS No.		REVISION LETTER		PAGE 14 of 14	
SPECIFICATION NO.		REVISION.		DATE		TPS A/A 328-001 Sample #119 +30%	
BACK-UP		PURGE GAS		X-Ray Results: Accept			
INTERNAL GAS ARG		HEAD GAS ARG		HEAD		TUBE DATA	
FLOW CFH 5+2		FLOW CFH 20		O.D. 1.500		WALL 0.049	
PRE-PURGE TIME 2 MIN(MIN)(1)		PRE-PURGE TIME 15 SEC(MIN)		ALLOY			
POST-PURGE TIME 1 MIN(MIN)		POST-PURGE TIME 1 MIN(MIN)		FTG. P/N			
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.							
PROGRAMMER SETTINGS							
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps	
093		092		089		087	
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec	
009		012		009		010	
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		FINISH SLOPE .1 to 9.9 Sec	
0.1		0.1		1.0		9.9	
HEAD SPEED RPM							
1.60							
QUALIFICATION POSITIONS							
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL							
MACHINE E-200T4 S/N 328							
HEAD S/N 1							
		ELECTRODE (Sketch)					
		A 80°					
		B .015					
		C 1.270					
		D .020					
WELDERS NAME _____ STAMP _____ RADIOGRAPH ACCEPTANCE _____ TENSILE TEST ACCEPTANCE _____ REPORT NUMBER _____ APPROVALS: MFG. D/821 _____ DATE _____ Q.E. D/814 _____ DATE _____ ENGR. D/830 _____ DATE _____ QUALITY CONTROL _____ DATE _____ STAMP _____							
ACCEPT							

ORIGINAL PAGE IS  
OF POOR QUALITY

DATA SHEET  
1 1/2" Increasing Shielding Gas

AUTOMATIC BUTTWELD  
WELDING PROCEDURE SPECIFICATION (WPS)


WPS No.		
MPP NUMBER <b>MPP-LO-0001</b>	REVISION LETTER <div style="border: 1px solid black; height: 15px; width: 100%;"></div>	PAGE 14 of 14
SPECIFICATION NO. <b>REVISION.</b> DATE <b>TPS A/A 328-001</b> Sample <b>#120 +40%</b>		
X-Ray Results: <b>Accept</b>		
BACK-UP	PURGE GAS	HEAD
INTERNAL GAS <u>ARG</u>	HEAD GAS <u>ARG</u>	TUBE DATA
FLOW CFH <u>5+2</u>	FLOW CFH <u>22</u>	O.D. <u>1.500</u>
WALL <u>0.049</u>		
PRE-PURGE TIME <u>2 MIN(MIN)</u> (1) PRE-PURGE TIME <u>15 SEC(MIN)</u> ALLOY _____		
POST-PURGE TIME <u>1 MIN(MIN)</u> POST-PURGE TIME <u>1 MIN(MIN)</u> FTG. P/N _____		
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.		
PROGRAMMER SETTINGS		
WELD LEVEL I 5 to 199 Amps	WELD LEVEL II 5 to 199 Amps	WELD LEVEL III 5 to 199 Amps
093	092	089
WELD LEVEL IV 5 to 199 Amps	PULSE LOW 5 to 199 Amps	
087	038	
LEVEL I Time 1-299 Sec	LEVEL II Time 1-299 Sec	LEVEL III Time 1-299 Sec
009	012	009
LEVEL IV Time 1-299 Sec	FINISH SLOPE .1 to 9.9 Sec	
010	9.9	
PULSE HIGH .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec
0.1		1.0
PULSE LOW .1 to 9.9 Sec		HEAD SPEED RPM
0.1		1.60
QUALIFICATION POSITIONS		
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL		
WELDERS NAME _____ STAMP _____		
RADIOGRAPH ACCEPTANCE _____		
TENSILE TEST ACCEPTANCE _____		
REPORT NUMBER _____		
APPROVALS:		
MFG. D/821 _____ DATE _____		
Q.E. D/814 _____ DATE _____		
ENGR. D/830 _____ DATE _____		
QUALITY CONTROL _____ DATE _____		
STAMP		
ACCEPT		
<div style="display: flex; align-items: center;"><div style="flex: 1;"></div><div style="flex: 1; padding-left: 10px;"><p>ELECTRODE (Sketch)</p><p>A <u>80°</u></p><p>B <u>.015</u></p><p>C <u>1.270</u></p><p>D <u>.020</u></p></div></div>		

# DATA SHEET

## 1 1/2" Decreasing Shielding Gas

### AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

WPS No. \_\_\_\_\_



MPP NUMBER <b>MPP-LO-0001</b>		REVISION LETTER <div style="display: flex; justify-content: space-between;"> <div style="border: 1px solid black; width: 15px; height: 15px;"></div> <div style="border: 1px solid black; width: 15px; height: 15px;"></div> <div style="border: 1px solid black; width: 15px; height: 15px;"></div> <div style="border: 1px solid black; width: 15px; height: 15px;"></div> <div style="border: 1px solid black; width: 15px; height: 15px;"></div> <div style="border: 1px solid black; width: 15px; height: 15px;"></div> <div style="border: 1px solid black; width: 15px; height: 15px;"></div> <div style="border: 1px solid black; width: 15px; height: 15px;"></div> <div style="border: 1px solid black; width: 15px; height: 15px;"></div> <div style="border: 1px solid black; width: 15px; height: 15px;"></div> <div style="border: 1px solid black; width: 15px; height: 15px;"></div> <div style="border: 1px solid black; width: 15px; height: 15px;"></div> </div>										PAGE <b>14 of 14</b>			
<b>SPECIFICATION NO. REVISION. DATE</b> <b>TPS A/A 328-001</b> <b>Sample #100 -5%</b>															
<b>BACK-UP</b> <b>PURGE GAS</b> <b>X-Ray Results: Accept</b>				<b>HEAD</b> <b>TUBE DATA</b>											
<b>INTERNAL GAS</b> <u>ARG</u>				<b>HEAD GAS</b> <u>ARG</u>				<b>O.D.</b> <u>1.50</u>							
<b>FLOW CFH</b> <u>5+2</u>				<b>FLOW CFH</b> <u>14</u>				<b>WALL</b> <u>.049</u>							
<b>PRE-PURGE TIME</b> <u>2 MIN(MIN)</u> (1) <b>PRE-PURGE TIME</b> <u>15 SEC(MIN)</u> <b>ALLOY</b> _____															
<b>POST-PURGE TIME</b> <u>1 MIN(MIN)</u> <b>POST-PURGE TIME</b> <u>1 MIN(MIN)</u> <b>FTG. P/N</b> _____ (1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.															
PROGRAMMER SETTINGS															
<b>WELD LEVEL I</b> 5 to 199 Amps			<b>WELD LEVEL II</b> 5 to 199 Amps			<b>WELD LEVEL III</b> 5 to 199 Amps			<b>WELD LEVEL IV</b> 5 to 199 Amps			<b>PULSE LOW</b> 5 to 199 Amps			
<div style="border: 1px solid black; width: 60px; height: 30px; margin: 0 auto;">093</div>			<div style="border: 1px solid black; width: 60px; height: 30px; margin: 0 auto;">092</div>			<div style="border: 1px solid black; width: 60px; height: 30px; margin: 0 auto;">089</div>			<div style="border: 1px solid black; width: 60px; height: 30px; margin: 0 auto;">087</div>			<div style="border: 1px solid black; width: 60px; height: 30px; margin: 0 auto;">038</div>			
<b>LEVEL I</b> Time 1-299 Sec			<b>LEVEL II</b> Time 1-299 Sec			<b>LEVEL III</b> Time 1-299 Sec			<b>LEVEL IV</b> Time 1-299 Sec			<b>FINISH SLOPE</b> .1 to 9.9 Sec			
<div style="border: 1px solid black; width: 60px; height: 30px; margin: 0 auto;">009</div>			<div style="border: 1px solid black; width: 60px; height: 30px; margin: 0 auto;">012</div>			<div style="border: 1px solid black; width: 60px; height: 30px; margin: 0 auto;">009</div>			<div style="border: 1px solid black; width: 60px; height: 30px; margin: 0 auto;">010</div>			<div style="border: 1px solid black; width: 60px; height: 30px; margin: 0 auto;">9.9</div>			
<b>PULSE HIGH</b> .1 to 9.9 Sec						<b>PULSE LOW</b> .1 to 9.9 Sec						<b>ROTATION DELAY</b> .1 to 9.9 Sec		<b>HEAD SPEED</b> RPM	
<div style="border: 1px solid black; width: 60px; height: 30px; margin: 0 auto;">0.1</div>						<div style="border: 1px solid black; width: 60px; height: 30px; margin: 0 auto;">0.1</div>						<div style="border: 1px solid black; width: 60px; height: 30px; margin: 0 auto;">1.0</div>		<div style="border: 1px solid black; width: 60px; height: 30px; margin: 0 auto;">1.60</div>	
<b>QUALIFICATION POSITIONS</b> <input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL															
<b>MACHINE</b> E-200T4 S/N <u>328</u> <b>HEAD</b> S/N <u>1262</u>															
<b>WELDERS NAME</b> _____ <b>STAMP</b> _____ <b>RADIOGRAPH ACCEPTANCE</b> _____ <b>TENSILE TEST ACCEPTANCE</b> _____ <b>REPORT NUMBER</b> _____															
<b>APPROVALS:</b> <b>MFG. D/821</b> _____ <b>DATE</b> _____ <b>Q.E. D/814</b> _____ <b>DATE</b> _____ <b>ENGR. D/830</b> _____ <b>DATE</b> _____ <b>QUALITY CONTROL</b> _____ <b>DATE</b> _____ <div style="text-align: right; margin-top: 10px;">STAMP</div>															
<div style="display: flex; align-items: center;"> <div style="flex: 1;">  </div> <div style="flex: 1; padding-left: 10px;"> <b>ELECTRODE (Sketch)</b>  <b>A</b> <u>80°</u>  <b>B</b> <u>.015</u>  <b>C</b> <u>1.270</u>  <b>D</b> <u>.020</u> </div> </div>															
VISUAL ACCEPT															

ORIGINAL PAGE IS  
OF POOR QUALITY

DATA SHEET  
1 1/2" Decreasing Shielding Gas

AUTOMATIC BUTTWELD  
WELDING PROCEDURE SPECIFICATION (WPS)

WPS No.

MPP NUMBER MPP-L0-0001		REVISION LETTER 								PAGE 14 of 14	
SPECIFICATION NO. REVISION. DATE Tps A/A 328-001 Sample #101 -10%											
PURGE GAS				X-Ray Results: Accept							
BACK-UP		HEAD		TUBE DATA							
INTERNAL GAS ARG		HEAD GAS ARG		O.D.		1.50					
FLOW CFH 5+2		FLOW CFH 13+2		WALL		.049					
PRE-PURGE TIME 2 MIN(MIN)(1)				PRE-PURGE TIME 15 SEC(MIN)				ALLOY			
POST-PURGE TIME 1 MIN(MIN)				POST-PURGE TIME 1 MIN(MIN)				FTG. P/N			
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.											
PROGRAMMER SETTINGS											
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps		PULSE LOW 5 to 199 Amps			
093		092		089		087		038			
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec		FINISH SLOPE .1 to 9.9 Sec			
009		012		009		010		9.9			
		PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM			
		0.1		0.1		1.00		1.62			
QUALIFICATION POSITIONS											
<input type="checkbox"/> HORIZONTAL <input type="checkbox"/> VERTICAL											
MACHINE E-200T4 S/N 328 HEAD S/N 1262											
				ELECTRODE (Sketch) A 80° B .015 C 1.270 D .020							
				WELDERS NAME _____ STAMP _____ RADIOGRAPH ACCEPTANCE _____ TENSILE TEST ACCEPTANCE _____ REPORT NUMBER _____ APPROVALS: MFG. D/821 _____ DATE _____ Q.E. D/814 _____ DATE _____ ENGR. D/830 _____ DATE _____ QUALITY CONTROL _____ DATE _____ STAMP _____ VISUAL ACCEPT							

# DATA SHEET 1 1/2" Decreasing Shielding Gas

## AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

WPS. No.

MPP NUMBER MPP-LO-0001		REVISION LETTER		PAGE 14 of 14
SPECIFICATION NO. REVISION.		DATE TPS A/A 328-001 Sample #102 -15%		
BACK-UP		PURGE GAS		X-Ray Results: Accept
INTERNAL GAS	ARG	HEAD GAS	ARG	TUBE DATA
FLOW CFH	5+2	FLOW CFH	12+2	O.D. 1.500
PRE-PURGE TIME	2 MIN(MIN)	PRE-PURGE TIME	15 SEC(MIN)	WALL 0.049
POST-PURGE TIME 1 MIN(MIN)		POST-PURGE TIME 1 MIN(MIN) FTG. P/N		
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.				
PROGRAMMER SETTINGS				
WELD LEVEL I 5 to 199 Amps	WELD LEVEL II 5 to 199 Amps	WELD LEVEL III 5 to 199 Amps	WELD LEVEL IV 5 to 199 Amps	PULSE LOW 5 to 199 Amps
093	092	089	087	038
LEVEL I Time 1-299 Sec	LEVEL II Time 1-299 Sec	LEVEL III Time 1-299 Sec	LEVEL IV Time 1-299 Sec	FINISH SLOPE .1 to 9.9 Sec
009	012	009	010	9.9
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec
0.1		0.1		HEAD SPEED RPM
				1.60
QUALIFICATION POSITIONS				
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL				
MACHINE E-200T4 S/N 328				
HEAD S/N 1262				
		ELECTRODE (Sketch) A 80° B .015 C 1.270 D .020		
		WELDERS NAME _____ STAMP _____ RADIOGRAPH ACCEPTANCE _____ TENSILE TEST ACCEPTANCE _____ REPORT NUMBER _____ APPROVALS: MFG. D/821 _____ DATE _____ Q.E. D/814 _____ DATE _____ ENGR. D/830 _____ DATE _____ QUALITY CONTROL _____ DATE _____ STAMP _____ VISUAL ACCEPT		


FORM 3016 S-1 REV. 8-73

**DATA SHEET**  
**1 1/2" Decreasing Shielding Gas**

**ORIGINAL PAGE IS  
OF POOR QUALITY**

**AUTOMATIC BUTTWELD  
WELDING PROCEDURE SPECIFICATION (WPS)**


WPS No. \_\_\_\_\_

MPP NUMBER <b>MPP-LO-0001</b>		REVISION LETTER								PAGE 14 of 14	
<b>SPECIFICATION NO. REVISION. DATE</b> <u>TPS A/A 328-001</u> <u>Sample #103 -30%</u>											
<p align="center"><b>X-Ray Results: Accept</b></p>											
BACK-UP		PURGE GAS				HEAD		TUBE DATA			
INTERNAL GAS <u>ARG</u>		HEAD GAS <u>ARG</u>				O.D. <u>1.500</u>					
FLOW CFH <u>5+2</u>		FLOW CFH <u>10</u>				WALL <u>.049</u>					
PRE-PURGE TIME <u>2 MIN(MIN)</u> (1) PRE-PURGE TIME <u>15 SEC(MIN)</u> ALLOY <u>          </u>											
POST-PURGE TIME <u>1 MIN(MIN)</u> POST-PURGE TIME <u>1 MIN(MIN)</u> FTG. P/N <u>          </u> (1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.											
<b>PROGRAMMER SETTINGS</b>											
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps		PULSE LOW 5 to 199 Amps			
093		092		089		087		038			
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec		FINISH SLOPE .1 to 9.9 Sec			
009		012		009		010		9.9			
PULSE HIGH .1 to 9.9 Sec				PULSE LOW .1 to 9.9 Sec				ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM	
0.1				0.1				1.00		1.60	
<b>QUALIFICATION POSITIONS</b> <input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL											
MACHINE E-200T4 S/N <u>328</u> HEAD S/N <u>1262</u>											
WELDERS NAME _____ STAMP _____ RADIOGRAPH ACCEPTANCE _____ TENSILE TEST ACCEPTANCE _____ REPORT NUMBER _____											
<b>APPROVALS:</b> MFG. D/821 _____ DATE _____ Q.E. D/814 _____ DATE _____ ENGR. D/830 _____ DATE _____ QUALITY CONTROL _____ DATE _____ <div style="text-align: right;">STAMP</div>											
						<b>ELECTRODE (Sketch)</b> A <u>80°</u> B <u>.015</u> C <u>1.270</u> D <u>.020</u>					

# DATA SHEET 1 1/2" Decreasing Shielding Gas

## AUTOMATIC BUTTWELD WELDING PROCEDURE SPECIFICATION (WPS)

WPS No.


WPS NUMBER MPP-LO-0001		REVISION LETTER				PAGE 14 of 14
SPECIFICATION NO. REVISION.		DATE TPS A/A 328-001 Sample #104 -50%				
PURGE GAS		X-Ray Results: Accept				
BACK-UP	HEAD	TUBE DATA				
INTERNAL GAS ARG	HEAD GAS ARG	O.D. 1.500				
FLOW CFH 5+2	FLOW CFH 7.5	WALL 0.049				
PRE-PURGE TIME 2 MIN(MIN)(1)		PRE-PURGE TIME 15 SEC(MIN)			ALLOY	
POST-PURGE TIME 1 MIN(MIN)		POST-PURGE TIME 1 MIN(MIN)			FTG. P/H	
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.						
PROGRAMMER SETTINGS						
WELD LEVEL I 5 to 199 Amps	WELD LEVEL II 5 to 199 Amps	WELD LEVEL III 5 to 199 Amps	WELD LEVEL IV 5 to 199 Amps	PULSE LOW 5 to 199 Amps		
093	092	089	087	038		
LEVEL I Time 1-299 Sec	LEVEL II Time 1-299 Sec	LEVEL III Time 1-299 Sec	LEVEL IV Time 1-299 Sec	FINISH SLOPE .1 to 9.9 Sec		
009	012	009	010	9.9		
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		HEAD SPEED RPM
0.1		0.1		1.00		1.60
QUALIFICATION POSITIONS						
<input type="checkbox"/> HORIZONTAL <input checked="" type="checkbox"/> VERTICAL						
MACHINE E-200T4 S/N 328						
HEAD S/N 1262						
		ELECTRODE (Sketch) A 80° B .015 C 1.270 D .020				
WELDERS NAME _____ STAMP _____						
RADIOGRAPH ACCEPTANCE _____						
TENSILE TEST ACCEPTANCE _____						
REPORT NUMBER _____						
APPROVALS:						
MFG. D/821 _____ DATE _____						
Q.E. D/814 _____ DATE _____						
ENGR. D/830 _____ DATE _____						
QUALITY CONTROL _____ DATE _____						
STAMP						
REJECT EXCESSIVE HOT SPOT						



DATA SHEET  
1 1/2" Decreasing Shielding Gas

ORIGINAL PAGE IS  
OF POOR QUALITY

AUTOMATIC BUTTWELD  
WELDING PROCEDURE SPECIFICATION (WPS)

MPP NUMBER MPP-L0-0001		WPS No.		REVISION LETTER		PAGE 14 of 14	
SPECIFICATION NO. REVISION.		DATE		TPS A/A 328-001		Sample #105 -6%	
BACK-UP		PURGE GAS		X-Ray Results: Accept			
INTERNAL GAS ARG		HEAD GAS ARG		TUBE DATA			
FLOW CFH 5+2		FLOW CFH 5		O.D. 1.500			
PRE-PURGE TIME 2 MIN(MIN)		PRE-PURGE TIME 15 SEC(MIN)		ALLOY			
POST-PURGE TIME 1 MIN(MIN)		POST-PURGE TIME 1 MIN(MIN)		FTG. P/II			
(1) Add 1 min (min) for each additional ft. of line between the gas inlet and the joint to be welded.							
PROGRAMMER SETTINGS							
WELD LEVEL I 5 to 199 Amps		WELD LEVEL II 5 to 199 Amps		WELD LEVEL III 5 to 199 Amps		WELD LEVEL IV 5 to 199 Amps	
093		092		089		087	
LEVEL I Time 1-299 Sec		LEVEL II Time 1-299 Sec		LEVEL III Time 1-299 Sec		LEVEL IV Time 1-299 Sec	
009		012		009		010	
PULSE HIGH .1 to 9.9 Sec		PULSE LOW .1 to 9.9 Sec		ROTATION DELAY .1 to 9.9 Sec		FINISH SLOPE .1 to 9.9 Sec	
0.1		0.1		1.00		9.9	
HEAD SPEED RPM						1.60	
QUALIFICATION POSITIONS							
<input type="checkbox"/> HORIZONTAL		<input checked="" type="checkbox"/> VERTICAL					
MACHINE E-200T4 S/N		328					
HEAD S/N		1328					
		ELECTRODE (Sketch) A 80° B .015 C 1.270 D .020					
		WELDERS NAME _____ STAMP _____ RADIOGRAPH ACCEPTANCE _____ TENSILE TEST ACCEPTANCE _____ REPORT NUMBER _____ APPROVALS: MFG. D/821 _____ DATE _____ Q.E. D/814 _____ DATE _____ ENGR. D/830 _____ DATE _____ QUALITY CONTROL _____ DATE _____ VISUAL ACCEPT _____ STAMP _____					